CHAPTER

79

ENGINE OIL

(LEAP-1B ENGINES)



CHAPTER 79 ENGINE OIL

Subject/Page	Date	coc	Subject/Page	Date	COC	Subject/Page	Date	COC
79-EFFECTIV	E PAGES		79-00-00 (con	t)		79-00-00 (con	t)	
1 thru 3	Sep 15/2023		R 629	Sep 15/2023		665	Jan 15/2023	
4	BLANK		R 630	Sep 15/2023		666	Sep 15/2022	
79-CONTENTS	S		631	Sep 15/2022		667	Sep 15/2022	
1	Sep 15/2022		632	Sep 15/2022		668	Sep 15/2022	
2	Sep 15/2022		633	Sep 15/2022		669	May 15/2023	
3	Sep 15/2021		634	Sep 15/2022		670	Sep 15/2022	
4	May 15/2023		R 635	Sep 15/2023		671	Sep 15/2022	
79-00-00			R 636	Sep 15/2023		672	Sep 15/2022	
601	Jan 15/2023		R 637	Sep 15/2023		673	Sep 15/2022	
602	Jan 15/2023		R 638	Sep 15/2023		674	Sep 15/2022	
603	Sep 15/2022		R 639	Sep 15/2023		R 675	Sep 15/2023	
604	Sep 15/2022		640	Sep 15/2022		676	Sep 15/2022	
605	Sep 15/2022		R 641	Sep 15/2023		R 677	Sep 15/2023	
606	Sep 15/2022		R 642	Sep 15/2023		R 678	Sep 15/2023	
607	Sep 15/2022		R 643	Sep 15/2023		R 679	Sep 15/2023	
608	Sep 15/2022		644	Sep 15/2022		680	Sep 15/2022	
609	Sep 15/2022		645	Sep 15/2022		681	Sep 15/2022	
610	Sep 15/2022		646	Sep 15/2022		682	Sep 15/2022	
611	Jan 15/2023		647	Sep 15/2022		683	Sep 15/2022	
612	Sep 15/2022			•		684	BLANK	
613	Sep 15/2022		648	Sep 15/2022		79-00-00		
614	Sep 15/2022		649	Sep 15/2022		901	Sep 15/2021	
615	Sep 15/2022		650	Sep 15/2022		902	Sep 15/2021	
	•		651	Sep 15/2022		79-11-01	I 45/0000	
616	Sep 15/2022		652	Sep 15/2022		401	Jan 15/2023	
617	Sep 15/2022		653	Sep 15/2022		402	Sep 15/2021	
618	Sep 15/2022		654	Sep 15/2022		403	Sep 15/2021	
619	Sep 15/2022		655	Sep 15/2022		404	Sep 15/2021	
620	Sep 15/2022		656	Sep 15/2022		405	Sep 15/2021	
621	Sep 15/2022		657	Sep 15/2022		406	Sep 15/2021	
622	Jan 15/2023		658	Sep 15/2022		407	Sep 15/2021	
623	Sep 15/2022		659	Sep 15/2022		408	Sep 15/2021	
624	Sep 15/2022		R 660	Sep 15/2023		409	Sep 15/2021	
625	Sep 15/2022		661	Sep 15/2022		410	Sep 15/2021	
626	Sep 15/2022		662	Sep 15/2022		411	May 15/2023	
627	Sep 15/2022		663	Sep 15/2022		412	Sep 15/2021	
R 628	Sep 15/2023		664	May 15/2023		413	Sep 15/2021	

 $\mbox{A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change} \label{eq:added}$

79-EFFECTIVE PAGES



CHAPTER 79 ENGINE OIL

Subject/Page	Date	COC	Subject/Page	Date	COC	Subject/Page	Date	COC
79-11-01 (con	t)		79-21-02 (con	t)		79-21-03 (con	t)	
414	Sep 15/2021		416	May 15/2023		411	Sep 15/2021	
79-11-03			417	May 15/2023		412	Sep 15/2021	
401	Jan 15/2023		418	May 15/2023		413	May 15/2023	
402	Sep 15/2021		419	Sep 15/2022		414	Sep 15/2021	
403	Sep 15/2021		420	Sep 15/2022		415	Sep 15/2021	
404	Sep 15/2021		421	Sep 15/2022		416	Sep 15/2021	
405	May 15/2023		422	Sep 15/2022		417	Sep 15/2021	
406	Sep 15/2021		423	Sep 15/2022		418	Sep 15/2021	
79-21-01			424	Sep 15/2022		419	Sep 15/2021	
401	Jan 15/2023		425	Sep 15/2022		420	BLANK	
402	Sep 15/2021		426	Sep 15/2022		79-21-04		
403	Sep 15/2021		427	May 15/2023		201	Jan 15/2023	
404	Sep 15/2021		428	Sep 15/2022		202	Sep 15/2021	
405	Sep 15/2021		429	Sep 15/2022		203	Sep 15/2021	
406	Sep 15/2021		430	Sep 15/2022		204	Sep 15/2021	
407	Sep 15/2021		79-21-02			205	Sep 15/2021	
408	May 15/2023		601	May 15/2022		203	•	
409	Sep 15/2021		602	Jan 15/2023			Sep 15/2021	
410	Sep 15/2021		603	May 15/2022		207	Sep 15/2021	
411	Sep 15/2021		604	May 15/2022		208	Sep 15/2021	
412	BLANK		605	May 15/2022		209	Sep 15/2021	
79-21-02			606	May 15/2022		210	Sep 15/2021	
401	Jan 15/2023		607	May 15/2022		211	Sep 15/2021	
402	Jan 15/2023		608	May 15/2022		212	Sep 15/2021	
403	Sep 15/2022		609	May 15/2022		213	Sep 15/2021	
404	Sep 15/2022		610	BLANK		214	Sep 15/2021	
405	Sep 15/2022		79-21-03			215	Sep 15/2022	
406	Sep 15/2022		401	May 15/2023		216	Jan 15/2023	
407	Sep 15/2022		402	May 15/2023		217	May 15/2022	
408	Sep 15/2022		403	Sep 15/2021		218	May 15/2022	
409	Sep 15/2022		404	Sep 15/2021		219	May 15/2022	
410	Sep 15/2022		405	Sep 15/2021		220	May 15/2022	
411	Sep 15/2022		406	Sep 15/2021		221	Sep 15/2021	
412	May 15/2023		407	Sep 15/2021		222	Sep 15/2021	
413	Sep 15/2022		408	Sep 15/2021		223	Sep 15/2021	
414	Sep 15/2022		409	Sep 15/2021		224	Sep 15/2021	
415	Sep 15/2022		410	Sep 15/2021		225	Sep 15/2021	

 $\mbox{A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change} \label{eq:added}$

79-EFFECTIVE PAGES



CHAPTER 79 ENGINE OIL

Subject/Pag	ge Date	coc	Subject/Page	Date	COC	Subject/Page	Date	COC
79-21-04 ((cont)		79-21-17 (con	t)		79-31-01		
226	Sep 15/2021		408	Jan 15/2023		401	Jan 15/2023	
227	Sep 15/2021		79-21-21			402	Jan 15/2023	
228	BLANK		R 401	Sep 15/2023		403	Sep 15/2021	
79-21-07			R 402	Sep 15/2023		404	Sep 15/2021	
401	May 15/2023		403	Sep 15/2021		405	Sep 15/2021	
402	May 15/2023		404	May 15/2023		406	May 15/2023	
403	May 15/2023		405	May 15/2023		407	Sep 15/2021	
404	May 15/2022		406	May 15/2023		408	Sep 15/2021	
405	May 15/2023		407	May 15/2023		79-32-01		
406	May 15/2023		408	May 15/2023		401	Jan 15/2023	
407	May 15/2023		R 409	Sep 15/2023		402	Sep 15/2021	
408	May 15/2023		R 410	Sep 15/2023		403	Sep 15/2021	
79-21-07	,		411	May 15/2023		404	Sep 15/2021	
601	Sep 15/2021		412	BLANK		405	Sep 15/2021	
602	Sep 15/2021		79-21-22	DE/ II VI		R 406	Sep 15/2023	
79-21-12			401	Jan 15/2023		O 407	Sep 15/2023	
401	Jan 15/2023		402	Sep 15/2021		O 408	Sep 15/2023	
402	Sep 15/2021		403	Sep 15/2021		79-35-01		
403	Sep 15/2021		404	Sep 15/2021		401	Jan 15/2023	
404	Sep 15/2021		405	Sep 15/2021		402	May 15/2023	
405	May 15/2023		406	-		403	May 15/2023	
406	Sep 15/2021			May 15/2022		404	Sep 15/2021	
79-21-14			407	Sep 15/2021		405	Sep 15/2021	
401	Jan 15/2023		408	BLANK		406	May 15/2023	
402	Sep 15/2021		79-30-00 601	Son 15/2021		407	May 15/2023	
403	Sep 15/2021			Sep 15/2021		408	May 15/2023	
404	Sep 15/2021		602	Jan 15/2023				
405	May 15/2023		603	Sep 15/2021				
406	Sep 15/2021		604	Sep 15/2021				
79-21-17			605	Sep 15/2021				
401	Jan 15/2023		606	Sep 15/2021				
402	Jan 15/2023		607	Sep 15/2021				
403	Sep 15/2021		608	Sep 15/2021				
404	Sep 15/2021		609	Sep 15/2021				
405	Sep 15/2021		610	Sep 15/2021				
406	May 15/2023		611	Sep 15/2021				
407	Jan 15/2023		612	Sep 15/2021				

 $\mbox{A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change} \label{eq:control_delta}$

79-EFFECTIVE PAGES



CHAPTER 79 ENGINE OIL

CHAPTER SECTION

	SECTION			
SUBJECT	SUBJECT	CONF	PAGE	<u>EFFECT</u>
ENGINE OIL - INSPECTION/CHECK	79-00-00		601	SIAALL
Engine Oil System (External Surfaces Walk Around) Inspection TASK 79-00-00-210-801-G00			601	SIA ALL
Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection TASK 79-00-00-210-802-G00			610	SIA ALL
Engine Oil System (Internal) Inspection TASK 79-00-00-210-803-G01			621	SIAALL
Oil Debris Monitoring System Sensor Inspection TASK 79-00-00-210-804-G00			628	SIAALL
Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check TASK 79-00-00-220-801-G00			635	SIA ALL
Engine Oil System (Fluids (Fuel or Skydrol) and Solids Contamination) Detailed Inspection TASK 79-00-00-211-801-G00			664	SIA ALL
Engine Oil System (Wear Metal Contamination) Inspection TASK 79-00-00-200-802-G00			669	SIA ALL
ODMS Fault Check TASK 79-00-00-200-803-G00			675	SIA ALL
Drain Tubes Inspection and Cleaning TASK 79-00-00-200-804-G00			676	SIAALL
ENGINE OIL - DDG MAINTENANCE PROCEDURES	79-00-00		901	SIA ALL
DDG 79-31-01 Oil Quantity Indicating Systems Inoperative - Preparation TASK 79-00-00-040-802-G00			901	SIA ALL
DDG 79-21-01 Engine Oil Debris Monitoring System Inoperative - Preparation TASK 79-00-00-040-804-G00			902	SIA ALL
OIL TANK - REMOVAL/INSTALLATION	79-11-01		401	SIA ALL
Oil Tank Removal TASK 79-11-01-000-801-G00			401	SIA ALL



CHAPTER 79 ENGINE OIL

CHAPTER SECTION

	SECTION			
SUBJECT	SUBJECT	CONF	<u>PAGE</u>	EFFECT
Oil Tank Installation TASK 79-11-01-400-801-G00			411	SIA ALL
OIL TANK FILLER CAP - REMOVAL/INSTALLATION	79-11-03		401	SIA ALL
Oil Tank Filler Cap Removal TASK 79-11-03-000-801-G00			401	SIA ALL
Oil Tank Filler Cap Installation TASK 79-11-03-400-801-G00			405	SIA ALL
MAIN FUEL/OIL HEAT EXCHANGER - REMOVAL/INSTALLATION	79-21-01		401	SIA ALL
Main Fuel/Oil Heat Exchanger Removal TASK 79-21-01-000-801-G00			401	SIA ALL
Main Fuel/Oil Heat Exchanger Installation TASK 79-21-01-400-801-G00			408	SIA ALL
ENGINE SURFACE AIR COOLING OIL COOLER - REMOVAL/INSTALLATION	79-21-02		401	SIA ALL
Engine Surface Air Cooling Oil Cooler 1 Removal TASK 79-21-02-000-801-G00			401	SIA ALL
Engine Surface Air Cooling Oil Cooler 1 Installation TASK 79-21-02-400-801-G00			412	SIA ALL
Engine Surface Air Cooling Oil Cooler 2 Removal TASK 79-21-02-000-802-G00			415	SIA ALL
Engine Surface Air Cooling Oil Cooler 2 Installation			427	SIA ALL
TASK 79-21-02-400-802-G00				
ENGINE SURFACE AIR COOLING OIL COOLER - INSPECTION/CHECK	79-21-02		601	SIA ALL
Engine Surface Air Cooling Oil Cooler Inspection TASK 79-21-02-211-801-G00			601	SIA ALL
LUBRICATION UNIT - REMOVAL/INSTALLATION	79-21-03		401	SIA ALL
Lubrication Unit Removal TASK 79-21-03-000-801-G00			401	SIA ALL
Lubrication Unit Installation TASK 79-21-03-400-801-G00			413	SIA ALL



CHAPTER 79 ENGINE OIL

CHAPTER SECTION

SECTION			
SUBJECT	CONF	PAGE	EFFECT
79-21-04		201	SIA ALL
		201	SIA ALL
		211	SIA ALL
		214	SIA ALL
79-21-07		401	SIA ALL
		401	SIA ALL
		406	SIA ALL
79-21-07		601	SIA ALL
		601	SIA ALL
79-21-12		401	SIA ALL
		401	SIA ALL
		405	SIA ALL
79-21-14		401	SIA ALL
		401	SIA ALL
		405	SIA ALL
79-21-17		401	SIA ALL
		401	SIA ALL
		406	SIA ALL
	79-21-07 79-21-07 79-21-12	SUBJECT CONF 79-21-04 79-21-07 79-21-12 79-21-14	SUBJECT CONF PAGE 79-21-04 201 201 211 214 214 79-21-07 401 406 406 79-21-07 601 601 401 401 405 79-21-14 401 405 401 79-21-17 401 405 401 405 401 401 405 79-21-17 401 401 401 402 401 403 401 404 401 405 401 401 401 402 401 403 401 404 401 405 401 401 401 402 401 403 401 404 401 405 401 406 401 407 401 408 401 409 401



CHAPTER 79 ENGINE OIL

CHAPTER SECTION

	SECTION			
SUBJECT	SUBJECT	CONF	<u>PAGE</u>	EFFECT
AIR OIL SEPARATOR - REMOVAL/INSTALLATION	79-21-21		401	SIA ALL
Air Oil Separator Removal TASK 79-21-21-000-801-G00			401	SIA ALL
Air Oil Separator Installation TASK 79-21-21-400-801-G00			409	SIA ALL
ANTI LEAK VALVE - REMOVAL/INSTALLATION	79-21-22		401	SIA ALL
Anti Leak Valve Removal TASK 79-21-22-000-801-G00			401	SIA ALL
Anti Leak Valve Installation TASK 79-21-22-400-801-G00			405	SIA ALL
OIL INDICATING SYSTEM - INSPECTION/CHECK	79-30-00		601	SIA ALL
Oil Indicating System Inspection TASK 79-30-00-210-801-G00			601	SIA ALL
OIL LEVEL SENSOR - REMOVAL/INSTALLATION	79-31-01		401	SIA ALL
Oil Level Sensor Removal TASK 79-31-01-000-801-G00			401	SIA ALL
Oil Level Sensor Installation TASK 79-31-01-400-801-G00			406	SIA ALL
OIL PRESSURE AND TEMPERATURE SENSOR - REMOVAL/INSTALLATION	79-32-01		401	SIA ALL
Oil Pressure and Temperature Sensor Removal TASK 79-32-01-000-801-G00			401	SIA ALL
Oil Pressure and Temperature Sensor Installation TASK 79-32-01-400-801-G00			406	SIA ALL
OIL FILTER DIFFERENTIAL PRESSURE SENSOR - REMOVAL/INSTALLATION	79-35-01		401	SIA ALL
Oil Filter Differential Pressure Sensor Removal TASK 79-35-01-000-801-G00			401	SIA ALL
Oil Filter Differential Pressure Sensor Installation TASK 79-35-01-400-801-G00			406	SIA ALL



ENGINE OIL - INSPECTION/CHECK

1. General

- A. This procedure has these tasks:
 - (1) An inspection of the engine oil system (external surfaces walk around)
 - (2) An inspection of the engine oil system (fan cowl panels and thrust reversers open)
 - (3) An inspection of the engine oil system (internal)
 - (4) An inspection of the oil debris monitoring system sensor
 - (5) A detailed dimensional check of the engine oil system (oil debris monitoring system sensor, scavenge screen plugs, starter magnetic plug, and oil filter)
 - (6) A detailed inspection of the engine oil system (fluids and solids contamination)
 - (7) An inspection of the engine oil system (wear metal contamination)
 - (8) A check of the ODMS fault.
 - (9) An inspection and cleaning of the drain tubes.

TASK 79-00-00-210-801-G00

2. Engine Oil System (External Surfaces Walk Around) Inspection

(Figure 601)

A. General

(1) This task gives the instructions on how to examine the engine and nacelle for evidence of oil leakage.

B. References

Reference	Title
71-00-00-800-802-G00	Engine Operation Limits (P/B 201)
71-00-02-000-801-G00	Power Plant - Removal (P/B 401)
71-00-02-400-801-G00	Power Plant - Installation (P/B 401)
71-71-00-200-801-G00	Engine Vents and Drains Inspection (P/B 601)
72-22-01-200-801-G00	Front Spinner Cone Inspection (P/B 601)
72-60-00-200-801-G00	Accessory Drives Inspection (P/B 601)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Prepare for the Inspection

SUBTASK 79-00-00-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.

SIA ALL



- (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

F. Engine Oil System (External Surfaces Walk Around) Inspection

SUBTASK 79-00-00-210-001-G00

- (1) Do the visual inspection of the fan blades [1], stage 1 booster vanes [2], and front spinner cone [3] as follows (Figure 601 (Sheet 1)):
 - (a) Examine the fan blades [1] and the inner side of the fan case for oil leakage.
 - (b) Do a visual inspection at the 6:00 o'clock position of the fan blades [1] and stage 1 booster vanes [2] behind the fan blades.
 - 1) If they are wet with oil, replace the engine (TASK 71-00-02-000-801-G00 and TASK 71-00-02-400-801-G00).
 - (c) Do the visual inspection of the front spinner cone [3].
 - 1) If it is wet with oil, look for indications of the source of the oil leakage (TASK 72-22-01-200-801-G00).

SUBTASK 79-00-00-210-002-G00

- (2) Do a visual inspection of the drain masts as follows (Figure 601 (Sheet 2)):
 - (a) Do a visual inspection of the fan drain mast [4].
 - (b) Do a visual inspection of the core drain mast [5].
 - (c) If there is oil leakage from the drain tubes on the drain masts, do this task: Engine Vents and Drains Inspection, TASK 71-71-00-200-801-G00.

SUBTASK 79-00-00-210-003-G00

- (3) Do a visual inspection of the bottom of left fan cowl panel [6] and the right fan cowl panel [7] (Figure 601 (Sheet 2), Figure 601 (Sheet 5)).
 - (a) If there is oil leakage, do this task: Accessory Drives Inspection, TASK 72-60-00-200-801-G00.

SUBTASK 79-00-00-210-005-G00

- (4) Do a visual inspection of these engine areas (Figure 601 (Sheet 6), Figure 601 (Sheet 5)):
 - NOTE: Oil puddling on the aft sump area cover, lower area of the forward plug, aft plug, and core primary nozzle is permitted if the oil consumption rate and leakage rate from the aft sump flooding drain are within the serviceable limits (TASK 71-00-00-800-802-G00).
 - (a) The aft sump area of the primary nozzle [10].
 - (b) The 6:00 o'clock areas of the forward plug [11] and aft plug [12].

SUBTASK 79-00-00-960-001-G00

(5) If the oil consumption rate and oil leakage rate are more than the serviceable limits, replace the engine (TASK 71-00-02-000-801-G00 and TASK 71-00-02-400-801-G00).

G. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-860-002-G00

- (1) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.

SIA ALL 79-00-00

LEAP-1B ENGINES




737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

(b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

----- END OF TASK -----

SIA ALL





NOTE:

STAGE 1 BOOSTER VANES ARE NOT VISIBLE IN THIS VIEW.

2465655 S0000574679_V1

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 1 of 6)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 604 Sep 15/2022





2465653 S0000574680_V3

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 2 of 6)

SIA ALL


D633AM101-SIA


ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 605 Sep 15/2022







2465684 S0000574681_V2

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 3 of 6)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





2465651 S0000574682_V1

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 4 of 6)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 607 Sep 15/2022





2523945 S0000595139_V1

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 5 of 6)

EFFECTIVITY

SIA ALL


D633AM101-SIA


ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 608 Sep 15/2022







2523943 S0000595137_V1

Engine Oil System (External Surfaces Walk Around) Inspection Figure 601/79-00-00-990-809-G00 (Sheet 6 of 6)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



TASK 79-00-00-210-802-G00

3. Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection (Figure 602)

A. General

(1) This task gives the instructions to do a visual inspection of the of the engine for evidence of oil leakage.

B. References

Reference	Title
70-00-05-200-801-G00	Tube and Hose Inspection Criteria and Damage Limits (P/B 201)
71-00-00-910-803-G00	Start the Engine (Normal Start) (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
B00682 [CP2011]	Solvent - Stoddard	MIL-PRF-680 Type I, II or III
B01058 [CP1039]	Solvent - Acetone, Reagent Grade	
B50290 [CP2559]	Solvent - degreasing, Ardrox 5503	
B50291 [CP2560]	Solvent - cleaning - BONDERITE C-SO IND 79 AERO (TURCO IND79)	
B50292 [CP2566]	Solvent - Degreasing - MAG-CHEM DIESTONE MTK	
B50293 [CP2584]	Solvent - Cleaning - Degreasol 99R	
B50294 [CP2656]	Solvent - Cleaning - MAGCHEM DIESTONE M-SK	
B50295 [CP2010]	Solvent - cleaning, White Spirit	

E. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

F. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1

SIA ALL



(Continued)

Number	Name/Location
416	Right Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

G. Prepare for the Inspection

SUBTASK 79-00-00-860-003-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-00-00-860-004-G00

(2) Do these tasks in sequence to safely open the left and right thrust reversers on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left or right fan cowl panels (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left or right thrust reversers (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

SIA ALL

79-00-00

Jan 15/2023



(Continued)

Number Name/Location

426 Right Thrust Reverser, Engine 2

H. Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection

SUBTASK 79-00-00-212-001-G00

- (1) Do a visual inspection of these components for oil leakage:
 - (a) Internal surface of the left fan cowl panel [1]
 - (b) Internal surface of the right fan cowl panel [2]
 - (c) Internal surface of the left thrust reverser [3]
 - (d) Internal surface of the right thrust reverser [4]
 - (e) Engine surface
 - (f) Oil tank [5]
 - (g) Non-return valve [6]
 - (h) lubrication unit and scavenge pump [1]
 - (i) Transfer gearbox assembly [8] and Fan frame [9] interfaces.

NOTE: Staining or wetting is permitted (e.g., Lubrication (petrolatum) used during seals, gaskets, and joints assembly).

SUBTASK 79-00-00-211-001-G00

(2) Do a visual inspection of tubes:

NOTE: Look for oil strips and drops to do this check.

- (a) Worn and cracked hoses [10] are not permitted.
- (b) Cracked tubes and tube coupling nuts [11] are not permitted.
- (c) Do this task: (Tube and Hose Inspection Criteria and Damage Limits, TASK 70-00-05-200-801-G00).
 - Repair if necessary.
- (d) Leakage is not permitted.

NOTE: Staining or wetting is permitted (e.g., Lubrication (engine oil) used during tubes assembly to ensure proper seating and to minimize the risk of damage).

SUBTASK 79-00-00-212-002-G00

- (3) If leakage is suspected, do these steps:
 - (a) Clean the suspected area with the solvent, B00682 [CP2011] or the acetone solvent, B01058 [CP1039] or the Ardrox 5503, B50290 [CP2559] or the BONDERITE C-SO IND 79 AERO solvent, B50291 [CP2560] or the MAG-CHEM DIESTONE MTK solvent, B50292 [CP2566] or the Degreasol 99R solvent, B50293 [CP2584] or the MAGCHEM DIESTONE M-SK solvent, B50294 [CP2656] or the White Spirit, B50295 [CP2010].
 - (b) Operate the engine at 70% of N1 or above to pressurize the oil system and to get accurate reading during leak test (TASK 71-00-00-910-803-G00).
 - (c) Do a visual inspection of the suspected area.
 - (d) If leakage is identified, tighten the nuts to the appropriate torque values and/or replace the defective components.
 - (e) Repeat the engine operation and visual inspection.

SIA ALL



SUBTASK 79-00-00-212-004-G00

- (4) Do a visual inspection of the attachment parts of the oil tubes.
 - (a) Replace the broken or cracked brackets [12].
 - (b) Replace the worn clamps [13].
 - (c) Install the missing nuts and bolts [14].
 - (d) Tighten the loose nuts and bolts [14] to the appropriate torque values.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-860-005-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the applicable left or right thrust reversers:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	<u>Name/Location</u>
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

- (b) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.


SUBTASK 79-00-00-860-006-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

 END	OF	TASK	
	\sim	17011	

SIA ALL





2462861 S0000573784_V1

Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 1 of 7)

EFFECTIVITY


SIA ALL

Page 614

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details






Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 2 of 7)

EFFECTIVITY
SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details






2463199 S0000573786_V1

Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 3 of 7)

- EFFECTIVITY SIA ALL D633AM101-SIA ECCN 9E991 BOEING PROPRIETARY - See title page for details





Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 4 of 7)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 5 of 7)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details






2463211 S0000573789_V1

Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 6 of 7)

SIA ALL





ICN-LEAP-1B-790000-B-F0301-A0028-A-001-01 2578075 S0000613642_V1

Engine Oil System (Fan Cowl Panels and Thrust Reversers Open) Inspection Figure 602/79-00-00-990-808-G00 (Sheet 7 of 7)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 620 Sep 15/2022



TASK 79-00-00-210-803-G01

4. Engine Oil System (Internal) Inspection

(Figure 603)

A. General

- (1) This task provides the instructions on how to examine the internal areas of the engine for oil system leakage.
- (2) This task also provides the steps to do if you find wet oil in these areas:
 - (a) Inlet guide vanes and the first stage blades of the fan booster
 - (b) Exhaust area.

B. References

Reference	Title
71-00-00-790-803-G00	Test No. 3 - Wet Motor Leak Test (P/B 501)
71-00-02-000-801-G00	Power Plant - Removal (P/B 401)
71-00-02-400-801-G00	Power Plant - Installation (P/B 401)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
72-00-00-290-811-G00	Low Pressure Turbine (LPT) Section Borescope Inspection (P/B 601)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
414	Right Fan Cowl, Engine 1	
415	Left Thrust Reverser, Engine 1	
416	Right Thrust Reverser, Engine 1	
423	Left Fan Cowl, Engine 2	
424	Right Fan Cowl, Engine 2	
425	Left Thrust Reverser, Engine 2	
426	Right Thrust Reverser, Engine 2	

SIA ALL



F. Prepare for the Inspection

SUBTASK 79-00-00-860-007-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-00-00-010-001-G00

(2) Do these tasks in sequence to safely open the left and right thrust reversers on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left or right fan cowl panels (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left or right thrust reversers (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

G. Engine Oil System (Internal) Inspection

SUBTASK 79-00-00-210-006-G00



DO NOT TOUCH THE COMPONENTS OF THE OIL SYSTEM IF THE ENGINE IS HOT. THESE COMPONENTS STAY HOTTER THAN OTHER COMPONENTS. HOT COMPONENTS CAN BURN YOU.

SIA ALL 79-00-00



(WARNING PRECEDES)



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET OIL STAY ON YOUR SKIN. THE SYNTHETIC OIL CONTAINS ADDITIVES THAT CAN BE POISONOUS IF THEY ARE ABSORBED THROUGH THE SKIN. CLEAN AWAY ALL OIL THAT GETS ON THE SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Do the visual examination of the engine oil system (Internal) as follows:
 - (a) Examine the fan blades [1] or the inner side of the fan stator case for oil leakage.
 - (b) If the fan blades [1] or the inner side of the fan stator case are wet with oil, do these steps:
 - 1) Examine the inlet guide vanes [2] and the first stage blades of the fan booster for oil leakage.
 - 2) If the inlet guide vanes [2] and the first-stage blades of the fan booster are wet with oil, do this task: Test No. 3 Wet Motor Leak Test, TASK 71-00-00-790-803-G00.
 - 3) If the leakage is not repairable, replace the engine (TASK 71-00-02-000-801-G00 and TASK 71-00-02-400-801-G00).
 - (c) Examine exhaust area for oil leakage.
 - (d) If the exhaust area is wet with oil, do these steps:
 - 1) Examine the primary nozzle [3] and exhaust plug [4] interfaces.
 - 2) If there is oil leakage, examine the internal area of the exhaust plug [4] for leakage at the oil tubes (Low Pressure Turbine (LPT) Section Borescope Inspection, TASK 72-00-00-290-811-G00).
 - 3) Examine the turbine rear frame struts [6] surfaces in the gaspath and the tubing interfaces on the outer side of the turbine rear frame [5].
 - 4) If you find oil leakage, examine the internal area of the exhaust plug [4] for leakage at the oil tubes (Low Pressure Turbine (LPT) Section Borescope Inspection, TASK 72-00-00-290-811-G00).
 - 5) If the leakage is not repairable, replace the engine (TASK 71-00-02-000-801-G00 and TASK 71-00-02-400-801-G00).

H. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-080-001-G00

(1) Remove all tools used to do the inspection and clean the work area.

SIA ALL



SUBTASK 79-00-00-410-001-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (2) Do these tasks in sequence to safely close the applicable left or right thrust reversers:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

- (b) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.


SUBTASK 79-00-00-860-008-G00

- (3) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.



SIA ALL 79-00-00






2456151 S0000571369_V1

Engine Oil System (Internal) Inspection Figure 603/79-00-00-990-806-G00 (Sheet 1 of 3)

SIA ALL D633AM101-SIA ECCN 9E991 BOEING PROPRIETARY - See title page for details 79-00-00

Page 625 Sep 15/2022





2456152 S0000571370_V1


Engine Oil System (Internal) Inspection Figure 603/79-00-00-990-806-G00 (Sheet 2 of 3)

SIA ALL

79-00-00

Page 626 Sep 15/2022





2456155 S0000571371_V1

Engine Oil System (Internal) Inspection Figure 603/79-00-00-990-806-G00 (Sheet 3 of 3)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-00-00

Page 627 Sep 15/2022



TASK 79-00-00-210-804-G00

5. Oil Debris Monitoring System Sensor Inspection

(Figure 604)

A. General

I

(1) This task gives the instructions to examine the Oil Debris Monitoring System (ODMS) sensor.

B. References

Reference	Title
71-00-00-700-802-G00	Test No. 26 - Debris Monitoring System Channel B Special
	Functions Test (P/B 501)
79-21-04-211-801-G00	Scavenge Screen Plug Inspection (P/B 201)
79-21-12-000-801-G00	Oil Debris Monitoring System Sensor Removal (P/B 401)
79-21-12-400-801-G00	Oil Debris Monitoring System Sensor Installation (P/B 401)
80-11-09-200-801-G00	Engine Starter Magnetic Plug Inspection (P/B 201)

C. Tools/Equipment

Reference	Description
STD-1070	Lens - Magnifying, 10X, Hand Held
STD-1280	Source - Air, Regulated, Dry Filtered, 0-30 PSIG

D. Consumable Materials

Reference	Description	Specification
B00682 [CP2011]	Solvent - Stoddard	MIL-PRF-680 Type I, II or III
G00034	Cotton Wiper - Process Cleaning Absorbent Wiper (Cheesecloth, Gauze)	AMS3819 Class 1 Grade A or B Form 1 (Supersede BMS15-5 CL A)

E. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

F. Prepare for the Inspection

SUBTASK 79-00-00-020-001-G00

(1) Do this task: Oil Debris Monitoring System Sensor Removal, TASK 79-21-12-000-801-G00.

NOTE: It is recommended to perform this task only when requested by another Aircraft Maintenance Manual (AMM)/ Interactive Fault Isolation Manual (IFIM)/scheduled maintenance task or CFM International (CFMI) instructions.

NOTE: If the ODMS sensor is removed for inspection only, it is not necessary to disconnect the ODMS sensor connector from the ODMS Signal Conditioner Unit (SCU).

(a) When a Customer Notification Request (CNR) is received, make sure to perform this task within CNR urgency requirements.

SIA ALL 79-00-00



G. Oil Debris Monitoring System Sensor Inspection

SUBTASK 79-00-00-200-004-G00



TAG THE REMOVED PARTICLES WITH THE ODMS SENSOR NAME TO PREVENT AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL DURING VISUAL CHARACTERIZATION AND LABORATORY ANALYSIS. AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL COULD LEAD TO AN INACCURATE INTERPRETATION OF SERVICEABLE CRITERIA AND DAMAGE CAN OCCUR.



CFM DOES NOT RECOMMEND THE USE OF ADHESIVE TAPE. HOWEVER, IF A PIECE OF ADHESIVE TAPE IS USED TO COLLECT THE PARTICLES, MAKE SURE THE ADHESIVE IS NOT TOO STRONG. IF THE ADHESIVE ON THE TAPE IS TOO STRONG, THE PARTICLES MAY BE DAMAGED WHEN THEY ARE REMOVED AND/OR IT WILL AFFECT THE LABORATORY ANALYSIS OF THE MATERIAL.

- (1) Inspect the ODMS sensor [1] for material presence on the magnetic tip [2] with a 10x hand held magnifying lens, STD-1070.
 - (a) If there are no findings on the magnetic tip [2] of the ODMS sensor [1], do these steps:
 - 1) Check the chip count value on the Debris Monitoring System (DMS) chip counter.
 - NOTE: Engine Propulsion Control System (EPCS) page 2 shows the engine DMS chip count for both Engine Electronic Controller (EEC) channel A and EEC channel B.
 - a) If chip count value = 0
 - <1> No further actions are required.
 - b) If chip count value > 0
 - <1> Refer to the IFIM and do the applicable procedure(s) (79-42852 or 79-42854).
 - <2> Reset chip count value, do this task: Test No. 26 Debris Monitoring System Channel B Special Functions Test, TASK 71-00-00-700-802-G00.
 - 2) Do this task: Oil Debris Monitoring System Sensor Installation, TASK 79-21-12-400-801-G00.
 - (b) If you find material on the magnetic tip [2] of the ODMS sensor [1], do these steps:
 - Take pictures of the particles on the magnetic tip [2] of the ODMS sensor [1], before
 you remove them.
 - 2) Carefully remove and keep the particles from the magnetic tip [2] of the ODMS sensor [1], with cotton wiper, G00034, on a thin sheet of paper.
 - After you remove all the particles, clean the magnetic tip [2] of the ODMS sensor [1] with solvent, B00682 [CP2011].
 - 4) Dry the magnetic tip [2] of the ODMS sensor [1] with a 0-30 psig dry filtered regulated air source, STD-1280.
 - 5) Make sure that the chip detector is free of all particles.

NOTE: If you do not remove all the particles from the ODMS sensor, a difference between the collected particles and chips count value can occur at the next ODMS sensor inspection.

SIA ALL



6) Do this task: Oil Debris Monitoring System Sensor Installation, TASK 79-21-12-400-801-G00.

SUBTASK 79-00-00-200-003-G00

(2) Examine particle size with a 10x hand held magnifying lens, STD-1070, and use scale paper to take pictures (View D and View F, Figure 604).

NOTE: Normal fuzz ONLY (less than 0.004 in. (0.10 mm)) is not expected with ODMS fault raised or chip count shift.

- (a) If you find ONLY very fine particles like powder, less than 0.004 in. (0.10 mm) (Normal Fuzz) in any dimension on the magnetic tip [2] of the ODMS sensor [1], do these steps:
 - 1) If chip count value = 0
 - a) No further actions are required.
 - If chip count value > 0
 - a) Refer to the IFIM and do the applicable procedure(s) (79-42852 or 79-42854).
 - b) Reset chip count value, do this task: Test No. 26 Debris Monitoring System Channel B Special Functions Test, TASK 71-00-00-700-802-G00.
 - 3) Continue the engine in service.
- (b) If you find particles that are larger than 0.004 in. (0.10 mm) (Abnormal Fuzz) in any dimension on the magnetic tip [2] of the ODMS sensor [1], do these steps:




DO NOT APPLY TEST NO. 26 - DEBRIS MONITORING SYSTEM RESET CHANNEL B SPECIAL FUNCTIONS TEST, TASK 71-00-00-700-802-G00. IF YOU DO NOT OBEY, DAMAGE CAN OCCUR TO THE ENGINE.

- Check the A, B, C sumps, Accessory Gear Box (AGB), and Transfer Gearbox (TGB) sumps scavenge screen plugs for further troubleshooting (TASK 79-21-04-211-801-G00).
- 2) Do this task: Engine Starter Magnetic Plug Inspection, TASK 80-11-09-200-801-G00.
- Analyze particles, do this task: Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check, TASK 79-00-00-220-801-G00.
- 4) If chip count value = 0
 - a) Refer to the IFIM and do the applicable procedure(s) (79-42852 or 79-42854).

——— END OF TASK ———

SIA ALL





ICNLEAP1B790000D5882800017A00101 2967651 S0000747146_V1

Oil Debris Monitoring System (ODMS) Sensor Inspection Figure 604/79-00-00-990-801-G00 (Sheet 1 of 4)

Figure 604/79-00-990-801-G00 (Sheet 1 of 4)


- EFFECTIVITY

SIA ALL

79-00-00

Page 631 Sep 15/2022





MAGNETIC TIP











CONTAMINATION ON THE MAGNETIC TIP



ICNLEAP1B790000D5882800018A00101 2355316 S00061516985_V5


Oil Debris Monitoring System (ODMS) Sensor Inspection Figure 604/79-00-00-990-801-G00 (Sheet 2 of 4)

SIA ALL









(ODMS SENSOR TIP DIMENSION)



ICNLEAP1B790000D5882800019A00101 2967680 \$0000747143_V1

Oil Debris Monitoring System (ODMS) Sensor Inspection Figure 604/79-00-00-990-801-G00 (Sheet 3 of 4)

EFFECTIVITY —

SIA ALL





0.0008 TO 0.004 INCH (0.02 TO 0.10 mm) (NORMAL FUZZ SATISFACTORY CONDITION)





0.016 TO 0.035 INCH (0.4 TO 0.9 mm) (ABNORMAL FUZZ UNSATISFACTORY CONDITION)



0.008 TO 0.003 INCH (0.2 TO 0.8 mm) (ABNORMAL FUZZ UNSATISFACTORY CONDITION)



ICNLEAP1B790000D5882800020A00101 2967682 \$0000747144_V1

Oil Debris Monitoring System (ODMS) Sensor Inspection Figure 604/79-00-00-990-801-G00 (Sheet 4 of 4)

EFFECTIVITY

SIA ALL



TASK 79-00-00-220-801-G00

6. Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check

(Figure 605, Figure 606)

A. General

(1) This task gives the instructions to do an analysis of the unwanted material found on the Oil Debris Monitoring System (ODMS) sensor tip, scavenge screens plugs, starter magnetic plug and oil filter cartridge.

B. References

Reference	Title
71-00-00-710-801-G00	Test No. 5 - Part Power Leak Check (P/B 501)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
79-21-04-211-801-G00	Scavenge Screen Plug Inspection (P/B 201)
79-21-04-400-801-G00	Scavenge Screen Plugs Installation (P/B 201)
79-21-07-400-801-G00	Oil Filter Cartridge Element Installation (P/B 401)
79-21-12-400-801-G00	Oil Debris Monitoring System Sensor Installation (P/B 401)
80-11-09-200-801-G00	Engine Starter Magnetic Plug Inspection (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-562	Lens - Magnifying, 10x	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

F. Prepare for the Check

SUBTASK 79-00-00-860-011-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SIA ALL



SUBTASK 79-00-00-860-012-G00

- (2) Do this task: Open the Fan Cowl Panels (Selection), TASK 71-11-04-010-801-G00.
 - (a) On the applicable engine, open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

G. Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check

SUBTASK 79-00-00-211-008-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. USE THE OIL IN AN AREA WITH GOOD AIRFLOW. THE OIL IS POISONOUS AND YOUR SKIN CAN ABSORB THE OIL. THE OIL FUMES CAN CAUSE INJURY.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.



YOU MUST PUT A MARK OR LABEL ON THE PARTICLES WITH THE SOURCE OF THE MATERIAL YOU REMOVE. THE MARK PREVENTS AN INCORRECT VISUAL IDENTIFICATION AND LABORATORY ANALYSIS. IF YOU DO NOT OBEY, DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do the visual inspection of the particles collected from the ODMS sensor, scavenge screen plugs/starter magnetic plug and oil filter cartridge to identify the physical properties of the material (shape, size, quantity, magnetic properties, color), do the following:
 - (a) Examine the particles with 10x magnifying lens, STD-562.

SIA ALL



(b) Any quantity of material that is less than or equal to 0.004 in. (0.10 mm) in all dimension (normal fuzz) is satisfactory with no need to send particles for analysis.

NOTE: Normal fuzz can be noticed on the new engines or engines after overhaul.

NOTE: Material that is larger than 0.004 in. (0.10 mm) in any dimension is not normal fuzz.

(c) Refer to NDT manual Part 9 "LEAP-00-70-30-05-02A-371B-D" and Part 10 "LEAP-00-70-30-04-02A-370B-D" to identify possible source or refer to the Field Guide for Lubrication System Debris Tool Number GEK 131722 for examples of shapes that may be seen on the ODMS sensor, scavenge screen plugs/magnetic plug and oil filter cartridge.

SUBTASK 79-00-00-211-009-G00

- (2) Examine the particles to identify their potential source from within the engine and the recommendations (Figure 606).
 - (a) To identify the particles, take into consideration the following:
 - size
 - shape
 - · quantity
 - · color
 - nature (magnetic, non magnetic, non metallic)
 - origin (sump, filter, ODMS sensor).
 - (b) If you found some magnetic material on the Accessory Gear Box (AGB) scavenge screen plug or on the ODMS sensor, make sure that you examine the starter magnetic plug for contamination (TASK 80-11-09-200-801-G00).

SUBTASK 79-00-00-211-010-G00



IF THERE IS AN INDICATION OF BEARING MATERIAL, DO NOT OPERATE THE ENGINE UNTIL YOU IDENTIFY THE MAGNETIC PARTICLES. IF YOU DO NOT OBEY, DAMAGE TO EQUIPMENT AND THE ENGINE CAN OCCUR.

- (3) Identify the nature of particles greater than normal fuzz from all sources (ODMS and/or scavenge screen, starter magnetic plug, oil filter).
 - (a) If material cannot be visually identified, send the particles to a laboratory for chemical analysis according to NDTM Part 10.
 - (b) Once you have identified the debris, examine the particles (Figure 606).
 - (c) If you find any other material, contact a CFM representative and provide maintenance history related to oil system (recent event, shop visit, part replacement).

SUBTASK 79-00-00-211-005-G00

(4) If you find magnetic particles that you cannot identify, do these steps:



IF THERE IS AN INDICATION OF BEARING MATERIAL, DO NOT OPERATE THE ENGINE UNTIL YOU IDENTIFY THE MAGNETIC PARTICLES. IF YOU DO NOT OBEY, DAMAGE TO EQUIPMENT AND THE ENGINE CAN OCCUR.

(a) Engine can Continue-In-Service (CIS) for 72 hours straight after ODMS sensor inspection until particles are identified if the below conditions are satisfied:

SIA ALL



· Magnetic particles were found at the ODMS sensor only.

NOTE: Magnetic particle in scavenge screen plugs are not allowed.

- · ODMS chips count is not reset.
- Maintenance messages 79-4119X (cumulative chip count) or 79-4286X (single flight chip count) or 79-4288X (oil filter approaching bypass) were not set at inspection and until laboratory report is available.
- (b) If at least one of those conditions is not fulfilled, the 72 hours CIS after ODMS sensor inspection does not apply anymore.
- (c) After you get the analysis from the laboratory, do the applicable corrective action for the type of material that is found (Figure 606).
 - If you find any other material, contact a CFM representative and provide maintenance history related to oil system (recent event, shop visit, part replacement).
- (d) Satisfactory condition for continue the engine in service with no need to send particles for analysis:
 - 1) Less than four particles, not more than 0.01 in. (0.25 mm) in any dimension.
- (e) Marginal condition:
 - Four or more particles between 0.004 in. (0.10 mm) and 0.01 in. (0.25 mm) in any dimension.
 - Or less than four particles between 0.01 in. (0.25 mm) and 0.02 in. (0.5 mm) in any dimension.
 - 1) Send the particles to the laboratory for analysis.
 - 2) Do the inspection of the oil debris and scavenge screen plugs for particles after each flight until you get the analysis from the laboratory.
 - If you find magnetic particles during the post flight inspections that you cannot identify limit the engine operation to 5 cycles or 25 hours whichever comes first.
 - 4) After you get the analysis from the laboratory, then do the applicable corrective action for the type of material that you found as defined in step (3).
- (f) Unsatisfactory condition:

I

- Four or more particles between 0.01 in. (0.25 mm) and 0.02 in. (0.5 mm) in any dimension.
- Or any quantity of particles that is more than 0.02 in. (0.5 mm) in any dimension.
- 1) Send the particles to the laboratory for analysis.
- Operate the engine at minimum of 70 percent N1 for 10 minutes (TASK 71-00-00-710-801-G00), then perform the oil debris monitoring system sensor inspection (TASK 79-00-00-210-804-G00), and scavenge screen plug inspection (TASK 79-21-04-211-801-G00).
 - a) If you find magnetic particles larger than 0.004 in. (0.10 mm) in any dimension during any oil debris monitoring system sensor and scavenge screen plugs inspection, do not operate the engine until the first sample of magnetic particles have been identified.
 - b) If you do not find magnetic particles, do these steps:
 - If you cannot get the analysis from the laboratory, do a check of the oil debris monitoring system sensor (TASK 79-00-00-210-804-G00) and

SIA ALL



scavenge screen plugs inspection (TASK 79-21-04-211-801-G00) after each flight until you get the analysis from the laboratory.

- After performing the oil debris monitoring system sensor and scavenge screen plugs inspections in the previous step, if you find magnetic particles larger than 0.004 in. (0.10 mm) in any dimension, do not operate the engine until the first sample of magnetic particles have been identified.
- c) After you get the analysis from the laboratory, do the applicable corrective action for the type of material that you found as defined in step (3).

H. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-860-028-G00

(1) If not already done, install the oil filter catridge element (TASK 79-21-07-400-801-G00).

SUBTASK 79-00-00-860-030-G00

(2) If not already done, install the single stage scavenge screen plugs and double stage scavenge screen plugs (TASK 79-21-04-400-801-G00).

SUBTASK 79-00-00-860-031-G00

(3) If not already done, install the ODMS sensor (TASK 79-21-12-400-801-G00).

SUBTASK 79-00-00-860-013-G00

- (4) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - (a) On the applicable engine, close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2


SUBTASK 79-00-00-860-014-G00

- 5) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.



SIA ALL 79-00-00





2457757 S0000571934_V3

Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug and Oil Filter) Detailed Dimensional Check Figure 605/79-00-00-990-807-G00

SIA ALL



RECOMMENDATION	SERVICEABLE	SERVICEABLE, RESET ODMS REF AMM TASK 71-00-00-700-802-G00	SERVICEABLE, RESET ODMS REF AMION IN 2. CAUTO-09-202-G00 •: CAMION IN CAPP. CHIP, MAKE SURE THAT IS DOES NOT MATCH WITH KEY LOCK INSERT THREAD (REFER TO FIGURE 17-4PH). SEE DEDICATED RECOMMENDATION IN CASE OF	SERVICEABLE, CONTINUE THE ENGINE IN SERVICE IF THERE IS NO OTHER METALLIC BEBRIS, RESET ODMS REF AMM TASK 71-00-00-700-802-G00	1) CONTINUE THE ENGINE IN SERVICE IF THE OIL PRESSURE AND CONSUMPTION ARE IN THE LIMITS. 2) DO A CHECKOF OIL PRESSURE AND CONSUMPTION IN 100 TO 200 HOURS. 3) DO A CHECK OF THE DOMS AND SCAVENGE SCREEN PLUGS IN 100-150 HOURS: - IF THERE IS NO ADDITIONAL PARTICLES IN SCAVENGE SCREEN PLUGS RETURN TO NORMAL OPERATION CONDITION, ENGINE IS IN SERVICEABLE CONDITION, ENGINE IS IN SERVICEABLE CONDITION, ENGINE IS IN SERVICEABLE ADDITIONAL PARTICLES, FOLLOW AMM TASK 71-00-070-802-G00 - IF THERE IS ADDITIONAL PARTICLES, FOLLOW AMM TASK 79-00-00-220-801-G00	IF THIS IS THE 1ST TIME, PARTICLE IS FOUND IN ODMS, DO A CHECK OF THE ODMS AND SCAVENGE SCREEN PLUGS IN 50-75 HOURS FOR 3 CONSECUTIVE TIMES: - IF THERE IS NO ADDITIONAL PARTICLES IN ODMS AND SCAVENGE SCREEN PLUGS RETURN TO NORMAL OPERATION CONDITION. - OPERATION CONDITION. - IF THERE IS ADDITIONAL PARTICLES, FOLLOW AMM TASK 79-00-00-222-801-600 - IF THERE IS ADDITIONAL PARTICLES, FOLLOW AMM TASK 79-00-00-222-801-600 - IF SAME PARTICLE TYPE IS FOUND ONLY AT ODMS DURING A REPEAT INSPECTION: - REDUCE INSPECTION INTERVAL TO 25/50 HOURS OUTIL PARTICLES ARE FOUND IN AGB OR TGB SCREEN. DO NOT RESET ODMS	REMOVE AND REPLACE AGB OR TGB, RESET ODMS REF AMM TASK 71-00-00-700-802-G00 DO OIL SYSTEM FLUSHING AMM TASK12-13-11-100-801-G00	REMOVE AND REPLACE AGB OR TGB DO OIL SYSTEM FLUSHING AMM TASK12-13-11-100-801-G00
POTENTIAL SOURCE	A/N	N/A	ANY MACHINED OIL-WETTED SURFACE	AGB OR TGB KEY LOCK FROM INSERTS	ALL SUMPS	AGB OR TGB KEY INSERTS THREAD	AGB OR TGB KEY INSERTS THREAD	AGB OR TGB HOUSING THREAD
MATERIAL COMPOSITION FROM LAB ANALYSIS	N/A	N/A	NA	17-4PH	17-4PH	17-4РН	17-4PH	ALUMINIUM
QUANTITY	ANY	3 OR FEWER PARTICLES	ANY	ANY	ANY	ANY	ANY	ANY
DESCRIPTION	<0.004 INCH (0.10 mm) IN LARGEST DIMENSION	<0.010 INCH (0.25 mm) IN LARGEST DIMENSION	MACHINED CHIPS OR SHINY CURLS OF METAL OR THAT HAVE PARALLEL MARKS FROM MACHINE TOOLS AT MAGNIFYING GLASS POWER 10X	FLAT PIECE WITH CASTELLATED PORTION REFER TO FIGURE 606 (SHEET 19)	SHAPE OTHER THAN THOSE DESCRIBES IN FIGURE 606 (SHEET 18)	MACHINED CURLS, ELONGATED CURLS, SLIVER CHUNK REFER TO FIGURE 606 (SHEET 18)	MACHINED CURLS, ELONGATED CURLS, SLIVER CHUNK REFER TO FIGURE 606 (SHEET 18)	MACHINED CURLS, ELONGATED CURLS, SLIVER CHUNK REFER TO FIGURE 606 (SHEET 20)
ЯЭТЯАТС	×							
FILTER	×	×	×					
O	×	×	×					
m r	×	×	×					
A A	×	×	*					
В ТС	×	×		×			×	×
AG	×	×	*	×			×	×
ODWS	×	×	×	× ×	×	×	×	
DITEMBAM	YES	YES	YES	YES	YES	YES	YES	9

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 1 of 23)

SIA ALL

79-00-00

2967729 S0000747145_V3

ICNLEAP1B790000D5882800021A00201

RECOMMENDATION	DO NOT RESET THE CHIP COUNT AND PUT THE ENGINE ON WATCH: I-INSPECT THE ODMS SENSOR AND ALL THE SCAVENGE SCREEN PLUG AND STARTER MCD EVERY DAY OR BEFORE 5 FC MAX FOR 3 TIMES A-IF NO FINDINGS, INSPECT THE ODMS SENSOR AND ALL THE SCAVENGE SCREEN PLUGS AND 3 TIMES J. FN OF FINDINGS, ENGINE IS CLEARED, RESET ODMS REF AMM TASK 79-00-00-220-801-G00 B-IF FINDINGS, FOLLOW AMM TASK 79-00-00-220-801-G00 B-IF FINDINGS, FOLLOW AMM	DO NOT OPERATE THE ENGINE, CONTACT CFM SUPPORT AND PROVIDE MAINTENANCE HISTORY RELATED TO OIL SYSTEM (RECENT EVENT, SHOP VISIT, PART REPLACEMENT) DO NOT RESET ODMS BEFORE REMOVING THE ENGINE OR IN CASE OF ENGINE REMOVAL, FOR INVESTIGATION PURPOSE, DOWNLOAD: DIR 1 AND DIR 3 CHANNELS AND AND B. REFER TO AMM TASK 73-21-05-970-801-G00	DO NOT OPERATE THE ENGINE, CONTACT CFM SUPPORT AND PROVIDE MAINTENANCE HISTORY RELATED TO OIL SYSTEM (RECENT EVENT, SHOP VISIT, PART REPLACEMENT) DO NOT RESET ODMS BEFORE REMOVING THE ENGINE OOR IN CASE OF ENGINE REMOVAL, FOR INVESTIGATION PURPOSE, DOWNLOAD: DIR 1 AND DIR 3 CHANNELS AND AND B. REFER TO AMM TASK 73-21-05-970-801-G00
POTENTIAL SOURCE	ENGINE BEARINGS	ENGINE BEARINGS	ENGINE BEARING CAGES
MATERIAL COMPOSITION FROM LAB ANALYSIS	- M50/E-80DCV40 (RACE/BALL MATERIAL), - M50NIL/E-13DCNV40 (RACE/BALL MATERIAL), - 32CDV13, - 220WC10 NOTE: THE MATERIAL 32CDV13, CAN BE CONFOUNDED WITH M50 OR 40CDV12 WITH SOME LAB ANALYSES	- M50/E-80DCV40 MATERIAL), - M50NIL/E-13DCNV40 (RACE/BALL MATERIAL), - 32CDV13, - 220WC10, - 32CDV13, - 32CDV1	- AISI 4340 /E-40NCD7 (CAGE MATERIAL), NOTE: THE AISI 9315/16NCD13 (GEAR MATERIAL) (GAN BE CON POUNDED WITH AISI4340/E-40NCD7 (CAGE MATERIAL)
QUANTITY	4 OR LESS PARTICLES -0,76MM IN LARGEST DIMENSION	5 OR MORE PARTICLES NONE GREATER THAN 0.03 INCH (0.76 mm) OR ANY SINGLE PARTICLE PARTICLE PARTICLE GREATER THAN 0.03 INCH (0.76	4 OR MORE PARTICLES, NONE GREATER GREATER INCH (0.25 MM) OR ANY SINGLE GREATER THAN 0.020 INCH (0.5 MM)
DESCRIPTION	EVIDENCE OF BEARING DEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.	EVIDENCE OF BEARING DEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.	EVIDENCE OF BEARING DEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.
яэтяатс			
ЯЭТЛІЯ			
С			
4			
TGB			
AGB			
ODMS	×	×	×
MAGNETIC	YES	YES	YES

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 2 of 23)

ICNLEAP1B790000D5882800022A00301 2967753 S0000747147_V4



RECOMMENDATION	DO NOT OPERATE THE ENGINE, CONTACT CFM SUPPORT AND PROVIDE MAINTENANCE HISTORY RELATED TO OIL SYSTEM (RECENT EVENT, SHOP VISIT, PART REPLACEMENT) DO NOT RESET ODMS BEFORE REMOVAL, FOR ENGINE OR IN CASE OF ENGINE REMOVAL, FOR INVESTIGATION PURPOSE, DOWNLOAD: DIR 1 AND DIR 3 CHANNELS A AND B. REFER TO AMM TASK 73-21-05-970-801-G00.	REMOVE AND REPLACE THE AGB, RESET ODMS REF AMM TASK 71-00-00-700-802-G00 DO OIL SYSTEM FLUSHING AMM TASK 12-13-11-100-801-G00	REMOVE AND REPLACE THE TGB, RESET ODMS REF AMM TASK T-00-00-700-802-G00 DO OIL SYSTEM FLUSHING AMM TASK 12-13-11-100-801-G00	REFER TO AMM TASK 80-11-09-200-801-G00. IN CASE OF STARTER REPLACEMENT, DO OIL SYSTEM FLUSHING AMM TASK 12-13-11-100-801-G00
POTENTIAL SOURCE	ENGINE BEARINGS	AGB BEARINGS	TGB BEARINGS	STARTER BEARINGS
MATERIAL COMPOSITION FROM LABANALYSIS	- M50/E-80DCV40 (RACE/BALL MATERIAL), (RACE/BALL MATERIAL), - M50NIL/E-13DCNV40 (RACE/BALL MATERIAL), - A S1 4340/E-40NDC7 (CAGE MATERIAL), - 32CDV13, - 220WC10 (RBD MODIFIED) NOTE: THE MATERIAL 32CDV13 CAN BE CONFOUNDED WITH M50 OR 40CDV12 WITH SOME LAB NOTE: THE AISI 9315/16NCD13 (GEAR MATERIAL) CAN BE CONFOUNDED WITH ASI34340/E-40NCD7 (CAGE MATERIAL) CAGE MATERIAL) CAGE MATERIAL) CAGE MATERIAL) CAGE MATERIAL)	- M50/E-80DCV40 (RACE/BALL MATERIAL), - M50NIL/E-13DCNV40 (RACE/BALL MATERIAL), - AISI 4340 /E-40NDC7 (CAGE MATERIAL), - 22CDV13, - 22CDV13, - 22CWC10 (RAD MODIFIED) NOTE: THE MATERIAL 32CDV13 CAN BE CONFOUNDED WITH M50 CAN BE CONFOUNDED WITH M50 GEAR MATERIAL) CAN BE CONFOUNDED WITH AISI4430/E-40NCD7 (CAGE MATERIAL) CAN BE CONFOUNDED WITH CONFOUND	- M50/E-80DCV40 (RACE/BALL MATERIAL), - M50NIL/E-13DCNV40 (RACE/BALL MATERIAL), - A1SI 4340 /E-40NDC7 - CAGE MATERIAL), - 32CDV13 - 220WC10 (RBD MODIFIED) NOTE: THE MATERIAL 32CDV13 CAN BE CONFOUNDED WITH M50 CAGE MATERIAL) CAN BE CONFOUNDED WITH ASIS 4340/E-40NCO CAGE MATERIAL)	- MSO/E-80DCV40 (RACE/BALL MATERIAL), - ALLOY STEEL 52100/100C6 (RACE/BALL MATERIAL) NOTE: THE MATERIAL) NOTE: THE MATERIAL CAN BE CONFOUNDED WITH M50 OR 40CDV12 WITH SOME LAB ANALYSES.
QUANTITY	4 OR MORE - PARTICLES, (PARTICLES, (PARTICLES, (PARTICLES, (PARTICLE), (PARTIC	4 OR MORE PARTICLES, CREATER THAN 0.010 MM) OR ANY SINGLE PARTICLE	4 OR MORE NOME GREATER THAN 0.010 INCH (0.25 mm) OR ANY SINGLE PARTICLE GREATER THAN 0.020 INCH (0.5 mm)	
DESCRIPTION	EVIDENCE OF BEARING BEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNIETIC FLAKES.	EVIDENCE OF BEARING DEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.	EVIDENCE OF BEARING BEGRADATION: THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.	EVIDENCE OF REF AMM BEARING TASK DEGRADATION: 80-11-09-200 THIN, SHINY, BRIGHT LAMINATED MAGNETIC FLAKES.
ЯЭТЯАТС				×
ЯЭТЛІЯ				
C	×			
A B	×			
ТGВ			×	
AGB		×		
ормѕ	_			
MAGNETIC	YES	YES	YES	YES

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 3 of 23)

ICNLEAP1B790000D5882800042A00301

2967755 S0000747148_V3

79-00-00

SIA ALL





RECOMMENDATION	INSPECT THE AFFECTED SCAVENGE SCREEN IN 50-75 HOURS INTERVALS UNTIL 3 CONSECUTIVE TIMES WITHOUT ANY FINDINGS. IF OTHER MATERIAL THAN SILVER IS FOUND DURING THESE REPEATED INSPECTIONS, FOLLOW AMM TASK 79-00-00-220-801-G00	1. WITHIN 10 CYCLES OR 30 FLIGHT HOURS, WHICHEVER COMES FIRST. DO THE FOLLOWING 2. REVIEW MAINTEMANCE RECORDS FOR RECENT MAINTENANCE ACTIONS OR OPERATIONAL EVENTS THAT COULD ACCOUNT FOR THE SHIFTS NOTED THE SHIFTS NOTED 3. PERFORMA GENERAL VISUAL INSPECTION OF THE ENGINE OIL LEVEL SENSOR AND/OR HARNESS 4. INSPECTITHE A-SUMP SCAVENGE SCREEN (79-21-04-211-801-A) 3. PERFORMA GENERAL VISUAL INSPECTION OF THE ENGINE OIL LEVEL SENSOR AND/OR HARNESS 4. INSPECTITHE A-SUMP SCAVENGE SCREEN (79-21-04-211-801-A) 3. FOU FOUND SILVER PARTICLES IN THE A-SUMP SCAVENGE SCREEN (79-21-04-211-801-A) 3. IN FOU FOUND SILVER PARTICLES IN THE A-SUMP SCAVENGE SCREEN FROM ALL SILVER SCAVENGE SCREEN FROM ALL SILVER AND SILVER PARTICLES IN ANY 5. DO AN ENGINE GROUND RUN DURING 15 MIN (71-00-07-790-804-A) 6. INSPECTITHE A-SUMP SCAVENGE SCREEN FROM ALL SILVER AND AND CLEAN THE A-SUMP SCAVENGE SCREEN FROM ALL SILVER IN (71-00-00-790-804-A) 10. DO A SECOND ENGINE GROUND RUN DURING 15 MIN (71-00-00-790-804-A) 11. INSPECTION (79-21-04-211-801-A) 12. DO A SECOND ENGINE GROUND RUN DURING THE PREVIOUS INSPECTION, REPEAT STEPS 5 TO 11 12. PREFILE SESS PARTICLES THAN DURING THE PREVIOUS INSPECTION, REPEAT STEPS 5 TO 11 13. INSPECTION, REPEAT STEPS 5 TO 11 14. INSPECTION, REPEAT STEPS 5 TO 11 15. IF THERE IS LESS PARTICLES THAN DURING THE PREVIOUS INSPECTION, RETURN INTO SERVICE AND PERFORM A REPETITIVE INSPECTION OF A-SUMP SCAVENGE SCREEN AFTER 2556(7): HENDICATION ON THE COCKPIT DURING LAST FLIGHT STEMES IN SERVICE AS UNPRESIDENCED A LOW OIL LEVEL INDICATION ON THE COCKPIT DURING LAST FLIGHT 50-HENDICATION ON THE COCKPIT DURING LEVEL THE STATLED BELOW: 11. DO THE TERST THAT ARE GIVEN IN THE POWER PLANT TEST REFERENCE TABLE (71-00-00-90-800)	GLUE FROM REMOVE AND REPLACE THE OIL FILTER CARTRIDGE CARTRIDGE
POTENTIAL SOURCE	SILVER COATED PARTS	SILVER COATED PARTS	GLUE FROM OIL FILTER CARTRIDGE
MATERIAL COMPOSITION FROM LAB ANALYSIS	SILVER	SILVER	NON-METALLIC (ORGANIC) FRAGMENTS (WITH OR WITHOUT MINERAL GLASS FIBERS), RICH IN CARBON, OXYGEN, NITROGEN, SILICIUM AND CHLORINE
QUANTITY	ANY	ANY	ANY
DESCRIPTION	CHUNKS, SLIVER, PATELETS	CHUNKS, SLIVER, PATELETS	ELONGATED FRAGMENTS, THIN, BRITTLE, BROWN PARTICLES REFER TO FIGURE 606 (SHEET 22)
STARTER			
O FILTER			×
В			
8 A		×	
TGB	×		
AGB	×		
ODWS			
DITENDAM	ON	0 Z	O _Z

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 4 of 23)

SIA ALL








BEARING SHOULDER WEAR DISTRESS (EXAMPLE)


2900623 S0000692893_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 5 of 23)

SIA ALL








BEARING SPALL DISTRESS (EXAMPLE)

2900647 S0000692894_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 6 of 23)

SIA ALL






- 1 GENERAL CHARACTERISTICS
 - MAGNETIC
 - APPEARANCE
 - METALLIC FLAKESREFLECTIVE POWDER

2900648 S0000692896_V2

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 7 of 23)

SIA ALL





M50 2

GENERAL CHARACTERISTICS


- MAGNETIC
- APPEARANCE
 - METALLIC SMALL FLAKES AND / OR POWDER
 - DULLDARK COLOR

2900658 S0000692899_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 8 of 23)

SIA ALL





BEARING SPELL CHIP 3

3 GENERAL CHARACTERISTICS

- MAGNETIC
- APPEARANCE
 - METALLIC FLAKES - FLATTENED - OVAL
 - RAGGED EDGES COINED

- FLAKES - SMOOTH / REFLECTIVE - OVAL ON ONE SIDE, DULL ON


THE OTHER

2900678 S0000692900_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 9 of 23)

SIA ALL





BEARING CAGE 4

4 GENERAL CHARACTERISTICS


- MAGNETIC OR NON-MAGNETIC
- APPEARANCE
 - METALLIC STRUCTURAL IN SHAPE
 - SHARP EDGES REFLECTIVE
 - SMOOTH SHINY OR DISCOLORED COATING

2900684 S0000692902_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 10 of 23)

SIA ALL





GEARBOX DEBRIS 5



- MAGNETIC
- APPEARANCE
 - METALLIC FLAKES SHARP
 - REFLECTIVE IRREGULAR

2900695 S0000692903_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 11 of 23)


EFFECTIVITY ·

79-00-00

SIA ALL

Page 651 Sep 15/2022





SHOTPEENING MEDIA 6




- MAGNETIC
- APPEARANCE
 - SPHERICAL STEEL SHOTPEEN BALLS

2900697 S0000692908_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 12 of 23)

SIA ALL





MACHINING DEBRIS 7

- GENERAL CHARACTERISTICS
 - MAGNETIC OR NON-MAGNETIC
 - APPEARANCE


 - METALLICREFLECTIVE SOLID
 - IRREGULAR

2900699 S0000692905_V2

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 13 of 23)

- EFFECTIVITY **SIA ALL** D633AM101-SIA





SILVER PLATE 8


- **GENERAL CHARACTERISTICS**
 - NON-MAGNETIC
 - APPEARANCE
 - METALLIC FOIL REFLECTIVE MALLEABLE - IRREGULAR

2900705 S0000692907_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 14 of 23)

- EFFECTIVITY **SIA ALL**





- **GENERAL CHARACTERISTICS**
 - NON-MAGNETIC
 - APPEARANCE
 - NON-METALLIC
 ROUND
 SOLID
 JAGGED EDGES
 USULLY BLACK
 BRITTLE TO HARD - OILY SMELL
- SOLID


2900708 S0000692904_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 15 of 23)

- EFFECTIVITY

SIA ALL





PTFE (TEFLON) SEAL 10

- 10 GENERAL CHARACTERISTICS
 - NON-MAGNETIC
 - APPEARANCE
 - NON-METALLIC
- TAN TO BLACK IN COLOR
- CHUNKS LIGHTWEIGHT FOR SIZE

2900721 S0000692906_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 16 of 23)


EFFECTIVITY

79-00-00

SIA ALL

Page 656 Sep 15/2022





PTFE (TEFLON) SEAL 11

- 11 GENERAL CHARACTERISTICS
 - NON-MAGNETIC
 - APPEARANCE
 - LIGHT-WEIGHT - NON-METALLIC
 - STRIP CURLS LONG, THINFLAT

2900725 S0000692909_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 17 of 23)

- EFFECTIVITY **SIA ALL**





KEY INSERT THREAD MATERIAL 12

- 12 GENERAL CHARACTERISTICS
 - MAGNETIC
 - APPEARANCE
 - METALLIC

 - SHARP EDGES
 MACHINED CURLS
 ELONGATED CURLS
 - SLIVER CHUNK

ICNLEAP1B790000D5882800030A00101

2967723 S0000747155_V1


Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 18 of 23)

- EFFECTIVITY **SIA ALL**

79-00-00

Page 658 Sep 15/2022





KEY LOCK INSERT MATERIAL 13

- 13 GENERAL CHARACTERISTICS
 - MAGNETIC
 - APPEARANCE
 - METALLIC
 - SHARP EDGES
 - FLAT PIECE WITH CASTELLATED PORTION

ICNLEAP1B790000D5882800031A00101


2967714 S0000747157_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 19 of 23)

EFFECTIVITY -

SIA ALL





AGB OR TGB HOUSING THREAD 14

14 GENERAL CHARACTERISTICS

- NON MAGNETIC
- APPEARANCE:
 - METALLIC
 - SHARP EDGES
 - MACHINED CURLS
 - ELONGATED CURLS

- SLIVER CHUNK

ICNLEAP1B790000D5882800032A00201

2967710 S0000747158_V2

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 20 of 23)

- EFFECTIVITY

SIA ALL

79-00-00

Page 660 Sep 15/2023





O-RING 15



• NON-MAGNETIC

15 GENERAL CHARACTERISTICS

- APPEARANCE
 - NON-METALLIC
 - CHUNKS
 - DARK - BLACK
 - SOFT

ICNLEAP1B790000D5882800039A00101

2967708 S0000747159_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 21 of 23)

- EFFECTIVITY SIA ALL







GLUE FROM OIL FILTER CARTRIDGE 16



16 GENERAL CHARACTERISTICS

- NON-MAGNETIC
- APPEARANCE
 - NON-METALLIC
 - ELONGATED FRAGMENTS
 - THIN
 - BRITTLE
 - BROWN PARTICLES

ICNLEAP1B790000D5882800040A00101

2967707 S0000747160_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 22 of 23)

- EFFECTIVITY

79-00-00

SIA ALL

Page 662 Sep 15/2022





LIGHT FUZZ



LIGHT-MODERATE FUZZ



MINOR METAL



MAJOR METAL

STARTER MAGNETIC CHIP DETECTOR FINDINGS 17



17 GENERAL CHARACTERISTICS

- MAGNETIC
- APPEARANCE
 - METALLIC

ICNLEAP1B790000D5882800041A00101

2967702 S0000747161_V1

Disposition and Identification for Magnetic and Non-Magnetic Material Findings Figure 606/79-00-00-990-813-G00 (Sheet 23 of 23)

- EFFECTIVITY

SIA ALL



TASK 79-00-00-211-801-G00

7. Engine Oil System (Fluids (Fuel or Skydrol) and Solids Contamination) Detailed Inspection (Figure 607)

A. General

(1) This task gives the instructions to examine the engine oil system for fluid (fuel or Skydrol) and solid contamination.

B. References

Reference	Title
12-13-11-170-801	Oil Tank Flushing (P/B 301)
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
79-21-01-000-801-G00	Main Fuel/Oil Heat Exchanger Removal (P/B 401)
79-21-01-400-801-G00	Main Fuel/Oil Heat Exchanger Installation (P/B 401)

C. Tools/Equipment

Reference	Description
STD-193	Container
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236
G00034	Cotton Wiper - Process Cleaning Absorbent Wiper (Cheesecloth, Gauze)	AMS3819 Class 1 Grade A or B Form 1 (Supersede BMS15-5 CL A)
G02495 [CP8002]	Wire - Safety, 0.032 Inch (0.8 mm) Diameter	AMS5689

E. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

F. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

G. Prepare for the Inspection

SUBTASK 79-00-00-860-023-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.

SIA ALL



- (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-00-00-010-003-G00

- (2) Do this task: Open the Fan Cowl Panels (Selection), TASK 71-11-04-010-801-G00.
 - (a) On the applicable engine, open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

H. Engine Oil System (Fluids (Fuel or Skydrol) and Solids Contamination) Detailed Inspection

SUBTASK 79-00-00-010-004-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- Drain a small quantity of oil from the oil tank [1]:
 - (a) Put a 1.32 gal (5.00 l) oil resistant container, STD-193 below the oil tank [1].
 - (b) Cut the safety wire [5] from the drain plug [3].
 - (c) Use a clean cotton wiper, G00034 to remove all contamination around the drain plug [3].
 - (d) Remove the drain plug [3] from the oil tube [2].
 - (e) Discard the preformed packing [4].
 - (f) Drain a small quantity of oil into a clean sample bottle.
 - (g) Put a protective cap to stop the drain.
 - (h) Install the drain plug [3] on the oil tube [2]:

SIA ALL



- 1) Make sure that the mating faces are clean and clear of unwanted materials.
- 2) Lubricate the threads of the drain plug [3] with oil, D00599 [CP2442].
- 3) Lubricate the new preformed packing [4] with pure mineral vaseline, D00672 [CP5070].
- 4) Install the new preformed packing [4] in the groove on the drain plug [3].
- 5) Remove the protective cap from the oil tube [2].
- 6) Install the drain plug [3] on the oil tube [2].
- 7) Tighten the drain plug [3] to 177 in-lb (20 N·m) to 204 in-lb (23 N·m).
- 8) Install safety wire, G02495 [CP8002] on the drain plug [3].

SUBTASK 79-00-00-211-003-G00

(2) Examine the oil sample for contamination.

SUBTASK 79-00-00-170-001-G00

- (3) If you find fluid (Skydrol) or solid contamination, do these steps:
 - (a) Flush the oil tank (TASK 12-13-11-170-801).
 - (b) Do the steps again to get the oil sample.
 - (c) If the sample is clear of contamination, return the engine to service.
 - (d) If the sample shows contamination, send the sample for contamination analysis.

SUBTASK 79-00-00-960-002-G00

- (4) If you find fuel in the engine oil, do these steps:
 - (a) Replace the main fuel/oil heat exchanger (TASK 79-21-01-000-801-G00 and TASK 79-21-01-400-801-G00).
 - (b) Flush the oil tank (TASK 12-13-11-170-801).
 - (c) Do the steps again to get the oil sample.
 - (d) If the sample shows contamination, flush the engine oil system again until the engine oil does not show contamination (TASK 12-13-11-170-801).

SUBTASK 79-00-00-610-002-G00

(5) If you did not find any contamination, do this task: Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801.

SUBTASK 79-00-00-100-001-G00

(6) Clean the area and clear all tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-410-003-G00

- (1) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - (a) On the applicable engine, close these access panels:

Name of Landian

<u>number</u>	<u>name/Location</u>
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

SUBTASK 79-00-00-860-024-G00

(2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:

SIA ALL

LEAP-1B ENGINES




737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

- (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
- (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

----- END OF TASK -----

SIA ALL





Engine Oil System Fluids (Fuel or Skydrol) and Solids Contamination Detailed Inspection Figure 607/79-00-00-990-803-G00

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



TASK 79-00-00-200-802-G00

8. Engine Oil System (Wear Metal Contamination) Inspection

(Figure 608)

A. General

(1) This task provides the instructions on how to remove engine oil for the oil system wear metal contamination inspection.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	

E. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

F. Access Panels

Number	Name/Location
414AR	Oil Tank Access / Pressure Relief Door, Engine 1
424AR	Oil Tank Access / Pressure Relief Door, Engine 2

G. Prepare for the Inspection

SUBTASK 79-00-00-860-019-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-00-00-010-005-G00

(2) Open the applicable access panels:

<u>Number</u>	Name/Location
414AR	Oil Tank Access / Pressure Relief Door, Engine 1
424AR	Oil Tank Access / Pressure Relief Door, Engine 2

SIA ALL



H. Engine Oil System (Wear Metal Contamination) Inspection

SUBTASK 79-00-00-010-006-G00



DO NOT TOUCH THE COMPONENTS OF THE OIL SYSTEM IF THE ENGINE IS HOT. THESE COMPONENTS STAY HOTTER THAN OTHER COMPONENTS. HOT COMPONENTS CAN BURN YOU.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Open the oil tank filler cap [2] as follows:
 - (a) Lift the oil tank filler cap handle [3] to the open position.
 - (b) Open the oil tank filler cap [2].

SUBTASK 79-00-00-280-001-G00

- (2) Use an oil sample kit to get an oil sample as follows:
 - (a) Push the siphon tube [5] down into the oil tank [1] until it touches the bottom of the oil strainer.

NOTE: Do not let the siphon tube stay against the bottom of the oil strainer. The siphon tube can become full with unwanted materials that are on the bottom of the oil strainer.

- (b) Move the siphon tube [5] up slightly from the bottom of the strainer.
- (c) Use a siphon procedure to remove a sample of the oil from the oil tank [1].
- (d) Do these steps to get the oil sample with a siphon tube [5] and an attached plastic bottle [6] (Preferred Method):

NOTE: Oil sample kits come with a plastic bottle attached to a siphon tube or a siphon tube without the attached plastic bottle.

- 1) Slowly compress the plastic bottle [6] with your hand to move the air out.
- 2) Slowly release the hand pressure on the plastic bottle [6] to move oil up inside the siphon tube [5] and into plastic bottle [6].
- 3) Remove the plastic bottle [6] and the siphon tube [5] from the oil tank [1].
- 4) Put the end of the siphon tube [5] in the oil sample bottle.
- 5) Slowly move the plastic bottle [6] until all the oil in the siphon tube [5] is in the oil sample bottle.
- 6) Put a cap on the oil sample bottle and tighten the cap to seal the bottle.

SIA ALL



- Discard the plastic bottle [6] and the siphon tube [5].
 - NOTE: Use a new plastic bottle and siphon tube with each oil sample. This will make sure that the oil sample shows the present condition of the oil.
- (e) Do these steps to get the oil sample with a siphon tube [5] without an attached plastic bottle [6] (Alternate Method):

NOTE: Oil sample kits come with a plastic bottle attached to a siphon tube or a siphon tube without the attached plastic bottle.

- 1) Put your thumb over the end of the siphon tube [5].
- 2) Remove the siphon tube [5] from the oil tank [1].
- 3) Put the end of the siphon tube [5] in the oil sample bottle.
- 4) Slowly remove your thumb from the end of the siphon tube [5] until all oil in the siphon tube [5] is in the oil sample bottle.
- 5) Put a cap on the oil sample bottle and tighten it to seal the bottle.
- 6) Discard the siphon tube [5].

NOTE: Use a new siphon tube with each oil sample. This will make sure that the oil sample shows the present condition of the oil.

SUBTASK 79-00-00-970-001-G00

(3) Write the quantity of oil added for the oil consumption check on a oil consumption sheet.

SUBTASK 79-00-00-610-001-G00

(4) If it is necessary, replenish engine oil (Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801).

SUBTASK 79-00-00-970-002-G00

- (5) Make sure that you write the data that follows on the label for oil sample bottle:
 - NOTE: Make sure that you keep a copy of the label information before you send the sample to the laboratory.
 - (a) The airplane registration number
 - (b) The engine S/N
 - (c) The engine position
 - (d) The date of the sample
 - (e) The (type and quantity) of oil that is added.

SUBTASK 79-00-00-910-002-G00

(6) Send the sample to the laboratory as soon as possible to get good results.

SUBTASK 79-00-00-410-004-G00

- (7) Close the oil tank filler cap [2] as follows:
 - (a) Examine the preformed packing [4] for damage.
 -) If you find damage, replace the preformed packing [4] as follows:
 - 1) Remove the preformed packing [4] from the groove of the oil tank filler cap [2].
 - 2) Lubricate a new preformed packing [4] with engine oil, D00599 [CP2442].
 - 3) Install the new preformed packing [4] in the groove of the oil tank filler cap [2].
 - (c) Push the oil tank filler cap handle [3] to the CLOSED position.
 - (d) Make sure that the oil tank filler cap [2] is tightly closed and locked.

SIA ALL



SUBTASK 79-00-00-160-002-G00

(8) Clean the work area and remove the tools you use for the task.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-410-005-G00

(1) Close the applicable access panels:

<u>Number</u>	Name/Location
414AR	Oil Tank Access / Pressure Relief Door, Engine 1
424AR	Oil Tank Access / Pressure Relief Door, Engine 2

- (a) Make sure the latches are fully closed.
 - 1) Press the aft "PUSH CLOSE" button to fully close the latch.
 - 2) If the latch appears to be jammed in the fully open position and does not close, press the forward "PUSH OPEN" button to reset the latch.
 - NOTE: Do not use a prying tool to force the latch closed.
 - 3) Repeat the steps as necessary to fully close the latch.

NOTE: The latch may not close if the aft "PUSH CLOSE" button is released before the latch is fully closed.


SUBTASK 79-00-00-860-020-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

----- END OF TASK -----

SIA ALL 79-00-00






Engine Oil System (Wear Metal Contamination) Inspection Figure 608/79-00-00-990-810-G00 (Sheet 1 of 2)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details






FILLER CAP HANDLE (IN LOCKED POSITION)



FILLER CAP HANDLE (IN UNLOCKED POSITION)



FILLER CAP (OPEN)

2479903 S0000582555_V1

Engine Oil System (Wear Metal Contamination) Inspection Figure 608/79-00-00-990-810-G00 (Sheet 2 of 2)

SIA ALL

79-00-00

Page 674 Sep 15/2022



TASK 79-00-00-200-803-G00

9. ODMS Fault Check

A. General

(1) This task provides the instructions on how to do a message fault check of the Oil Debris Monitoring System (ODMS).

B. References

Reference	Title
46-13-00-480-801	Maintenance Laptop Connection (P/B 201)
46-13-02-700-806	Fault History Check (P/B 201)
73-21-00-800-801-G00	EEC Maintenance Power Selection (P/B 201)
IFIM and do the applicable procedure(s)	Interactive Fault Isolation Manual

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description
SPL-11321	Device - Universal Maintenance (UMD)
	Part #: G45004-3 Supplier: 81205 Part #: G45004-31 Supplier: 81205
	Opt Part #: G45003-3 Supplier: 81205
	Opt Part #: G45004-1 Supplier: 81205

D. Location Zones

Zone	Area
211	Flight Compartment - Left

E. Prepare for the Check

SUBTASK 79-00-00-860-025-G00

- (1) If you use the Multi-Function Display (MFD) to do the fault test, do these steps:
 - (a) Set the applicable EEC MAINT POWER switch on the MISC SYSTEM CTRLS page on the MFD to the TEST position (TASK 73-21-00-800-801-G00).
 - (b) Select the L or C on the MAINTENANCE/BITE PANEL (P61).

SUBTASK 79-00-00-480-001-G00

(2) If you do the test with a Portable Maintenance Device (PMD), do this task: Maintenance Laptop Connection, TASK 46-13-00-480-801.

F. ODMS Fault Check

SUBTASK 79-00-00-280-002-G00

- (1) If you use the MAX Display System (MDS) display, do the fault check as follows:
 - (a) Use the tabber device on the maintenance/BITE panel (P61) and select the ONBD MAINT on the MAX display.
 - (b) Select the FAULT HISTORY from the EXTENDED MAINT menu (TASK 46-13-02-700-806).
 - (c) Do a check for one or more maintenance messages in chapter 71-80 left or right engine in the last three flight legs (LEG 0, LEG-1 and LEG-2).
 - 1) If you see a fault message, do the IFIM and do the applicable procedure(s).

SIA ALL

79-00-00

Page 675 Sep 15/2023



(d) After the check, exit the maintenance menu on the MDS.

SUBTASK 79-00-00-280-003-G00

- (2) If you use a portable universal maintenance device, SPL-11321, do the fault check as follows (TASK 46-13-02-700-806):
 - (a) Select the Onboard Maintenance Function (OMF).
 - (b) From the onboard maintenance menu, select EXTENDED MAINTENANCE.
 - (c) From the extended maintenance menu select FAULT HISTORY for chapter 71-80 left or right engine.
 - (d) Do a check for one or more maintenance messages in the last three flight legs (LEG 0, LEG-1 and LEG-2).
 - 1) If you see a fault message, do the IFIM and do the applicable procedure(s).
 - (e) After the check, exit the maintenance menu on the laptop.

G. Put the Airplane Back to Its Usual Condition

SUBTASK 79-00-00-080-002-G00

(1) If it is necessary, disconnect the Ethernet connection from the Onboard Network System (ONS).

SUBTASK 79-00-00-080-003-G00

(2) If it is necessary, disconnect the portable universal maintenance device, SPL-11321.



TASK 79-00-00-200-804-G00

10. Drain Tubes Inspection and Cleaning

(Figure 609, Figure 610, Figure 611)

A. General

(1) This task gives instructions to examine the drain tubes for the coking condition.

B. References

Reference	Title
73-11-05-000-801-G00	Fuel Nozzle Removal (P/B 401)
73-11-05-400-801-G00	Fuel Nozzle Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Prepare for the Inspection

SUBTASK 79-00-00-210-014-G00

- (1) Do these steps to make sure that the ENGINE START switch and START LEVER switch are not operated:
 - (a) On the P5 overhead panel, make sure the applicable ENGINE START switch is in the OFF position.

SIA ALL



- 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
- (b) On the P10 control stand, make sure that the applicable START LEVER switch is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

F. Drain Tubes Inspection

SUBTASK 79-00-00-200-007-G00

- (1) Criteria for oil coke build-up:
 - (a) The oil coke build-up inside the drain tubes is not acceptable and must be cleaned if at least one section of any length of one tube:
 - 1) is covered 360° by oil coke build-up (brown surface varnish is accepted), or
 - 2) is not circular anymore because of one-sided heavy oil coke build-up.
 - (b) Refer to Figure 610 and Figure 611 for acceptable and non-acceptable conditions.

SUBTASK 79-00-00-211-011-G00

(2) B-sump drain

- (a) Find the B-sump drain port in the core drain mast [1] (View A, Figure 609).
- (b) Put the BSI (Borescope Inspection) equipment into the engine through the B-Sump drain mast port.
 - NOTE: A 4-mm borescope tip is the recommended size to do the BSI procedure. A 6-mm borescope tip is the maximum size that can be used to do the BSI procedure.
- (c) Do a BSI up the B-sump drain through the B-sump external main drain oil tube [2] and B-sump internal main drain oil tube [3] until reaching the B-sump cavity to examine for oil coke build-up, do the following steps (View C, Figure 609):
 - 1) If oil coke build-up is acceptable (defined in F.(1)) in the sections of the B-sump external main drain oil tube [2] and B-sump internal main drain oil tube [3] to the B-sump cavity, the inspection is complete and continued operation is permitted.
 - NOTE: Small oil traces on the Inside Diameter (ID) of the B-sump external main drain oil tube [2] and B-sump internal main drain oil tube [3] are permitted.
 - a) Do the steps in the Put the Airplane Back to Its Usual Condition paragraph.
 - 2) If oil coke build-up is not acceptable (defined in F.(1)) in the sections of the B-sump external main drain oil tube [2] and/or of the B-sump internal main drain oil tube [3] to the B-sump cavity, do the following steps:
 - a) Remove the B-sump external main drain oil tube [2] (TASK 73-11-05-000-801-G00).
 - b) Clean oil coke build-up in the ID of the removed B-sump external main drain oil tube [2] with a nylon tube brush.
 - c) Encase the steel wire elements of the nylon tube brush with rubber or plastic coating to prevent scratching.
 - d) Clean oil coke build-up in the ID of the B-sump internal main drain oil tube [3] with a nylon tube brush. If it is possible, try to remove oil coke build-up out of the B-sump internal main drain oil tube [3] and do not push it in the engine.
 - e) Do a BSI or a visual inspection to make sure that oil coke build-up in the B-sump internal main drain oil tube [3] is acceptable up to the B-sump cavity.
 - NOTE: Small oil traces on the ID of the B-sump internal main drain oil tube [3] are permitted.

SIA ALL



- f) If there is unwanted material found or if coke build-up is still not acceptable, do steps F(2).2).d and F(2).2).e again.
- g) Install the B-sump external main drain oil tube [2] (TASK 73-11-05-400-801-G00).

SUBTASK 79-00-00-211-012-G00

- (3) C-sump drain
 - a) Find the C-Sump drain port in the core drain mast [1] (View A, Figure 609).
 - (b) Put the BSI equipment into the engine through the C-sump drain mast port.
 - NOTE: A 4-mm borescope tip is the recommended size to do the BSI procedure. A 6-mm borescope tip is the maximum size that can be used to do the BSI procedure.
 - (c) Do a BSI up the C-sump drain through the C-sump external main drain oil tube [4] and C-sump internal main drain oil tube [5] until reaching the C-sump cavity to examine for oil coke build-up (View C, Figure 609).
 - 1) If oil coke build-up is acceptable (defined in F.(1)) in the sections of the C-sump external main drain oil tube [4] and C-sump internal main drain oil tube [5] to the C-sump cavity, the inspection is complete and continued operation is permitted.
 - NOTE: Small oil traces on the ID of the C-sump external main drain oil tube [4] and C-sump internal main drain oil tube [5] are permitted.
 - 2) If oil coke build-up is not acceptable (defined in F.(1)) in the sections of the C-sump external main drain oil tube [4] and/or of the C-sump internal main drain oil tube [5] to the C-sump cavity, do the following steps:
 - a) Remove the C-sump external main drain oil tube [4] (TASK 73-11-05-000-801-G00).
 - b) Clean oil coke build-up in the ID of the removed C-sump external main drain oil tube [4] with a nylon tube brush.
 - <1> Encase the steel wire elements of the nylon tube brush with rubber or plastic coating to prevent scratching.
 - c) Clean oil coke build-up in the ID of the C-sump internal main drain oil tube [5] with a nylon tube brush. If it is possible, try to remove oil coke build-up out of the C-sump internal main drain oil tube [5] and do not push it in the engine.
 - d) Do a BSI or a visual inspection to make sure that oil coke build-up in the C-sump internal main drain oil tube [5] is acceptable up to the C-sump cavity.
 - NOTE: Small oil traces on the ID of the C-sump internal main drain oil tube [5] are permitted.
 - e) If there is unwanted material found or if coke build-up is still not acceptable, do steps F(3).2).d and F(3).2).e again.
 - f) Install the C-sump external main drain oil tube [4] (TASK 73-11-05-400-801-G00).

SUBTASK 79-00-00-211-013-G00

- (4) Auxiliary drain
 - (a) Find the Auxiliary drain port in the core drain mast [1] (View A, Figure 609).
 - (b) Put the BSI equipment into the engine through the Auxiliary drain mast port.
 - NOTE: A 4-mm borescope tip is the recommended size to do the BSI procedure. A 6-mm borescope tip is the maximum size that can be used to do the BSI procedure.

SIA ALL



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

- (c) Do a BSI up the Auxiliary drain through the auxiliary external main drain oil tube [6] and auxiliary internal main drain oil tube [7] until reaching the Turbine Center Frame (TCF) cavity to examine for oil coke build-up, do the following steps (View C, Figure 609):
 - 1) If oil coke build-up is acceptable (defined in F.(1)) in the sections of the auxiliary external main drain oil tube [6] and the auxiliary internal main drain oil tube [7] to the TCF cavity, the inspection is complete and continued operation is permitted.
 - NOTE: Small oil traces on the ID of the auxiliary external main drain oil tube [6] and auxiliary internal main drain oil tube [7] are permitted.
 - 2) If oil coke build-up is not acceptable (defined in F.(1)) in the sections of the auxiliary external main drain oil tube [6] and/or of the auxiliary internal main drain oil tube [7] to the TCF cavity, do the following steps:
 - a) Remove the auxiliary external main drain oil tube [6] (TASK 73-11-05-000-801-G00).
 - b) Clean oil coke build-up in the ID of the removed auxiliary external main drain oil tube [6] with a nylon tube brush.
 - <1> Encase the steel wire elements of the nylon tube brush with rubber or plastic coating to prevent scratching.
 - c) Clean oil coke build-up in the ID of the auxiliary internal main drain oil tube [7] with a nylon tube brush. If it is possible, try to remove oil coke build-up out of the auxiliary internal main drain oil tube [7] and do not push it in the engine.
 - d) Do a BSI or a visual inspection to make sure that oil coke build-up in the auxiliary internal main drain oil tube [7] is acceptable up to the TCF cavity.
 - NOTE: Small oil traces on the ID of the auxiliary internal main drain oil tube [7] are permitted.
 - e) If there is unwanted material found or if coke build-up is still not acceptable, do steps F(4).2).d and F(4).2).e again.
 - f) Install the auxiliary external main drain oil tube [6] (TASK 73-11-05-400-801-G00).

G. Put the Airplane Back to Its Usual Condition


SUBTASK 79-00-00-840-001-G00

- (1) Do these steps to remove the DO NOT OPERATE tag, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, from the applicable START LEVER switch.

E	ND	OF	TASK	
---	----	----	-------------	--

SIA ALL






Drain Oil Tubes Inspection Figure 609/79-00-00-990-814-G00 (Sheet 1 of 2)

SIA ALL
D633AM101-SIA

79-00-00

Page 680 Sep 15/2022





Drain Oil Tubes Inspection Figure 609/79-00-00-990-814-G00 (Sheet 2 of 2)

- EFFECTIVITY **SIA ALL** D633AM101-SIA







BROWN SURFACE VARNISH EXAMPLE (ACCEPTABLE CONDITION)

2978275 S0000756503_V1

Brown Surface Varnish Inspection Figure 610/79-00-00-990-815-G00

EFFECTIVITY

79-00-00

SIA ALL

Page 682 Sep 15/2022





ONE-SIDED COKE BUILD-UP EXAMPLE (ACCEPTABLE CONDITION)



ONE-SIDED HEAVY COKE BUILD-UP EXAMPLES (NON-ACCEPTABLE CONDITION)

2978276 S0000756515_V1

One-sided Build-up Inspection Figure 611/79-00-00-990-816-G00

SIA ALL



ENGINE OIL - DDG MAINTENANCE PROCEDURES

1. General

- A. This procedure has the maintenance tasks for the Master Minimum Equipment List (MMEL) maintenance requirements as shown in the Dispatch Deviations Guide (DDG). These tasks prepare the airplane for flight with components that are inoperative.
- B. This procedure also has the tasks that put the airplane back to its usual condition.
- C. This procedure has these tasks:
 - (1) DDG 79-21-01 Engine Oil Debris Monitoring System Inoperative Preparation
 - (2) DDG 79-31-01 Oil Quantity Indicating Systems Inoperative Preparation.

TASK 79-00-00-040-802-G00

2. DDG 79-31-01 Oil Quantity Indicating Systems Inoperative - Preparation

A. General

(1) This task gives the maintenance steps which prepare the airplane for flight with the engine oil quantity indication systems inoperative.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-00-00-800-802-G00	Engine Operation Limits (P/B 201)

C. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

D. Oil Quantity Indicating Systems Inoperative

SUBTASK 79-00-00-612-001-G00

- (1) Before each departure, do the steps that follows:
 - (a) Examine the oil level (TASK 71-00-00-800-802-G00).
 - (b) If necessary, fill the engine oil tank to the recommended capacity (TASK 12-13-11-600-801).
 - 1) Within 30 minutes of the engine shutdown, replenish the engine oil tank again if necessary (TASK 12-13-11-600-801).
 - (c) Visually examine the applicable engine area for the sign of oil leakage.
 - (d) Review engine records and verify that the oil usage is within the engine manufacturer's limits or operator's approved limits (if more restrictive).

SUBTASK 79-00-00-800-001-G00

(2) Do a check of the aircraft flight log to make sure that no faults were recorded which relate to the oil pressure and oil temperature indications and that the indications were within limits shown in Engine Operation Limits, TASK 71-00-00-800-802-G00.

FND	OF 1	TASK	
	\mathbf{v}		

SIA ALL



TASK 79-00-00-040-804-G00

3. DDG 79-21-01 Engine Oil Debris Monitoring System Inoperative - Preparation

A. General

(1) This task gives the maintenance steps which prepare the airplane for flight with the engine Oil Debris Monitoring System (ODMS) inoperative.

B. References

Reference	Title
31-65-00-750-801	Fault Interrogation for a Maintenance Message (P/B 201)
79-00-00-210-804-G00	Oil Debris Monitoring System Sensor Inspection (P/B 601)

C. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

D. Engine Oil Debris Monitoring System Inoperative

SUBTASK 79-00-00-200-002-G00

- (1) Do the following task to make sure that the malfunction is in the applicable engine ODMS:
 - (a) Oil Debris Monitoring System Sensor Inspection, TASK 79-00-00-210-804-G00.
- (2) If the engine oil system inspections show no contaminants, then the malfunction is in the ODMS.
- (3) If it is necessary, extinguish the MAINT light on the P5-1 panel. Do this task: Fault Interrogation for a Maintenance Message, TASK 31-65-00-750-801.

—— END OF TASK ——

SIA ALL 79-00-00



OIL TANK - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil tank removal
 - (2) Oil tank installation.

TASK 79-11-01-000-801-G00

2. Oil Tank Removal

(Figure 401)

A. General

(1) This task gives the instructions on how to remove the oil tank.

B. References

Reference	Title
12-13-11-600-803	Engine Oil Change Servicing (P/B 301)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
79-21-21-000-801-G00	Air Oil Separator Removal (P/B 401)
79-31-01-000-801-G00	Oil Level Sensor Removal (P/B 401)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE
STD-1055	Container - Oil Resistant, 5 Gallon (19 Liter)

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

F. Prepare for the Removal

SUBTASK 79-11-01-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-11-01-010-001-G00

(2) On the applicable engine, open the right fan cowl panel (TASK 71-11-04-010-801-G00).

SIA ALL



(a) Open these access panels:

<u>number</u>	<u>name/Location</u>
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

G. Oil Tank Removal

SUBTASK 79-11-01-680-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Drain the oil tank [1] as follows:
 - (a) Put the oil resistant container (5 gal)(19 Liter), STD-1055 below the oil tank [1].
 - (b) Drain the oil tank [1] (TASK 12-13-11-600-803).

SUBTASK 79-11-01-020-001-G00

(2) Do this task: Air Oil Separator Removal, TASK 79-21-21-000-801-G00.

SUBTASK 79-11-01-010-002-G00

(3) Do this task: Oil Level Sensor Removal, TASK 79-31-01-000-801-G00.

SUBTASK 79-11-01-020-002-G00

- (4) If necessary, disconnect the scupper drain tube [4] from the oil tank [1] as follows:
 - (a) Cut and remove the safety wire [6] from the coupling nut [5] of the scupper drain tube [4].
 - (b) Loosen the coupling nut [5] of the scupper drain tube [4].
 - (c) Disconnect the scupper drain tube [4] from the oil tank [1].
 - (d) Install the protective caps on the openings.

SUBTASK 79-11-01-020-003-G00

(5) Disconnect the oil tube [8] from the oil tank [1] as follows:

NOTE: Be careful. There is approximately 0.13 gal (0.5 liter) of oil remain in the oil tank [1].

SIA ALL



- (a) Remove the four bolts [9] from the oil tube [8].
- (b) Disconnect the oil tube [8] from the oil tank [1].
- (c) Remove and discard the gasket seal [10] from the oil tube [8].
- (d) Install the protective caps on the openings.

SUBTASK 79-11-01-020-004-G00

- (6) Disconnect the drain tube [11] from the oil tank [1] as follows:
 - (a) Loosen the coupling nut [12] of the drain tube [11].
 - (b) Remove the bolt [13] from the clamp [14] that attaches the drain tube [11] to the bracket [15].
 - (c) Remove the bolt [16] from the clamp [17] that attaches the drain tube [11] to the bracket [18].
 - (d) Remove the bolt [19] from the clamp [20] that attaches the drain tube [11] to the bracket [21].
 - (e) Install the protective caps on the openings.

SUBTASK 79-11-01-020-005-G00

SIA ALL


(7) Remove the oil tank [1] from the mounting bracket [23], the mounting bracket [25], and the mounting bracket [27] as follows:

NOTE: It is necessary for two people to do this procedure.

- (a) Remove the two bolts [22] that attach the oil tank [1] to the mounting bracket [23].
- (b) Remove the two bolts [24] that attach the oil tank [1] to the mounting bracket [25].
- (c) Loosen, but do not remove the four bolts [28] that attach the mounting bracket [25] to the engine.
- (d) Remove the four bolts [26] that attach the oil tank [1] to the mounting bracket [27].
- (e) Remove the oil tank [1] from the engine.
- (f) Install the protective covers on the openings.

----- END OF TASK -----






Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 1 of 7)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






Oil Tank Installation
Figure 401/79-11-01-990-801-G00 (Sheet 2 of 7)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181





Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 3 of 7)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-11-01

Page 406 Sep 15/2021





A0003-A-001-01 2355321 S00061517007_V1

Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 4 of 7)


SIA ALL

D633AM101-SIA

79-11-01

Page 407 Sep 15/2021





Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 5 of 7)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-11-01

Page 408 Sep 15/2021






Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 6 of 7)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181

79-11-01

Page 409 Sep 15/2021





ICNLEAP1B791101D5882800007A00101

2872563 S0000678923_V1

Oil Tank Installation Figure 401/79-11-01-990-801-G00 (Sheet 7 of 7)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181



TASK 79-11-01-400-801-G00

3. Oil Tank Installation

(Figure 401)

A. General

- (1) This task provides the instructions on how to install the oil tank.
- (2) You must do the tests that are listed in the power plant test reference table after you install the oil tank.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
79-21-21-400-801-G00	Air Oil Separator Installation (P/B 401)
79-31-01-400-801-G00	Oil Level Sensor Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
D00601 [CP2101]	Vaseline - Graphite Mineral	
G01048	Lockwire - MS20995C32, Corrosion Resistant	NASM20995
	Steel - 0.032 Inch (0.8128 mm) Diameter	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
10	Gasket seal	79-11-01-01-020	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location	
414	Right Fan Cowl, Engine 1	
424	Right Fan Cowl, Engine 2	

H. Oil Tank Installation

SUBTASK 79-11-01-420-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.

SIA ALL

May 15/2023



(WARNING PRECEDES)



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS.
IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(1) Install the oil tank [1] on the mounting bracket [23], mounting bracket [25], and mounting bracket [27] as follows:

NOTE: It is necessary for two people to do this procedure.

- (a) Remove the protective covers from the openings.
- (b) Make sure that the mating faces are clean and clear of unwanted materials.
- (c) Lubricate the threads of the two bolts [22], the two bolts [24], the four bolts [26], and the four bolts [28] with graphite mineral vaseline, D00601 [CP2101].
- (d) Install the oil tank [1] in a correct position on the engine.
- (e) Install the four bolts [26] that attach the oil tank [1] to the mounting bracket [27].
- (f) Secure the four bolts [28] that attach the mounting bracket [25] to the engine.
- (g) Install the two bolts [24] that attach the oil tank [1] to the mounting bracket [25].
- (h) Install the two bolts [22] that attach the oil tank [1] to the mounting bracket [23].

SUBTASK 79-11-01-420-003-G00

- (2) Connect the oil tube [8] to the oil tank [1] as follows:
 - (a) Remove the protective caps from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Lubricate the threads of the four bolts [9] and new gasket seal [10] with graphite mineral vaseline, D00601 [CP2101].
 - (d) Install the new gasket seal [10] and oil tube [8] on the oil tank [1].
 - (e) Install the four bolts [9] that attach the oil tube [8] to the oil tank [1].
 - 1) Tighten the four bolts [9] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-11-01-010-003-G00

(3) Do this task: Air Oil Separator Installation, TASK 79-21-21-400-801-G00.

SUBTASK 79-11-01-420-005-G00

(4) Tighten the bolts [28] to 227 in-lb (25.65 N·m) - 251 in-lb (28.35 N·m).

SIA ALL



SUBTASK 79-11-01-420-006-G00

(5) Tighten the bolts [26] to 133 in-lb (15 N·m) - 186 in-lb (21 N·m).

SUBTASK 79-11-01-420-007-G00

(6) Tighten the bolts [24] to 266 in-lb (30 N·m) - 327 in-lb (37 N·m).

SUBTASK 79-11-01-420-008-G00

(7) Tighten the bolts [22] to 227 in-lb (25.65 N·m) - 251 in-lb (28.35 N·m).

SUBTASK 79-11-01-420-004-G00

- (8) Connect the scupper drain tube [4] to the oil tank [1] as follows:
 - (a) Remove the protective caps from the openings.
 - (b) Lubricate the threads of the nipple [7] with oil, D00599 [CP2442].
 - (c) Engage and tighten the coupling nut [5] to the nipple [7].
 - (d) Tighten the coupling nut [5] to 257.0 in-lb (29.0 N·m) 283.0 in-lb (32.0 N·m).
 - (e) Install MS20995C32 lockwire, G01048, on the coupling nut [5].

SUBTASK 79-11-01-010-004-G00

(9) Do this task: Oil Level Sensor Installation, TASK 79-31-01-400-801-G00.

SUBTASK 79-11-01-420-002-G00

- (10) Connect the drain tube [11] as follows:
 - (a) Remove the protective caps from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Lubricate the threads of the coupling nut [12], bolt [13], bolt [16], and bolt [19] with graphite mineral vaseline, D00601 [CP2101].
 - (d) Engage and tighten the coupling nut [12].
 - (e) Install the bolt [19] and clamp [20] that attach the drain tube [11] to the bracket [21].
 - 1) Tighten the bolt [19] to 78.0 in-lb (8.8 N·m) 82.0 in-lb (9.3 N·m).
 - (f) Install the bolt [16] and clamp [17] that attach the drain tube [11] to the bracket [18].
 - 1) Tighten the bolt [16] to 78.0 in-lb (8.8 N·m) 82.0 in-lb (9.3 N·m).
 - (g) Install the bolt [13] and clamp [14] that attach the drain tube [11] to the bracket [15].
 - 1) Tighten the bolt [13] to 78.0 in-lb (8.8 N·m) 82.0 in-lb (9.3 N·m).

SUBTASK 79-11-01-610-001-G00

(11) Do this task: Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801.

SUBTASK 79-11-01-280-001-G00

(12) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-11-01-410-001-G00

- (1) On the applicable engine, close the right fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

SIA ALL 79-11-01

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

SUBTASK 79-11-01-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Oil Tank Installation Test

SUBTASK 79-11-01-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

——— END OF TASK ———

SIA ALL 79-11-01



OIL TANK FILLER CAP - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil Tank Filler Cap Removal
 - (2) Oil Tank Filler Cap Installation.

TASK 79-11-03-000-801-G00

2. Oil Tank Filler Cap Removal

(Figure 401)

A. General

(1) This task gives the instructions to remove the oil tank filler cap.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

F. Prepare for the Removal

SUBTASK 79-11-03-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-11-03-860-002-G00

(2) Do this task: Open the Fan Cowl Panels (Selection), TASK 71-11-04-010-801-G00.

SIA ALL



(a) On the applicable engine, open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

G. Oil Tank Filler Cap Removal

SUBTASK 79-11-03-020-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the oil tank filler cap [6]:
 - (a) Disconnect the drain tube [7] from the oil tank filler cap [6]:
 - 1) Loosen the coupling nut [8] of the drain tube [7].
 - Disconnect the drain tube [7] from the oil tank filler cap [6].
 - (b) Remove the two bolts [10] that attach the oil tank filler cap [6] to the oil tank service panel [11].
 - (c) Remove the oil tank filler cap [6] from the oil tank service panel [11].


NOTE: Do not remove the adapter assembly.


- (d) Remove and discard the O-ring [12] from the groove of the oil tank filler cap [6].
- (e) Install the protective covers on the drain tube [7], nipple [9], and oil tank filler cap [6] port on the oil tank service panel [11].

	OF T	ACIZ	
		$\Delta > N$	

SIA ALL









A0002-A-001-01 2428716 S0000561637_V2

Oil Tank Filler Cap Installation Figure 401/79-11-03-990-801-G00 (Sheet 1 of 2)

SIA ALL











A0003-A-001-01 2428719 S0000561638_V2

Oil Tank Filler Cap Installation Figure 401/79-11-03-990-801-G00 (Sheet 2 of 2)

SIA ALL
D633AM101-SIA

79-11-03

Page 404 Sep 15/2021



TASK 79-11-03-400-801-G00

3. Oil Tank Filler Cap Installation

(Figure 401)

A. General

- (1) This task gives the instructions to install the oil tank filler cap.
- (2) You must do the tests that are listed in the power plant test reference table after you install the oil tank filler cap.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity	
12	O-rina	79-11-01-01-100	SIA ALL	

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

H. Oil Tank Filler Cap Installation

SUBTASK 79-11-03-420-001-G00

- (1) Install the oil tank filler cap [6]:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the drain tube [7], nipple [9], and oil tank filler cap [6] port on the oil tank service panel [11].
 - (c) Lubricate the threads of the two bolts [10] with oil, D00599 [CP2442].
 - (d) Install the oil tank filler cap [6] in a correct position on the oil tank service panel [11].
 - (e) Install the two bolts [10] that attach the oil tank filler cap [6] to the oil tank service panel [11].
 - (f) Tighten the bolts [10] to 32.0 in-lb (3.6 N·m) to 35.0 in-lb (4.0 N·m).
 - (g) Connect the drain tube [7] to the oil tank filler cap [6]:

SIA ALL



- 1) Lubricate the threads of the nipple [9] with oil, D00599 [CP2442]
- 2) Engage the coupling nut [8] to the nipple [9].
- 3) Tighten the coupling nut [8] to 257.0 in-lb (29.0 N·m) to 283.0 in-lb (32.0 N·m).

SUBTASK 79-11-03-420-002-G00

- (2) Do these steps to install the new O-ring [12]:
 - (a) Lubricate the threads of the new O-ring [12] with oil, D00599 [CP2442].
 - (b) Install the new O-ring [12] onto the grooves of the oil tank filler cap [6].

SUBTASK 79-11-03-160-001-G00

(3) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-11-03-860-003-G00

- (1) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - (a) On the applicable engine, close these access panels:

<u>Number</u>		Name/Location
	413	Left Fan Cowl, Engine 1
	414	Right Fan Cowl, Engine 1
	423	Left Fan Cowl, Engine 2
	424	Right Fan Cowl, Engine 2

SUBTASK 79-11-03-860-004-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Oil Tank Filler Cap Installation Test

SUBTASK 79-11-03-710-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).



SIA ALL 79-11-03



MAIN FUEL/OIL HEAT EXCHANGER - REMOVAL/INSTALLATION

1. General

- A. This procedure provides two tasks:
 - (1) Main fuel/oil heat exchanger removal
 - (2) Main fuel/oil heat exchanger installation.

TASK 79-21-01-000-801-G00

2. Main Fuel/Oil Heat Exchanger Removal

(Figure 401)

A. General

(1) This task gives the instructions to remove the main fuel/oil heat exchanger.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
73-11-12-000-801-G00	Main Fuel/Oil Heat Exchanger Differential Pressure Sensor Removal (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-201	Container - Fuel Resistant, 5 U.SGal (19 I)	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

F. Prepare for the Removal

SUBTASK 79-21-01-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SIA ALL 79-21-01



SUBTASK 79-21-01-860-002-G00

(2) Open the applicable circuit breakers and install safety tags:

F/O Electrical System Panel, P6-3

Row	Col	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2
В	4	C00359	FUEL SPAR VALVE ENG 1

SUBTASK 79-21-01-860-003-G00

(3) For the left engine, open these applicable circuit breakers and install safety tags:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Ε	5	C01320	ENGINE FUEL ENGINE 1 HPSOV CONT
Е	6	C01395	ENGINE FUEL ENGINE 1 HPSOV IND

SUBTASK 79-21-01-860-004-G00

(4) For the right engine, open these applicable circuit breakers and install safety tags:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Е	3	C01321	ENGINE FUEL ENGINE 2 HPSOV CONT
Ε	4	C01396	ENGINE FUEL ENGINE 2 HPSOV IND

SUBTASK 79-21-01-010-001-G00

- (5) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

G. Main Fuel/Oil Heat Exchanger Removal

SUBTASK 79-21-01-030-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

- EFFECTIVITY

79-21-01



(WARNING PRECEDES)




DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the main fuel/oil heat exchanger [1]:
 - (a) Put a 5 U.S.-gal (19 I) fuel resistant container, STD-201 below the main fuel/oil heat exchanger [1].
 - (b) Remove the main fuel/oil heat exchanger DP sensor [2] from the main fuel/oil heat exchanger [1] (TASK 73-11-12-000-801-G00).
 - (c) Disconnect the oil tube [3] from the main fuel/oil heat exchanger [1]:
 - 1) Disconnect the fitting nut [4] from the oil tube [3].
 - 2) Install the protective covers on the openings.
 - (d) Disconnect the oil tube [6] from the main fuel/oil heat exchanger [1]:
 - 1) Remove the four bolts [7] from the oil tube [6].
 - 2) Disconnect the oil tube [6] from the main fuel/oil heat exchanger [1].
 - 3) Remove and discard the gasket [8].
 - 4) Install the protective covers on the openings.
 - (e) Disconnect the oil tube [9] from the main fuel/oil heat exchanger [1]:
 - 1) Remove the four bolts [10] from the oil tube [9].
 - 2) Disconnect the oil tube [9] from the main fuel/oil heat exchanger [1].
 - 3) Remove and discard the gasket [11].
 - 4) Install the protective covers on the openings.
 - (f) Disconnect the fuel tube [12] from the main fuel/oil heat exchanger [1]:
 - 1) Remove the four bolts [13] from the fuel tube [12].
 - 2) Disconnect the fuel tube [12] from the main fuel/oil heat exchanger [1].
 - 3) Remove and discard the gasket [14].
 - 4) Install the protective covers on the openings.
 - (g) Disconnect the fuel tube [15] from the main fuel/oil heat exchanger [1]:
 - 1) Remove the four bolts [16] from the fuel tube [15].
 - 2) Disconnect the fuel tube [15] from the main fuel/oil heat exchanger [1].
 - 3) Remove and discard the gasket [17].
 - 4) Install the protective covers on the openings.
 - 5) Remove the bolt [18] that attaches the clamp [19] to the fuel tube [15].
 - (h) Remove the main fuel/oil heat exchanger [1] from the three mounting brackets [24]:
 - 1) Remove the four bolts [22] and the four washers [23] that attach the main fuel/oil heat exchanger [1] to the three mounting brackets [24].
 - 2) Remove the main fuel/oil heat exchanger [1] from the three mounting brackets [24].
 - 3) Install the protective covers on the openings.

ENID	OF TA	NOV	
		7 > N -	

SIA ALL





ICN-LEAP-1B-792101-B-F0301-A0001-A-001-01 2355334 S00061517045_V3


Main Fuel/Oil Heat Exchanger Installation Figure 401/79-21-01-990-802-G00 (Sheet 1 of 4)

SIA ALL
D633AM101-SIA

79-21-01

Page 404 Sep 15/2021





ICN-LEAP-1B-792101-B-F0301-A0002-A-001-01 2355335 S00061517046_V4

Main Fuel/Oil Heat Exchanger Installation Figure 401/79-21-01-990-802-G00 (Sheet 2 of 4)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-01

Page 405 Sep 15/2021





ICN-LEAP-1B-792101-B-F0301-A0003-A-001-01 2402886 \$0000555519_V3


Main Fuel/Oil Heat Exchanger Installation Figure 401/79-21-01-990-802-G00 (Sheet 3 of 4)

SIA ALL

79-21-01

Page 406 Sep 15/2021





Ε

A0004-A-001-01 2403164 S0000555520_V1

Main Fuel/Oil Heat Exchanger Installation Figure 401/79-21-01-990-802-G00 (Sheet 4 of 4)

SIA ALL

D633AM101-SIA



TASK 79-21-01-400-801-G00

3. Main Fuel/Oil Heat Exchanger Installation

(Figure 401)

A. General

(1) This task gives the instructions to install the main fuel/oil heat exchanger.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
73-11-12-400-801-G00	Main Fuel/Oil Heat Exchanger Differential Pressure Sensor Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
D00601 [CP2101]	Vaseline - Graphite Mineral	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
8	Gasket	79-21-01-01-020	SIA ALL
11	Gasket	79-21-01-01-040	SIAALL
14	Gasket	79-21-01-01-060	SIA ALL
17	Gasket	79-21-01-01-080	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

H. Main Fuel/Oil Heat Exchanger Installation

SUBTASK 79-21-01-420-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

EFFECTIVITY -

SIA ALL



(CAUTION PRECEDES)



DO NOT CAUSE DAMAGE TO THE PREFORMED PACKINGS WHEN YOU INSTALL THE HEAT EXCHANGER. A DAMAGED PACKING CAN CAUSE A LEAK IN THE ENGINE FUEL OR OIL SYSTEMS. THE LEAK CAN CAUSE AN ENGINE SHUTDOWN IN-FLIGHT.

- Install the main fuel/oil heat exchanger [1]:
 - (a) Remove the protective covers from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Install the main fuel/oil heat exchanger [1] on the three mounting brackets [24].
 - 1) Lubricate the threads of the four bolts [22] with engine oil, D00599 [CP2442].
 - 2) Install the four bolts [22] and the four washers [23] on the main fuel/oil heat exchanger [1].
 - 3) Tighten the bolts [22] to 67.45 in-lb (7.6 N·m) 74.35 in-lb (8.4 N·m).
 - (d) Connect the fuel tube [15] to the main fuel/oil heat exchanger [1]:
 - Lubricate the threads of the four bolts [16] with graphite mineral vaseline, D00601 [CP2101].
 - 2) Lubricate the new gasket [17] with engine oil, D00599 [CP2442].
 - 3) Install the gasket [17] and the fuel tube [15] on the main fuel/oil heat exchanger [1].
 - 4) Install the bolts [16] on the fuel tube [15].
 - 5) Tighten the four bolts [16] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - 6) Install the bolt [18] and the clamp [19] that attach the fuel tube [15] to the engine bracket.
 - 7) Tighten the bolt [20] and bolt [18] to 42.04 in-lb (4.75 N·m) 46.47 in-lb (5.25 N·m).
 - (e) Connect the fuel tube [12] to the main fuel/oil heat exchanger [1]:
 - Lubricate the threads of the four bolts [13] with graphite mineral vaseline, D00601 [CP2101].
 - 2) Lubricate the new gasket [14] with engine oil, D00599 [CP2442].
 - 3) Install the gasket [14] and the fuel tube [12] on the main fuel/oil heat exchanger [1].
 - 4) Install the four bolts [13] on the fuel tube [12].
 - 5) Tighten the four bolts [13] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - (f) Connect the oil tube [9] to the main fuel/oil heat exchanger [1]:
 - Lubricate the threads of the four bolts [10] with graphite mineral vaseline, D00601 [CP2101].
 - Lubricate the new gasket [11] with engine oil, D00599 [CP2442].
 - 3) Install the new gasket [11] and the oil tube [9] on the main fuel/oil heat exchanger [1].
 - Install the four bolts [10] on the oil tube [9].
 - 5) Tighten the four bolts [10] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - (g) Connect the oil tube [6] to the main fuel/oil heat exchanger [1]:
 - 1) Lubricate the threads of the four bolts [7] with graphite mineral vaseline, D00601 [CP2101].

SIA ALL



- Lubricate the new gasket [8] with engine oil, D00599 [CP2442].
- 3) Install the new gasket [8] and the oil tube [6] on the main fuel/oil heat exchanger [1].
- 4) Install the four bolts [7] on the oil tube [6].
- 5) Tighten the four bolts [7] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
- (h) Connect the oil tube [3] to the main fuel/oil heat exchanger [1]:
 - 1) Lubricate the threads of the fitting nut [4] with engine oil, D00599 [CP2442].
 - 2) Install the fitting nut [4] on the bolt [7].
 - 3) Tighten the fitting nut [4] to 266 in-lb (30 N·m) 310 in-lb (35 N·m).
- (i) Do this task: Main Fuel/Oil Heat Exchanger Differential Pressure Sensor Installation, TASK 73-11-12-400-801-G00.
- (j) Clean the work area and clear the tools you used to do the task.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-01-860-005-G00

- (1) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SUBTASK 79-21-01-860-006-G00

(2) Remove the safety tags and close the applicable circuit breakers:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2
В	4	C00359	FUEL SPAR VALVE ENG 1

SUBTASK 79-21-01-860-007-G00

(3) For the left engine, remove the safety tags and close these applicable circuit breakers:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Ε	5	C01320	ENGINE FUEL ENGINE 1 HPSOV CONT
Ε	6	C01395	ENGINE FUEL ENGINE 1 HPSOV IND

SUBTASK 79-21-01-860-008-G00

(4) For the right engine, remove the safety tags and close these applicable circuit breakers:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Ε	3	C01321	ENGINE FUEL ENGINE 2 HPSOV CONT
Ε	4	C01396	ENGINE FUEL ENGINE 2 HPSOV IND

SUBTASK 79-21-01-410-001-G00

(5) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).

SIA ALL

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

(a) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

J. Main Fuel/Oil Heat Exchanger Installation Test

SUBTASK 79-21-01-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

——— END OF TASK ———

SIA ALL



ENGINE SURFACE AIR COOLING OIL COOLER - REMOVAL/INSTALLATION

1. General

- A. This procedure has four tasks:
 - (1) Engine Surface Air Cooling Oil Cooler 1 Removal
 - (2) Engine Surface Air Cooling Oil Cooler 1 Installation
 - (3) Engine Surface Air Cooling Oil Cooler 2 Removal
 - (4) Engine Surface Air Cooling Oil Cooler 2 Installation.

TASK 79-21-02-000-801-G00

2. Engine Surface Air Cooling Oil Cooler 1 Removal

(Figure 401)

A. General

This task gives the instructions to remove the engine Surface Air Cooled Oil Cooler (SACOC)
 1.

B. References

Reference	Title
12-13-11-600-803	Engine Oil Change Servicing (P/B 301)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

F. Prepare for the Removal

SUBTASK 79-21-02-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.

SIA ALL



- (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-02-010-001-G00

(2) Do these tasks in sequence to safely open the left thrust reverser on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left fan cowl panel (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left thrust reverser (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

G. Engine Surface Air Cooling Oil Cooler 1 Removal

SUBTASK 79-21-02-030-001-G00



DO NOT TOUCH THE COMPONENTS OF THE OIL SYSTEM IF THE ENGINE IS HOT. THESE COMPONENTS STAY HOTTER THAN OTHER COMPONENTS. HOT COMPONENTS CAN BURN YOU.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL 79-21-02



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE, OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE AREAS THAT OIL FALLS ON. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

(1) Drain the engine oil system (TASK 12-13-11-600-803).

SUBTASK 79-21-02-020-001-G00

- (2) Disconnect the oil tube [6] from the engine SACOC 1 [1] as follows:
 - (a) Loosen the coupling nut [5] that attaches the oil tube [6] to the engine SACOC 1 [1].
 - (b) Disconnect the oil tube [6] from the engine SACOC 1 [1].

SUBTASK 79-21-02-020-002-G00

- (3) Disconnect the oil tube [7] from the engine SACOC 1 [1] as follows:
 - (a) Loosen the coupling nut [8] that attaches the oil tube [7] to the engine SACOC 1 [1].
 - (b) Disconnect the oil tube [7] from the engine SACOC 1 [1].

SUBTASK 79-21-02-480-002-G00

- (4) Install protective covers on the oil tube [6], oil tube [7], and ports on the engine SACOC 1 [1]. SUBTASK 79-21-02-020-003-G00
- (5) Remove the engine SACOC 1 [1] as follows:

SIA ALL: PRE LEAP-1B SERVICE BULLETIN 72-0181

(a) Remove the 14 bolts with plates [9] that attach the engine SACOC 1 [1] to the engine.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

(b) Remove the 14 bolts with integrated washers [9] that attach the engine SACOC 1 [1] to the engine.


SIA ALL

- (c) Remove the two bolts with integrated washers [4] that attach the engine SACOC 1 [1] to the engine.
- (d) Remove the two screws [13] and attachment clamp [14] that attach the engine SACOC 1 [1] to the bracket [27].
- (e) Remove the two screws [12] and attachment clamp [11] that attach the engine SACOC 1 [1] to the bracket [10].
- (f) Remove the engine SACOC 1 [1] from the engine.

 END	OF TA	ASK -	

SIA ALL 79-21-02






Engine Surface Air Cooling Oil Cooler 1 Installation Figure 401/79-21-02-990-802-G00 (Sheet 1 of 5)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






Engine Surface Air Cooling Oil Cooler 1 Installation Figure 401/79-21-02-990-802-G00 (Sheet 2 of 5)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181






ICNLEAP1B792102D5882800002A00101 2355339 S00061517054_V5

Engine Surface Air Cooling Oil Cooler 1 Installation Figure 401/79-21-02-990-802-G00 (Sheet 3 of 5)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






ICNLEAP1B792102D5882800011A00101 2841248 S0000663124_V1

Engine Surface Air Cooling Oil Cooler 1 Installation Figure 401/79-21-02-990-802-G00 (Sheet 4 of 5)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181





ICNLEAP1B792102D5882800003A00201 2355340 S00061517055_V6

Engine Surface Air Cooling Oil Cooler 1 Installation Figure 401/79-21-02-990-802-G00 (Sheet 5 of 5)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-02

Page 408 Sep 15/2022






ICNLEAP1B792102D5882800014A00101 2946276 S0000723171_V2

Bolt Tightening Sequence Figure 402/79-21-02-990-806-G00 (Sheet 1 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






Bolt Tightening Sequence Figure 402/79-21-02-990-806-G00 (Sheet 2 of 3)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

79-21-02

Page 410 Sep 15/2022









NOTE:

NUMBERS FROM 3 AND 4 ARE THESE OF THE TORQUING SEQUENCE.

ICNLEAP1B792102D5882800015A00101 2946282 S0000723172_V1

Bolt Tightening Sequence Figure 402/79-21-02-990-806-G00 (Sheet 3 of 3)

EFFECTIVITY
SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-02

Page 411 Sep 15/2022



TASK 79-21-02-400-801-G00

3. Engine Surface Air Cooling Oil Cooler 1 Installation

(Figure 401 and Figure 402)

A. General

(1) This task gives the instructions to install the engine Surface Air Cooled Oil Cooler (SACOC) 1.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
A50474 [CP2256]	Locking Agent - Liquid	
D00599 [CP2442]	Oil - Engine	
D00601 [CP2101]	Vaseline - Graphite Mineral	

E. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

F. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

G. Engine Surface Air Cooling Oil Cooler 1 Installation

SUBTASK 79-21-02-420-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE, OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE AREAS THAT OIL FALLS ON. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

- (1) Install the engine SACOC 1 [1]:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.

SIA ALL





MAKE SURE THAT YOU CORRECTLY ALIGN THE LUG OF THE BRACKET WITH THE NOTCH OF THE ENGINE SURFACE AIR COOLED OIL COOLER (SACOC) 1. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE SACOC 1 CAN OCCUR.

- (b) Install the engine SACOC 1 [1] on the engine.
- (c) Remove the protective covers from the engine SACOC 1 [1], oil tube [6], and oil tube [7].

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181

(d) Lubricate the threads of the 14 bolts with plates [9] and two bolts with integrated washers [4] with graphite mineral vaseline, D00601 [CP2101].

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

(e) Lubricate the threads of the 14 bolts with integrated washers [9] and two bolts with integrated washers [4] with graphite mineral vaseline, D00601 [CP2101].

SIA ALL

- (f) Put the bracket [10] and engine SACOC 1 [1] in position at the same time.
 - 1) Slide the bracket [10] between the engine SACOC 1 [1] and fan case.
 - 2) Make sure that the assembly direction is correct.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181



BE CAREFUL WHEN YOU INSTALL THE BOLTS ON THE AIR/OIL EXCHANGER. IF YOU DO NOT OBEY, DAMAGE TO THE LIP SEAL OF THE AIR/OIL EX-CHANGER CAN OCCUR.

(g) Install the 14 bolts with plates [9] and two bolts with integrated washers [4] that attach the engine SACOC 1 [1] to the engine.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181



BE CAREFUL WHEN YOU INSTALL THE BOLTS ON THE AIR/OIL EXCHANGER. IF YOU DO NOT OBEY, DAMAGE TO THE LIP SEAL OF THE AIR/OIL EX-CHANGER CAN OCCUR.

(h) Install the 14 bolts with integrated washers [9] and two bolts with integrated washers [4] that attach the engine SACOC 1 [1] to the engine.

SIA ALL

(i) Remove the covers.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181

- (j) Tighten the bolts with plates [9] from the top to the bottom, following the sequence 1 to 16 then re-tighten the bolts with plates [9] a second time following the same sequence order as follows (Figure 402):
 - 1) Tighten the two bolts with plates [9], following the specific sequence (start by 1 and finish by 2), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 2) Tighten the two bolts with integrated washers [4], following the specific sequence (start by 3 and finish by 4), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).

SIA ALL 79-21-02



SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181 (Continued)

- 3) Tighten the 12 remaining bolts with plates [9], from the top to the bottom following the specific sequence (start by 5 until 16), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
- 4) Tighten the bolts with plates [9] and bolts with integrated washers [4] again in accordance with the requested torque value, follow the sequence order from the top to the bottom.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

- (k) Tighten the bolts with integrated washers [9] from the top to the bottom, following the sequence 1 to 16 then re-tighten the bolts with plates [9] a second time following the same sequence order as follows (Figure 402):
 - 1) Tighten the two bolts with integrated washers [9], following the specific sequence (start by 1 and finish by 2), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 2) Tighten the two bolts with integrated washers [4], following the specific sequence (start by 3 and finish by 4), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 3) Tighten the 12 remaining bolts with integrated washers [9], from the top to the bottom following the specific sequence (start by 5 until 16), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 4) Tighten the bolts with integrated washers [9] and bolts with integrated washers [4] again in accordance with the requested torque value, follow the sequence order from the top to the bottom.

SIA ALL

- (I) Install the attachment clamp [14] and attachment clamp [11] to secure the engine SACOC 1 [1] as follows:
 - 1) Apply Loctite 241, A50474 [CP2256], on the threads and under the head of the two screws [12].
 - 2) Lubricate the threads of the two screws [13] with graphite mineral vaseline, D00601 [CP2101].
 - 3) Install the attachment clamp [14] and two screws [13] that attach the engine SACOC 1 [1] to the bracket [27].
 - 4) Install the attachment clamp [11] and two screws [12] that attach the engine SACOC 1 [1] to the bracket [10].
 - 5) Tighten the two screws [12] to 84.1 in-lb (9.5 N·m) 92.9 in-lb (10.5 N·m).
 - 6) Tighten the two screws [13] to 84.1 in-lb (9.5 N·m) 92.9 in-lb (10.5 N·m).
- (m) Connect the oil tube [7] to the engine SACOC 1 [1] as follows:
 - 1) Lubricate the threads of the coupling nut [8] with oil, D00599 [CP2442].
 - 2) Connect the oil tube [7] with the coupling nut [8] to the engine SACOC 1 [1].
 - 3) Tighten the coupling nut [8] to 443 in-lb (50 N·m) 531 in-lb (60 N·m).
- (n) Connect the oil tube [6] to the engine SACOC 1 [1] as follows:
 - 1) Lubricate the threads of the coupling nut [5] with oil, D00599 [CP2442].
 - 2) Connect the oil tube [6] with the coupling nut [5] to the engine SACOC 1 [1].
 - 3) Tighten the coupling nut [5] to 443 in-lb (50 N·m) 531 in-lb (60 N·m).
- (o) Clean the work area and clear the tools used to do the procedure.

SIA ALL



H. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-02-600-001-G00

(1) Do this task: Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801.

SUBTASK 79-21-02-410-001-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (2) Do these tasks in sequence to safely close the left thrust reverser:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

- (b) Close the applicable left Fan Cowl Panel (TASK 71-11-04-410-801-G00).
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

SUBTASK 79-21-02-860-002-G00

- (3) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.
- I. Engine Surface Air Cooling Oil Cooler 1 Installation Test

SUBTASK 79-21-02-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

------ END OF TASK ------

TASK 79-21-02-000-802-G00

4. Engine Surface Air Cooling Oil Cooler 2 Removal

(Figure 403)

- A. General
 - This task gives the instructions to remove the engine Surface Air Cooled Oil Cooler (SACOC)
 2.
- B. References

Reference	Title
12-13-11-600-803	Engine Oil Change Servicing (P/B 301)

SIA ALL



(Continued)

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
416	Right Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2
426	Right Thrust Reverser, Engine 2

F. Prepare for the Removal

SUBTASK 79-21-02-860-003-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-02-010-002-G00

(2) Do these tasks in sequence to safely open the right thrust reverser on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

(a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.

SIA ALL 79-21-02





IF FAN COWLS ARE INSTALLED, MAKE SURE THAT LEFT AND RIGHT FAN COWLS ARE IN THE FULL OPEN POSITION. MAKE SURE THAT THE SPRING DOOR OPENING-SYSTEM (SDOS) AND HOLD OPEN RODS (HOR) ARE LOCKED IN THEIR POSITION. IF YOU DO NOT, STRUCTURAL DAMAGE TO THE FAN COWL AND THRUST REVERSER CAN OCCUR.

(b) Open both fan cowl panels (TASK 71-11-04-010-801-G00).

NOTE: Because the center line of the thrust reversers is off 6:00 o'clock position, both fan cowl panels must be opened to prevent damaging the fan cowl panel if either thrust reverser needs to be opened.

1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable right thrust reverser (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
416	Right Thrust Reverser, Engine 1
426	Right Thrust Reverser, Engine 2

G. Engine Surface Air Cooling Oil Cooler 2 Removal

SUBTASK 79-21-02-680-001-G00



DO NOT TOUCH THE COMPONENTS OF THE OIL SYSTEM IF THE ENGINE IS HOT. THESE COMPONENTS STAY HOTTER THAN OTHER COMPONENTS. HOT COMPONENTS CAN BURN YOU.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE, OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE AREAS THAT OIL FALLS ON. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

Drain the engine oil system (TASK 12-13-11-600-803).

SUBTASK 79-21-02-010-003-G00

- (2) Disconnect the oil tube [17] from the engine SACOC 2 [2] as follows:
 - (a) Loosen the coupling nut [16] that attaches the oil tube [17] to the engine SACOC 2 [2].
 - (b) Disconnect the oil tube [17] from the engine SACOC 2 [2].

SUBTASK 79-21-02-010-004-G00

- (3) Disconnect the oil tube [18] from the engine SACOC 2 [2] as follows:
 - (a) Loosen the coupling nut [19] that attaches the oil tube [18] to the engine SACOC 2 [2].
 - (b) Disconnect the oil tube [18] from the engine SACOC 2 [2].

SUBTASK 79-21-02-480-001-G00

(4) Install the protective covers on the oil tube [17], oil tube [18], and engine SACOC 2 [2].

SUBTASK 79-21-02-020-004-G00

(5) Remove the engine SACOC 2 [2] as follows:

SIA ALL: PRE LEAP-1B SERVICE BULLETIN 72-0181

(a) Remove the 14 bolts with plates [20] that attach the engine SACOC 2 [2] to the engine.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181


(b) Remove the 14 bolts with integrated washers [20] that attach the engine SACOC 2 [2] to the engine.

SIA ALL

- (c) Remove the two bolts with integrated washers [15] that attach the engine SACOC 2 [2] to the engine.
- (d) Remove the two screws [23] and attachment clamp [22] that attach the engine SACOC 2 [2] to the bracket [21].
- (e) Remove the two screws [24] and attachment clamp [25] that attach the engine SACOC 2 [2] to the bracket [26].
- (f) Remove the engine SACOC 2 [2] from the engine.

	חו	OF	TA	C L	
	\mathbf{v}	V)		JIV.	






Engine Surface Air Cooling Oil Cooler 2 Installation Figure 403/79-21-02-990-804-G00 (Sheet 1 of 5)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






Engine Surface Air Cooling Oil Cooler 2 Installation Figure 403/79-21-02-990-804-G00 (Sheet 2 of 5)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181






ICNLEAP1B792102D5882800005A00101 2422245 S0000556951_V5

Engine Surface Air Cooling Oil Cooler 2 Installation Figure 403/79-21-02-990-804-G00 (Sheet 3 of 5)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






ICNLEAP1B792102D5882800013A00101 2841260 S0000663128_V1

Engine Surface Air Cooling Oil Cooler 2 Installation Figure 403/79-21-02-990-804-G00 (Sheet 4 of 5)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181





ICNLEAP1B792102D5882800006A00201 2422391 S0000556952_V6


Engine Surface Air Cooling Oil Cooler 2 Installation Figure 403/79-21-02-990-804-G00 (Sheet 5 of 5)

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details






Bolt Tightening Sequence Figure 404/79-21-02-990-807-G00 (Sheet 1 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181






ICNLEAP1B792102D5882800016A00101 2946454 S0000723173_V2

Bolt Tightening Sequence Figure 404/79-21-02-990-807-G00 (Sheet 2 of 3)

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181









NOTE:

NUMBERS FROM 3 AND 4 ARE THESE OF THE TORQUING SEQUENCE.

ICNLEAP1B792102D5882800017A00101

2946456 S0000723174_V1

Bolt Tightening Sequence Figure 404/79-21-02-990-807-G00 (Sheet 3 of 3)

ECCN 9E991 BOEING PROPRIETARY - See title page for details

SIA ALL

D633AM101-SIA

79-21-02

Page 426 Sep 15/2022



TASK 79-21-02-400-802-G00

5. Engine Surface Air Cooling Oil Cooler 2 Installation

(Figure 403 and Figure 404)

A. General

(1) This task gives the instructions to install the engine Surface Air Cooled Oil Cooler (SACOC) 2.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
A50474 [CP2256]	Locking Agent - Liquid	
D00599 [CP2442]	Oil - Engine	
D00601 [CP2101]	Vaseline - Graphite Mineral	

E. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

F. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
416	Right Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2
426	Right Thrust Reverser, Engine 2

G. Engine Surface Air Cooling Oil Cooler 2 Installation

SUBTASK 79-21-02-420-002-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE, OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE AREAS THAT OIL FALLS ON. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

- (1) Install the engine SACOC 2 [2]:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.

SIA ALL



SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181

(b) Lubricate the threads of the 14 bolts with plates [20] and two bolts with integrated washers [15] with graphite mineral vaseline, D00601 [CP2101].

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

(c) Lubricate the threads of the 14 bolts with integrated washers [20] and two bolts with integrated washers [15] with graphite mineral vaseline, D00601 [CP2101].

SIA ALL



MAKE SURE THAT YOU ALIGN THE LUG OF THE BRACKET CORRECTLY WITH THE NOTCH OF THE ENGINE SURFACE AIR COOLED OIL COOLER (SACOC) 2. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE SACOC 2 CAN OCCUR.

- (d) Install the engine SACOC 2 [2] on the engine.
- (e) Remove the protective covers from the engine SACOC 2 [2], oil tube [17], and oil tube [18].
- (f) Put the engine SACOC 2 [2] and bracket [21] in position at the same time.
 - 1) Slide the bracket [21] between the engine SACOC 2 [2] and the fan case.
 - 2) Make sure that the assembly direction is correct.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181



BE CAREFUL WHEN YOU INSTALL THE BOLTS ON THE AIR/OIL EXCHANGER. IF YOU DO NOT OBEY, DAMAGE TO THE LIP SEAL OF THE AIR/OIL EX-CHANGER CAN OCCUR.

(g) Install the 14 bolts with plates [20] and two bolts with integrated washers [15] that attach the engine SACOC 2 [2] to the engine.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181



BE CAREFUL WHEN YOU INSTALL THE BOLTS ON THE AIR/OIL EXCHANGER. IF YOU DO NOT OBEY, DAMAGE TO THE LIP SEAL OF THE AIR/OIL EX-CHANGER CAN OCCUR.

(h) Install the 14 bolts with integrated washers [20] and two bolts with integrated washers [15] that attach the engine SACOC 2 [2] to the engine.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181

- (i) Tighten the bolts with plates [20] from the top to the bottom, following the sequence 1 to 16 then re-tighten the bolts with plates [20] a second time following the same sequence order as follows (Figure 404):
 - 1) Tighten the two bolts with plates [20], following the specific sequence (start by 1 and finish by 2), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 2) Tighten the two bolts with integrated washers [15], following the specific sequence (start by 3 and finish by 4), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 3) Tighten the 12 remaining bolts with plates [20], from the top to the bottom following the specific sequence (start by 5 until 16), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).



SIA ALL; PRE LEAP-1B SERVICE BULLETIN 72-0181 (Continued)

4) Tighten the bolts with plates [20] and two bolts with integrated washers [15] again in accordance with the requested torque value, follow the sequence order from the top to the bottom.

SIA ALL; POST LEAP-1B SERVICE BULLETIN 72-0181

- (j) Tighten the bolts with integrated washers [20] from the top to the bottom, following the sequence 1 to 16 then re-tighten the bolts with plates [20] a second time following the same sequence order as follows (Figure 404):
 - 1) Tighten the two bolts with integrated washers [20], following the specific sequence nj,nj(start by 1 and finish by 2), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 2) Tighten the two bolts with integrated washers [15], following the specific sequence (start by 3 and finish by 4), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 3) Tighten the 12 remaining bolts with integrated washers [20], from the top to the bottom following the specific sequence (start by 5 until 16), to 110.6 in-lb (12.5 N·m) 119.5 in-lb (13.5 N·m).
 - 4) Tighten the bolts with integrated washers [20] and two bolts with integrated washers [15] again in accordance with the requested torque value, follow the sequence order from the top to the bottom.

SIA ALL

- (k) Install the attachment clamp [22] and attachment clamp [25] to secure the engine SACOC 2 [2] as follows:
 - Apply Loctite 241, A50474 [CP2256], on the threads and under the head of the two screws [23].
 - Lubricate the threads of the two screws [24] with graphite mineral vaseline, D00601 [CP2101].
 - 3) Install the attachment clamp [22] and two screws [23] that attach the engine SACOC 2 [2] to the bracket [21].
 - 4) Install the attachment clamp [25] and two screws [24] that attach the engine SACOC 2 [2] to the bracket [26].
 - 5) Tighten the two screws [23] to 84.1 in-lb (9.5 N·m) 92.9 in-lb (10.5 N·m).
 - 6) Tighten the screws [24] to 84.1 in-lb (9.5 N·m) 92.9 in-lb (10.5 N·m).
- (I) Connect the oil tube [18] to the engine SACOC 2 [2] as follows:
 - 1) Lubricate the threads of the coupling nut [19] with oil, D00599 [CP2442].
 - 2) Connect the oil tube [18] with the coupling nut [19] to the engine SACOC 2 [2].
 - 3) Tighten the coupling nut [19] to 442.5 in-lb (50 N·m) 531 in-lb (60 N·m).
- (m) Connect the oil tube [17] to the engine SACOC 2 [2] as follows:
 - 1) Lubricate the threads of the coupling nut [16] with oil, D00599 [CP2442].
 - 2) Connect the oil tube [17] with the coupling nut [16] to the engine SACOC 2 [2].
 - 3) Tighten the coupling nut [16] to 442.5 in-lb (50 N·m) 531 in-lb (60 N·m).
- (n) Clean the work area and clear the tools used to do the task.

SIA ALL



H. Put the Airplane Back to its Usual Condition

SUBTASK 79-21-02-410-002-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the right thrust reverser:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	<u>Name/Location</u>
416	Right Thrust Reverser, Engine 1
426	Right Thrust Reverser, Engine 2

- (b) Close the fan cowl panels (TASK 71-11-04-410-801-G00).
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

SUBTASK 79-21-02-860-004-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.
- I. Engine Surface Air Cooling Oil Cooler 2 Installation Test

SUBTASK 79-21-02-730-002-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

	\cap E	TASK	
	V)F	IASN	



ENGINE SURFACE AIR COOLING OIL COOLER - INSPECTION/CHECK

1. General

- A. This procedure has one task:
 - (1) Engine Surface Air Cooling Oil Cooler Inspection.

TASK 79-21-02-211-801-G00

2. Engine Surface Air Cooling Oil Cooler Inspection

(Figure 601)

A. General

(1) This task gives the instructions to do the inspection of the engine Surface Air Cooling Oil Cooler (SACOC).

B. References

Reference	Title
71-00-00-800-802-G00	Engine Operation Limits (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)
79-21-02 P/B 401	ENGINE SURFACE AIR COOLING OIL COOLER - REMOVAL/INSTALLATION
79-21-02-000-801-G00	Engine Surface Air Cooling Oil Cooler 1 Removal (P/B 401)
79-21-02-000-802-G00	Engine Surface Air Cooling Oil Cooler 2 Removal (P/B 401)
79-21-02-400-801-G00	Engine Surface Air Cooling Oil Cooler 1 Installation (P/B 401)
79-21-02-400-802-G00	Engine Surface Air Cooling Oil Cooler 2 Installation (P/B 401)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description
COM-21826	Fine India Oil Stone
	Part #: FF724 Supplier: 44197
STD-858	Tag - DO NOT OPERATE
STD-1081	Flashlight - Explosion Proof
STD-3907	Mirror - Dental
STD-21746	Set - Carbide Bur

D. Consumable Materials

Reference	Description	Specification
G51791	Cloth - Abrasive, Silicon Carbide, 500 Grit	



E. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

F. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

G. Prepare for the Inspection

SUBTASK 79-21-02-860-005-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-02-010-006-G00

(2) Do these tasks in sequence to safely open the left and right thrust reversers on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left or right fan cowl panels (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2





OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- Open the applicable left or right thrust reversers (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

H. Engine Surface Air Cooling Oil Cooler Inspection

SUBTASK 79-21-02-211-003-G00

- (1) Use the explosion proof flashlight, STD-1081, to shine the light at the forward face of the heat exchanger, and look for these conditions:
 - (a) Make sure that no bird debris is present before you continue (TASK 71-00-00-800-802-G00).
 - (b) Debris in the heat exchanger fins.
 - NOTE: The most likely area of damage is the forward facing surface of the heat exchanger. You will need a small hand held dental mirror, STD-3907, to see the forward face of the heat exchanger.
 - 1) If you find debris, clean to remove debris.
 - NOTE: If you see little to no light through the heat exchanger fins during the check with a flashlight, this indicates that airflow is significantly obstructed and the cooling capability could be diminished. You can do the cleaning procedure to remove debris and improve airflow.
 - (c) Inspection of the fins.
 - 1) Broken, teared or cracked fins are not permitted.
 - a) If broken, teared or cracked fins are present, do the applicable tasks:
 - Engine Surface Air Cooling Oil Cooler 1 Removal, TASK 79-21-02-000-801-G00 and Engine Surface Air Cooling Oil Cooler 1 Installation, TASK 79-21-02-400-801-G00
 - Engine Surface Air Cooling Oil Cooler 2 Removal, TASK 79-21-02-000-802-G00 and Engine Surface Air Cooling Oil Cooler 2 Installation, TASK 79-21-02-400-802-G00.
 - 2) Missing fins
 - a) Not permitted.
 - b) Not repairable.
 - c) If it is necessary, replace or send to manufacturer.
 - Nick, scratch, gouge or dent on the fin.
 - a) Permitted up to 0.01 in. (0.254 mm) in depth for the nick or scratch and gouge without loss of the protective layer.
 - b) Permitted up to 0.1 in. (2.54 mm) in depth for dent or blending depth without loss of the protective layer.

SIA ALL



- c) Raised metal is not permitted.
- d) If raised metal is present, do these steps:
 - NOTE: Dents indication types on fins are considered as bent fins indication type, therefore the maximum number of cumulated finding to be considered on fins is 42 findings on both engine surface air cooling oil cooler.
 - <1> If 43 fins are found with findings, replace the engine surface air cooling oil coolers (PAGEBLOCK 79-21-02/401).
 - Use a carbide bur set, STD-21746, and hand grind out findings to remove heavy burrs or raised metal.
 - <3> Use an India oil stone, COM-21826, to remove light burrs.
 - <4> Use a 500 grit abrasive cloth, G51791, to remove edges of repaired surfaces smoothly into adjacent surfaces.
 - <5> Do not remove more material than necessary.
 - NOTE: No high metal must remain. The transition with the non-blended area must be smooth.
 - NOTE: After blending, the maximum depth on the blended area must be not over than 0.1 in. (2.54 mm).
- 4) The first and last three rows of fins are removed. Any surface cooler found to have missing fins in any other area should be replaced with a new surface cooler assembly.
 - NOTE: The first and last three rows of fins are removed for manufacturing purposes and will not adversely affect the function of the coolers.
- 5) Bent fins
 - A total of 42 bent fins, without loss of the protective layer, is acceptable on both air-oil exchanger. If cracks are visible, remove and replace the part.
 - b) If there is more than 21 bent fins on 1 air-oil exchanger, proceed to the following repair steps.
 - <1> Insert a locally manufactured straightening tool between the bent fins and gently apply force to straighten the fins back to approximately 90 degrees to the cooler body.
 - NOTE: The fins should have a gap of 0.085 in. (2.159 mm) (reference) between them.
 - <a> If you damage any fins when you straight it, remove the surface cooler.
 - You may use needle nose pliers or similar type tool to straighten small localized areas of fin deformation.
 - <3> Continue the same process to repair all the bent fins.
 - NOTE: Fins can become loose or dislodged from repeated or over bending. After straightening all fins, check to assure the fins are secure. You should not be able to move the individual fins with your fingers. If the fins move easily with just finger pressure, the surface cooler should be replaced.
- (d) Examine the sealing surfaces in zone A, B, and C.

SIA ALL



- 1) Examine all the sealing surfaces of the cooler for evidence of scratches, raised metal, nicks, gouges, cracks, and dents.
- 2) The requirements of inspection criteria apply to all sealing surfaces.
 - a) Any number up to 0.001 in. (0.025 mm) is permitted.
 - b) Do a check for scratches, raised metal, nicks, gouges, and cracks.
 - <1> Permitted up to 0.010 in. (0.254 mm) in depth of scratches/gouges.
 - <2> Raised metal or cracks are not permitted.
 - <3> Not repairable.
 - <4> If it is necessary, replace or send to manufacturer.
 - c) Do a check for dents in zone A.
 - <1> Permitted up to 0.01 in. (0.254 mm) in depth without loss of the protective layer.
 - <2> Raised metal or cracks are not permitted.
 - <3> If raised metal is present, do these steps:
 - <a> Use a carbide bur set, STD-21746, and hand grind out findings to remove heavy burrs or raised metal.
 -

 Use an India oil stone, COM-21826, to remove light burrs.
 - <c> Use a 500 grit abrasive cloth, G51791, to remove edges of repaired surfaces smoothly into adjacent surfaces.
 - <d> Do not remove more material than necessary.
 - NOTE: No high metal must remain. The transition with the non-blended area must be smooth.
 - NOTE: After blending, the maximum depth on the blended area must be less than 0.032 in. (0.81 mm).
 - <4> If it is necessary, replace or send to manufacturer.
- (e) Oil stains or leakage.
 - 1) Oil stains or leakage are not permitted.
 - a) If you find them, do the applicable tasks:
 - Engine Surface Air Cooling Oil Cooler 1 Removal, TASK 79-21-02-000-801-G00 and Engine Surface Air Cooling Oil Cooler 1 Installation, TASK 79-21-02-400-801-G00
 - Engine Surface Air Cooling Oil Cooler 2 Removal, TASK 79-21-02-000-802-G00 and Engine Surface Air Cooling Oil Cooler 2 Installation, TASK 79-21-02-400-802-G00.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-02-410-004-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the applicable left or right thrust reversers:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.

SIA ALL



1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

- (b) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location	
413	Left Fan Cowl, Engine 1	
414	Right Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	
424	Right Fan Cowl, Engine 2	


(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

SUBTASK 79-21-02-860-006-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.







ZONE ALLOWABLE SCRATCH/GOUGE:

ZONE A: 0.010 in (0.254 mm) SCRATCH/GOUGE DEPTH
ZONE B: 0.010 in (0.254 mm) SCRATCH/GOUGE DEPTH
ZONE C: 0.010 in (0.254 mm) SCRATCH/GOUGE DEPTH
NO HIGH METAL IN ZONES A, B, C
NO MISSING FIN ALLOWED 0.010 in (0.254 mm) SCRATCH/GOUGE DEPTH ALLOWABLE ON FIN

2798878 S0000639898_V1

Engine Surface Air Cooling Oil Cooler Inspection Figure 601/79-21-02-990-805-G00 (Sheet 1 of 3)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details


79-21-02

Page 607 May 15/2022






ALLOWABLE SCRATCH / GOUGE DEPTH ON THE INLET / OUTLET MANIFOLDS



ALLOWABLE SCRATCH / GOUGE DEPTH ON THE RETURN MANIFOLDS



2799088 S0000639899_V1


Engine Surface Air Cooling Oil Cooler Inspection Figure 601/79-21-02-990-805-G00 (Sheet 2 of 3)


SIA ALL
D633AM101-SIA


79-21-02

Page 608 May 15/2022









2799146 S0000639900_V1

Engine Surface Air Cooling Oil Cooler Inspection Figure 601/79-21-02-990-805-G00 (Sheet 3 of 3)

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-02

Page 609 May 15/2022



LUBRICATION UNIT - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Lubrication Unit Removal
 - (2) Lubrication Unit Installation.

TASK 79-21-03-000-801-G00

2. Lubrication Unit Removal

(Figure 401)

A. General

(1) This task gives the instructions to remove the lubrication unit.

B. References

Reference	Title
12-13-11-600-803	Engine Oil Change Servicing (P/B 301)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
79-35-01-000-801-G00	Oil Filter Differential Pressure Sensor Removal (P/B 401)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description
SPL-14893	Guide Pins - Installation, Lubrication Unit
	Part #: 956A8673G02 Supplier: 58828
STD-858	Tag - DO NOT OPERATE
STD-1055	Container - Oil Resistant, 5 Gallon (19 Liter)

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
G02345 [CP8001]	Wire - Safety, 0.032 Inch (0.8 mm) Diameter	AMS 5687

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity	
4	Preformed packing	79-21-07-01-020	SIA ALL	

F. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

G. Access Panels

Number	Name/Location	
413	Left Fan Cowl. Engine 1	

SIA ALL



(Continued)

Number	Name/Location
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

H. Prepare for the Removal

SUBTASK 79-21-03-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-03-010-001-G00

(2) Do these tasks in sequence to safely open the left thrust reverser on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left fan cowl panel (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left thrust reverser (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2



I. Lubrication Unit Removal

SUBTASK 79-21-03-680-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(1) Drain the oil from the lubrication unit [1]:



DO NOT SPILL THE OIL. USE A MINIMUM OF TWO CONTAINERS TO DRAIN THE OIL. A LARGE VOLUME OF OIL WILL DRAIN FROM THE LUBE PUMP.

- (a) Put the oil resistant container (5 gal)(19 Liter), STD-1055 below the lubrication unit [1].
- (b) Drain the oil tank (TASK 12-13-11-600-803).
- (c) Remove the drain plug [3] from the lubrication unit [1].
 - 1) Cut the safety wire [5] from the drain plug [3].
 - 2) Remove the drain plug [3] from the lubrication unit [1].
 - 3) Remove and discard the preformed packing [4] from the drain plug [3].
 - 4) Let the oil drain into the oil resistant container (5 gal)(19 Liter), STD-1055.
- (d) Install the drain plug [3] on the lubrication unit [1].
 - 1) Make sure that the mating faces are clean and clear of unwanted materials.
 - 2) Lubricate a new preformed packing [4] with the oil, D00599 [CP2442].
 - 3) Install the new preformed packing [4] on the drain plug [3].
 - 4) Install the drain plug [3] on the lubrication unit [1].
 - 5) Tighten the drain plug [3] to 67.45 in-lb (7.6 N·m) 74.55 in-lb (8.4 N·m).
 - 6) Install a safety wire [5] (safety wire, G02345 [CP8001]) on the drain plug [3].

SIA ALL



SUBTASK 79-21-03-020-001-G00

(2) Do this task: Oil Filter Differential Pressure Sensor Removal, TASK 79-35-01-000-801-G00.

SUBTASK 79-21-03-030-001-G00

- (3) Disconnect the oil tube [6] from the lubrication unit [1]:
 - (a) Remove the four bolts [7] from the oil tube [6].
 - (b) Disconnect the oil tube [6] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [8] from the oil tube [6].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-030-002-G00

- (4) Disconnect the oil tube [9] from the lubrication unit [1]:
 - (a) Remove the four bolts [10] from the oil tube [9].
 - (b) Disconnect the oil tube [9] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [11] from the oil tube [9].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-030-003-G00

- (5) Disconnect the oil tube [22] and oil tube [29]:
 - (a) Remove the nut [12] and bolt [13] that attach the clamp [14] and clamp [15] to the bracket [16].
 - (b) Remove the clamp [14] and oil tube [22] from the bracket [16].
 - (c) Remove the clamp [15] and oil tube [29] from the bracket [16].

SUBTASK 79-21-03-010-002-G00

- (6) Disconnect the oil tube [22] and oil tube [29] from the bracket [21]:
 - (a) Remove the nut [17] and bolt [18] that attach the clamp [19] and clamp [20] to the bracket [21].
 - (b) Remove the clamp [19] and oil tube [22] from the bracket [21].
 - (c) Remove the clamp [20] and oil tube [29] from the bracket [21].

SUBTASK 79-21-03-010-003-G00

- (7) Disconnect the oil tube [22] from the lubrication unit [1]:
 - (a) Remove the electrical harness HJ3A [23] from the clip [24].
 - (b) Remove the two bolts [25] that attach the bracket [28] to the oil tube [22].
 - (c) Remove the bracket [28] from the oil tube [22].
 - (d) Remove the bolt [26] from the oil tube [22].
 - (e) Disconnect the oil tube [22] from the lubrication unit [1].
 - (f) Remove and discard the gasket seal [27] from the oil tube [22].
 - (g) Install the protective covers on the openings.

SUBTASK 79-21-03-010-004-G00

- (8) Disconnect the oil tube [29] from the lubrication unit [1]:
 - (a) Remove the three bolts [30] from the oil tube [29].
 - (b) Disconnect the oil tube [29] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [31] from the oil tube [29].



(d) Install the protective covers on the openings.

SUBTASK 79-21-03-010-005-G00

- (9) Disconnect the oil tube [32] from the AGB [35]:
 - (a) Remove the four bolts [33] from the oil tube [32].
 - (b) Disconnect the oil tube [32] from the AGB [35].
 - (c) Remove and discard the gasket seal [34] from the AGB [35].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-010-006-G00

- (10) Disconnect the oil tube [32] from the lubrication unit [1]:
 - (a) Remove the three bolts [37] from the oil tube [32].
 - (b) Disconnect the oil tube [32] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [38] from the oil tube [32].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-010-007-G00

- (11) Disconnect the oil tube [39] from the lubrication unit [1]:
 - (a) Remove the three bolts [40] from the oil tube [39].
 - (b) Disconnect the oil tube [39] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [41] from the oil tube [39].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-010-008-G00

- (12) Disconnect the oil tube [42] from the lubrication unit [1]:
 - (a) Remove the three bolts [43] from the oil tube [42].
 - (b) Disconnect the oil tube [42] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [44] from the oil tube [42].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-010-009-G00

- (13) Disconnect the oil tube [45] from the lubrication unit [1]:
 - (a) Remove the three bolts [46] from the oil tube [45].
 - (b) Disconnect the oil tube [45] from the lubrication unit [1].
 - (c) Remove and discard the gasket seal [47] from the oil tube [45].
 - (d) Install the protective covers on the openings.

SUBTASK 79-21-03-020-002-G00



BE CAREFUL WHEN YOU MOVE THE COMPONENT. THE COMPONENT IS HEAVY. INJURIES TO PERSONS CAN OCCUR.

(14) Remove the lubrication unit [1] from the Accessory Gearbox (AGB) input pad:

NOTE: The lubrication unit [1] weighs 28.7 lb (13.0 kg).

(a) Remove any three bolts [48] and three washers [49] not adjacent to each other that attach the lubrication unit [1] to the AGB input pad.

EFFECTIVITY SIA ALL



- (b) Install the guide pins, SPL-14893 through the three bolt holes of the lubrication unit [1] to the AGB input pad.
- (c) Remove the remaining six bolts [48] and six washers [49] that attach the lubrication unit [1] to the AGB input pad.




THE AGB SHAFT SLEEVE CAN STAY ATTACHED TO THE LUBE PUMP DRIVE-SHAFT WHEN YOU REMOVE THE LUBE PUMP FROM THE AGB. MAKE SURE THAT THE AGB SHAFT SLEEVE STAYS ON THE AGB. IF YOU DO NOT INSTALL THE AGB SHAFT SLEEVE, THE ENGINE WILL NOT HAVE SUFFICIENT LUBRICATION WHEN YOU OPERATE AND DAMAGE TO THE ENGINE CAN OCCUR.

- (d) Carefully pull the lubrication unit [1] rearward until the splines of the drive shaft [50] disengage from the AGB input pad.
- (e) Make sure that the AGB shaft sleeve remains installed in the AGB drive gear and that it is not pulled out together with the lubrication unit drive shaft.
- (f) Remove and discard the preformed packing [51] from the groove of the lubrication unit [1].
- (g) Remove and discard the preformed packing [52] from the groove of the drive shaft [50].
- (h) Remove and discard the preformed packing [53] from the groove of the lubrication unit [1].
- (i) Remove the guide pins.
- (j) Install the protective covers on the openings.

----- END OF TASK -----





Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 1 of 6)


ECCN 9E991 BOEING PROPRIETARY - See title page for details

SIA ALL

79-21-03

Page 407 Sep 15/2021





Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 2 of 6)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 3 of 6)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 4 of 6)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





A0005-A-001-01 2403284 S0000555956_V2

Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 5 of 6)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-03

Page 411 Sep 15/2021





Lubrication Unit Installation Figure 401/79-21-03-990-802-G00 (Sheet 6 of 6)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



TASK 79-21-03-400-801-G00

3. Lubrication Unit Installation

(Figure 401)

A. General

(1) This task gives the instructions to install the lubrication unit.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
72-00-00-910-801-G00	High Pressure Rotor (N2) Turning for Borescope (P/B 201)
72-63-01-610-802-G00	Accessory Gearbox Assembly Oil Replenishing (P/B 201)
72-63-04-400-801-G00	Accessory Gearbox Manual Control Cover Installation (P/B 401)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)
79-35-01-400-801-G00	Oil Filter Differential Pressure Sensor Installation (P/B 401)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description
SPL-14847	Kit, Installation - O-Ring, AGB
	Part #: 956A8610G01 Supplier: 58828
SPL-14893	Guide Pins - Installation, Lubrication Unit
	Part #: 956A8673G02 Supplier: 58828
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
8	Gasket seal	79-21-03-01-040	SIA ALL
11	Gasket seal	79-21-03-01-020	SIA ALL
27	Gasket seal	79-21-03-01-080	SIA ALL
31	Gasket seal	79-21-03-01-100	SIA ALL
34	Gasket seal	72-00-00-12-200	SIA ALL
38	Gasket seal	79-21-03-01-140	SIA ALL
41	Gasket seal	79-21-03-01-120	SIA ALL
44	Gasket seal	79-21-03-01-160	SIA ALL
47	Gasket seal	79-21-03-01-180	SIA ALL
51	Preformed packing	79-21-03-01-230	SIA ALL

SIA ALL



(Continued)

AMM Item	Description	AIPC Reference	AIPC Effectivity
52	Preformed packing	79-21-03-01-210	SIA ALL
53	Preformed packing	79-21-03-01-220	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

H. Lubrication Unit Installation

SUBTASK 79-21-03-490-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



BE CAREFUL WHEN YOU MOVE THE COMPONENT. THE COMPONENT IS HEAVY. INJURIES TO PERSONS CAN OCCUR.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.



THE AGB SHAFT SLEEVE CAN STAY ATTACHED TO THE LUBE PUMP DRIVE-SHAFT WHEN YOU REMOVE THE LUBE PUMP FROM THE AGB. MAKE SURE THAT THE AGB SHAFT SLEEVE STAYS ON THE AGB. IF YOU DO NOT INSTALL THE AGB SHAFT SLEEVE, THE ENGINE WILL NOT HAVE SUFFICIENT LUBRICATION WHEN YOU OPERATE AND DAMAGE TO THE ENGINE CAN OCCUR.

- (1) Install the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the splines of the drive shaft [50] with engine oil, D00599 [CP2442].
 - (d) Lubricate the nine bolts [48] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Lubricate the new preformed packing [51], new preformed packing [52], and new preformed packing [53] with pure mineral vaseline, D00672 [CP5070].
 - (f) Use the O-ring installation kit, SPL-14847 to install the new preformed packing [53] into the groove of the lubrication unit [1].

SIA ALL

79-21-03

Page 414 Sep 15/2021



- (g) Install the new preformed packing [52] into the groove of the drive shaft [50].
- (h) Install the new preformed packing [51] into the groove of the lubrication unit [1].
- (i) Install the guide pins, SPL-14893, through the three bolt holes of the Accessory Gearbox (AGB) input pad.



MAKE SURE THAT YOU INSTALL THE AGB SHAFT SPLINED SLEEVE IN THE AGB DRIVE GEAR BEFORE YOU INSTALL THE LUBRICATION UNIT ON THE AGB. DAMAGE TO EQUIPMENT CAN OCCUR.

- (j) Align the drive shaft [50] of the lubrication unit [1] with the splines of the AGB input pad as follows:
 - 1) If it is necessary, turn the AGB shaft (TASK 72-00-00-910-801-G00).
- (k) Carefully align the lubrication unit [1] with the guide pins and push the drive shaft [50] of the lubrication unit [1] into the AGB input pad.
- (I) Make sure that the mating flange of the lubrication unit [1] is fully engaged with the AGB input pad.
- (m) Install the six bolts [48] and six washers [49] that attach the lubrication unit [1] to the AGB input pad.
- (n) Remove the guide pins.
- (o) Install the remaining three bolts [48] and three washers [49] that attach the lubrication unit [1] to the AGB input pad.
- (p) Tighten the bolts [48] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m), in a criss-cross pattern.
- (q) If the AGB manual control cover has been removed, do this task: Accessory Gearbox Manual Control Cover Installation, TASK 72-63-04-400-801-G00.

SUBTASK 79-21-03-090-001-G00

- (2) Connect the oil tube [45] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [47] with engine oil, D00599 [CP2442].
 - (d) Lubricate the three bolts [46] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [47] and oil tube [45] on the lubrication unit [1].
 - (f) Install the three bolts [46] that attach the oil tube [45] to the lubrication unit [1].
 - (g) Tighten the three bolts [46] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-001-G00

- (3) Connect the oil tube [42] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [44] with engine oil, D00599 [CP2442].
 - (d) Lubricate the three bolts [43] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [44] and oil tube [42] on the lubrication unit [1].
 - (f) Install the three bolts [43] that attach the oil tube [42] to the lubrication unit [1].
 - (g) Tighten the bolts [43] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SIA ALL



SUBTASK 79-21-03-410-002-G00

- (4) Connect the oil tube [39] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [41] with engine oil, D00599 [CP2442].
 - (d) Lubricate the three bolts [40] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [41] and oil tube [39] on the lubrication unit [1].
 - (f) Install the three bolts [40] that attach the oil tube [39] to the lubrication unit [1].
 - (g) Tighten the bolts [40] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-003-G00

- (5) Connect the oil tube [32] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [38] with engine oil, D00599 [CP2442].
 - (d) Lubricate the three bolts [37] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [38] and oil tube [32] on the lubrication unit [1].
 - (f) Install the three bolts [37] that attach the oil tube [32] to the lubrication unit [1].
 - (g) Tighten the bolts [37] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-004-G00

- (6) Connect the oil tube [32] to the AGB [35].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [34] with engine oil, D00599 [CP2442].
 - (d) Install the new gasket seal [34] and oil tube [32] in a correct position on the lubrication unit [1].
 - (e) Install the four bolts [33] that attach the oil tube [32] to the lubrication unit [1].
 - (f) Tighten the bolts [33] to 84.1 in-lb (9.5 N·m) 92.9 in-lb (10.5 N·m).

SUBTASK 79-21-03-410-005-G00

- (7) Connect the oil tube [29] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [31] with engine oil, D00599 [CP2442].
 - (d) Lubricate the three bolts [30] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [31] and oil tube [29] on the lubrication unit [1].
 - (f) Install the three bolts [30] that attach the oil tube [29] to the lubrication unit [1].
 - (g) Tighten the bolts [30] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-006-G00

SIA ALL

- (8) Connect the oil tube [22] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.



- (c) Lubricate the new gasket seal [27] with engine oil, D00599 [CP2442].
- (d) Lubricate the two bolts [25] and bolt [26] with graphite mineral vaseline, D00601 [CP2101].
- (e) Install the new gasket seal [27] and oil tube [22] on the lubrication unit [1].
- (f) Install the bolt [26] that attach the oil tube [22] to the lubrication unit [1].
- (g) Tighten the bolt [26] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
- (h) Install the bracket [28] on the oil tube [22].
- (i) Install the two bolts [25] that attach the bracket [28] to the oil tube [22].
- (j) Tighten the two bolts [25] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-007-G00

(9) Install the electrical harness HJ3A [23] on the clip [24].

SUBTASK 79-21-03-410-008-G00

- (10) Connect the oil tube [22] and oil tube [29] to the bracket [21].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Install the clamp [20] and oil tube [29] on the bracket [21].
 - (d) Install the clamp [19] and oil tube [22] on the bracket [21].
 - (e) Install the nut [17] and bolt [18] that attach the clamp [19] and clamp [20] to the bracket [21].
 - (f) Tighten the nut [17] to 42.0 in-lb (4.75 N·m) 46.5 in-lb (5.25 N·m).

SUBTASK 79-21-03-410-009-G00

- (11) Connect the oil tube [22] and oil tube [29] to the bracket [16].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Install the clamp [15] and oil tube [29] on the bracket [16].
 - (d) Install the clamp [14] and oil tube [22] on the bracket [16].
 - (e) Install the nut [12] and bolt [13] that attach the clamp [14] and the clamp [15] to the bracket [16].
 - (f) Tighten the nut [12] to 42.0 in-lb (4.75 N·m) 46.5 in-lb (5.25 N·m).

SUBTASK 79-21-03-410-010-G00

- (12) Connect the oil tube [9] to the lubrication unit [1].
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.
 - (c) Lubricate the new gasket seal [11] with engine oil, D00599 [CP2442].
 - (d) Lubricate the four bolts [10] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new gasket seal [11] and oil tube [9] on the lubrication unit [1].
 - (f) Install the four bolts [10] that attach the oil tube [9] to the lubrication unit [1].
 - (g) Tighten the bolts [10] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-21-03-410-011-G00

(13) Connect the oil tube [6] to the lubrication unit [1].

SIA ALL



- (a) Make sure that the mating faces are clean and clear of unwanted materials.
- (b) Remove the protective covers on the openings.
- (c) Lubricate the new gasket seal [8] with engine oil, D00599 [CP2442].
- (d) Lubricate the four bolts [7] with graphite mineral vaseline, D00601 [CP2101].
- (e) Install the new gasket seal [8] and oil tube [6] on the lubrication unit [1].
- (f) Install the four bolts [7] that attach the oil tube [6] to the lubrication unit [1].
- (g) Tighten the bolts [7] to 110 in-lb (12.4 N·m) 120 in-lb (13.6 N·m).

SUBTASK 79-21-03-100-001-G00

- (14) Do this task: Oil Filter Differential Pressure Sensor Installation, TASK 79-35-01-400-801-G00.
- (15) Do this task: Accessory Gearbox Assembly Oil Replenishing, TASK 72-63-01-610-802-G00.
- (16) Do this task: Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801.

SUBTASK 79-21-03-420-001-G00

- (17) Clean the work area and clear the tools and other items.
- I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-03-410-012-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the left thrust reverser:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

- (b) Close the applicable left Fan Cowl Panel (TASK 71-11-04-410-801-G00).
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

SUBTASK 79-21-03-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SIA ALL

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

J. Lubrication Unit Installation Test

SUBTASK 79-21-03-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

----- END OF TASK -----

SIA ALL

79-21-03

ECCN 9E991 BOEING PROPRIETARY - See title page for details



SCAVENGE SCREEN PLUGS - MAINTENANCE PRACTICES

1. General

- A. This procedure has these tasks:
 - (1) A removal of the scavenge screen plugs
 - (2) An installation of the scavenge screen plugs
 - (3) An inspection of the scavenge screen plugs.

TASK 79-21-04-000-801-G00

2. Scavenge Screen Plugs Removal

(Figure 201 or Figure 202)

A. General

(1) This task provides the instructions to remove the scavenge screen plugs.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	

F. Prepare for the Removal

SUBTASK 79-21-04-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-04-860-013-G00

- (2) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1

SIA ALL



(Continued)

Number Name/Location

423 Left Fan Cowl, Engine 2

Scavenge Screen Plugs Removal



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007



DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

SIA ALL

SUBTASK 79-21-04-010-003-G00

(1) Remove the single stage scavenge screen plug [1] as follows:

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007

(a) Do not remove the hexagonal magnetic chip plug [6] and magnetic bar for inspection.

NOTE: If you remove hexagonal magnetic chip plug and magnetic bar, then scavenge screen sleeve will catch the particles.

SIA ALL

79-21-04

Page 202 Sep 15/2021



- (b) Remove the scavenge screen plug bolt [9] that attaches the single stage scavenge screen plug [1] to the lubrication unit [5].
- (c) Remove the single stage scavenge screen plug [1] from the lubrication unit [5].
- (d) Remove the O-ring [10] from the groove on the single stage scavenge screen plug [1].
- (e) Discard the O-ring [10].
- (f) Install the protective covers on the single stage scavenge screen plug [1] and lubrication unit [5] port.

SUBTASK 79-21-04-010-004-G00

(2) Remove the single stage scavenge screen plug [2] as follows:

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007

(a) Do not remove the hexagonal magnetic chip plug [7] and magnetic bar for inspection.

NOTE: If you remove hexagonal magnetic chip plug and magnetic bar, then scavenge screen sleeve will catch the particles.

SIA ALL

- (b) Remove the scavenge screen plug bolt [11] that attaches the single stage scavenge screen plug [2] to the lubrication unit [5].
- (c) Remove the single stage scavenge screen plug [2] from the lubrication unit [5].
- (d) Remove the O-ring [12] from the groove on the single stage scavenge screen plug [2].
- (e) Discard the O-ring [12].
- (f) Install the protective covers on the single stage scavenge screen plug [2] and lubrication unit [5] port.

SUBTASK 79-21-04-010-005-G00

(3) Remove the double stage scavenge screen plug [3] as follows:

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007

(a) Do not remove the hexagonal magnetic chip plug [19] and magnetic bar for inspection.

NOTE: If you remove hexagonal magnetic chip plug and magnetic bar, then scavenge screen sleeve will catch the particles.

SIA ALL

- (b) Remove the scavenge screen plug bolt [13] that attaches the double stage scavenge screen plug [3] to the lubrication unit [5].
- (c) Remove the double stage scavenge screen plug [3] from the lubrication unit [5].
- (d) Remove the O-ring [14] from the groove on the double stage scavenge screen plug [3].
- (e) Remove the O-ring [15] from the groove on the double stage scavenge screen plug [3].
- (f) Discard the O-ring [14] and O-ring [15].
- (g) Install the protective covers on the double stage scavenge screen plug [3] and lubrication unit [5] port.

SUBTASK 79-21-04-010-001-G00

(4) Remove the double stage scavenge screen plug [4] as follows:

SIA ALL 79-21-04



SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007

(a) Do not remove the hexagonal magnetic chip plug [20] and magnetic bar for inspection.

NOTE: If you remove hexagonal magnetic chip plug and magnetic bar, then scavenge screen sleeve will catch the particles.


SIA ALL

- (b) Remove the scavenge screen plug bolt [16] that attaches the double stage scavenge screen plug [4] to the lubrication unit [5].
- (c) Remove the double stage scavenge screen plug [4] from the lubrication unit [5].
- (d) Remove the O-ring [17] from the groove on the double stage scavenge screen plug [4].
- (e) Remove the O-ring [18] from the groove on the double stage scavenge screen plug [4].
- (f) Discard the O-ring [17] and O-ring [18].
- (g) Install the protective covers on the double stage scavenge screen plug [4] and lubrication unit [5] port.

——— END OF TASK ———

SIA ALL 79-21-04






Scavenge Screen Plugs Installation Figure 201/79-21-04-990-804-G00 (Sheet 1 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007






ICNLEAP1B792104D5882800002A00101 2422204 S0000560083_V4

Scavenge Screen Plugs Installation Figure 201/79-21-04-990-804-G00 (Sheet 2 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007






A0003-A-001-01 2422217 S0000560084_V3

Scavenge Screen Plugs Installation Figure 201/79-21-04-990-804-G00 (Sheet 3 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007






2979188 S0000757149_V1

Scavenge Screen Plugs Installation Figure 202/79-21-04-990-806-G00 (Sheet 1 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007






ICNLEAP1B792104D5882800008A00101

2979189 S0000757082_V1

Scavenge Screen Plugs Installation Figure 202/79-21-04-990-806-G00 (Sheet 2 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007







ICNLEAP1B792104D5882800009A00101

2979190 S0000757088_V1

Scavenge Screen Plugs Installation Figure 202/79-21-04-990-806-G00 (Sheet 3 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007

79-21-04

Page 210 Sep 15/2021



TASK 79-21-04-400-801-G00

3. Scavenge Screen Plugs Installation

(Figure 201 or Figure 202)

A. General

(1) This task provides the instructions to install the scavenge screen plugs.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
10	O-ring	79-21-04-01-035	SIA ALL
12	O-ring	79-21-04-01-035	SIAALL
14	O-ring	79-21-04-01-225	SIAALL
15	O-ring	79-21-04-01-222	SIAALL
17	O-ring	79-21-04-01-125	SIAALL
18	O-ring	79-21-04-01-122	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

H. Scavenge Screen Plugs Installation

SUBTASK 79-21-04-010-002-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(1) Install the scavenge screen plugs as follows:

SIA ALL



(a) Make sure that the mating faces are clean and clear of unwanted materials.



DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

- (b) Install the double stage scavenge screen plug [4] as follows:
 - Remove the protective covers from the double stage scavenge screen plug [4] and lubrication unit [5] port.
 - 2) Lubricate the new O-ring [17] and new O-ring [18] with pure mineral vaseline, D00672 [CP5070].
 - 3) Install the new O-ring [17] on the groove on the double stage scavenge screen plug [4].



MAKE SURE THAT YOU USE THE CORRECT PART NUMBERS WHEN YOU REPLACE THE O-RING IN EACH SCAVENGE-SCREEN GROOVE LOCATION. THE PART NUMBERS OF THE DIFFERENT O-RINGS ARE ALMOST THE SAME NUMBER. IF YOU DO NOT USE THE CORRECT PART NUMBERS, DAMAGE CAN OCCUR.

- 4) Install the new O-ring [18] on the groove on the double stage scavenge screen plug [4].
- 5) Install the double stage scavenge screen plug [4] on the lubrication unit [5].
- 6) Install the scavenge screen plug bolt [16] that attaches the double stage scavenge screen plug [4] to the lubrication unit [5].
- 7) Tighten the scavenge screen plug bolt [16] to 67.45 in-lb (7.62 N·m) 74.55 in-lb (8.42 N·m).



DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

- (c) Install the double stage scavenge screen plug [3] as follows:
 - Remove the protective covers from the double stage scavenge screen plug [3] and lubrication unit [5] port.
 - 2) Lubricate the new O-ring [14] and new O-ring [15] with pure mineral vaseline, D00672 [CP5070].
 - Install the new O-ring [14] on the groove on the double stage scavenge screen plug [3].

SIA ALL 79-21-04





MAKE SURE THAT YOU USE THE CORRECT PART NUMBERS WHEN YOU REPLACE THE O-RING IN EACH SCAVENGE-SCREEN GROOVE LOCATION. THE PART NUMBERS OF THE DIFFERENT O-RINGS ARE ALMOST THE SAME NUMBER. IF YOU DO NOT USE THE CORRECT PART NUMBERS, DAMAGE CAN OCCUR.

- 4) Install the new O-ring [15] on the groove on the double stage scavenge screen plug [3].
- 5) Install the double stage scavenge screen plug [3] on the lubrication unit [5].
- Install the scavenge screen plug bolt [13] that attaches the double stage scavenge screen plug [3] to the lubrication unit [5].
- Tighten the scavenge screen plug bolt [13] to 67.45 in-lb (7.62 N·m) 74.55 in-lb (8.42 N·m).



DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

- Install the single stage scavenge screen plug [2] as follows:
 - Remove the protective covers from the single stage scavenge screen plug [2] and lubrication unit [5] port.
 - Lubricate the new O-ring [12] with pure mineral vaseline, D00672 [CP5070]. 2)
 - 3) Install the new O-ring [12] on the groove on the single stage scavenge screen plug [2].
 - 4) Install the single stage scavenge screen plug [2] on the lubrication unit [5].
 - Install the scavenge screen plug bolt [11] that attaches the single stage scavenge screen plug [2] to the lubrication unit [5].
 - Tighten the scavenge screen plug bolt [11] to 67.45 in-lb (7.62 N·m) 74.55 in-lb (8.42 N·m).



CAUTION

DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

- Install the single stage scavenge screen plug [1] as follows:
 - Remove the protective covers from the single stage scavenge screen plug [1] and 1) lubrication unit [5] port.
 - Lubricate the new O-ring [10] with pure mineral vaseline, D00672 [CP5070].

EFFECTIVITY SIA ALL



- 3) Installs the new O-ring [10] on the groove on the single stage scavenge screen plug [1].
- 4) Install the single stage scavenge screen plug [1] on the lubrication unit [5].
- 5) Install the scavenge screen plug bolt [9] that attaches the single stage scavenge screen plug [1] to the lubrication unit [5].
- 6) Tighten the scavenge screen plug bolt [9] to 67.45 in-lb (7.62 N·m) 74.55 in-lb (8.42 N·m).
- (f) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-04-860-014-G00

- (1) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

SUBTASK 79-21-04-860-007-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Scavenge Screen Plugs Installation Test

SUBTASK 79-21-04-730-001-G00

 Do the applicable tests given in the Power Plant Reference Table (TASK 71-00-00-800-804-G00).

------ END OF TASK ------

TASK 79-21-04-211-801-G00

4. Scavenge Screen Plug Inspection

(Figure 203 or Figure 204 or Figure 205)

A. General

(1) This task includes steps to perform the inspection of the scavenge screen plug.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
79-00-00-220-801-G00	Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check (P/B 601)
80-11-09-200-801-G00	Engine Starter Magnetic Plug Inspection (P/B 201)

SIA ALL



C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE
STD-1280	Source - Air, Regulated, Dry Filtered, 0-30 PSIG

D. Consumable Materials

Reference	Description	Specification		
B00682 [CP2011]	Solvent - Stoddard	MIL-PRF-680 Type I, II or III		
B50295 [CP2010]	Solvent - cleaning, White Spirit			
G00034	Cotton Wiper - Process Cleaning Absorbent Wiper (Cheesecloth, Gauze)	AMS3819 Class 1 Grade A or B Form 1 (Supersede BMS15-5 CL A)		

E. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

F. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	

G. Prepare for the Inspection



SOME OF THE SCAVENGE SCREENS PLUGS ARE DOUBLE STAGES. TAKE CARE TO DO NOT MIX PARTICLES DURING DOUBLE STAGES SCAVENGE SCREENS PLUGS MAINTENANCE. A MIX OF THE PARTICLES COULD LEAD TO AN INACCURATE INTERPRETATION OF SERVICEABLE CRITERIA, DAMAGE CAN OCCUR.



TAG THE REMOVED PARTICLES WITH THE RIGHT SUMP NAME TO PREVENT AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL DURING VISUAL CHARACTERIZATION AND LABORATORY ANALYSIS. AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL COULD LEAD TO AN INACCURATE INTERPRETATION OF SERVICEABLE CRITERIA AND DAMAGE CAN OCCUR.



CFM DOES NOT RECOMMEND THE USE OF ADHESIVE TAPE. IF YOU USE A PIECE OF ADHESIVE TAPE TO COLLECT THE PARTICLES, MAKE SURE THE ADHESIVE IS NOT TOO STRONG. IF THE ADHESIVE ON THE TAPE IS TOO STRONG, IT CAN CAUSE DAMAGE.



DO NOT USE A TOO STRONG POWER MAGNET TO REMOVE THE PARTICLES FROM THE SCAVENGE SCREENS PLUGS. IF YOU USE A TOO STRONG POWER MAGNET, IT CAN DECREASE THE MAGNETIC PERFORMANCE OF THE MAGNETIC CHIP DETECTOR. IF YOU DO NOT OBEY, DAMAGE CAN OCCUR.

SIA ALL 79-21-04



(CAUTION PRECEDES)

NOTE: Remove and examine the scavenge screen plug one by one to be sure of the origin of the particles.

NOTE: Remove, tag and examine one scavenge screen plug at a time. This is to prevent errors in identification of the source of the particles on the scavenge screen plug.

NOTE: Characteristics of magnetic bar retriever without impact on scavenge screen plug magnetic field:

- BHmax = 5.5 MGOe (max. energy product of magnetic field strength and magnetic flux density)
- Br = 12.8 kG (remanence, residual magnetism left behind after an external magnetic field is removed)
- Hc = 640 Oe (coercivity, measure of ability to withstand an external magnetic field without becoming demagnetized).

SUBTASK 79-21-04-860-009-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-04-860-010-G00

- (2) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location		
413	Left Fan Cowl, Engine 1		
423	Left Fan Cowl, Engine 2		

H. Scavenge Screen Plug Inspection



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.

SIA ALL



(WARNING PRECEDES)



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.



TAG THE REMOVED PARTICLES WITH THE RIGHT SUMP NAME TO PREVENT AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL DURING VISUAL CHARACTERIZATION AND LABORATORY ANALYSIS. AN ERROR IN IDENTIFICATION OF THE SOURCE OF THE MATERIAL COULD LEAD TO AN INACCURATE INTERPRETATION OF SERVICEABLE CRITERIA AND DAMAGE CAN OCCUR.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007



DO NOT REMOVE THE HEXAGONAL MAGNETIC CHIP PLUG FROM THE SCAVENGE SCREEN PLUG. IF YOU DO NOT OBEY, DAMAGE TO THE ENGINE CAN OCCUR.



DO NOT USE THE HEXAGONAL MAGNETIC CHIP PLUG TO REMOVE THE SCAVENGE SCREEN PLUGS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR.

SIA ALL

SUBTASK 79-21-04-200-002-G00

(1) Examine the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] for debris.

NOTE: Remove and inspect the scavenge screen plugs one by one to be sure of the origin of the particles.

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007

(a) Do not remove the hexagonal magnetic chip plug [12], hexagonal magnetic chip plug [13], hexagonal magnetic chip plug [16], hexagonal magnetic chip plug [17] and magnetic bars for inspection.

NOTE: If you remove hexagonal magnetic chip plugs and magnetic bars, then scavenge screen sleeve will catch the particles.

SIA ALL

SIA ALL

- (b) Remove the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9], from the lubrication unit lube and scavenge pump [1], do this task: Scavenge Screen Plugs Removal, TASK 79-21-04-000-801-G00.
- (c) Visually inspect the O-ring [15] of each scavenge screen plug.



- If the O-ring [15] is partially cut, inspect the lubrication unit lube and scavenge pump [1] scavenge cavity to check that the cavity is free of any piece(s) of O-ring [15] (Figure 203 or Figure 204 or Figure 205).
 - a) If there is a piece of O-ring [15] in the lubrication unit lube and scavenge pump [1] scavenge cavity, remove and keep it.
 - b) Make sure that the piece of O-ring [15] aligns with the cut O-ring [18].
 - <1> If the piece of O-ring [15] aligns with the O-ring [18], discard O-ring [15].
 - <2> If the piece of O-ring [15] does not align with the O-ring [18], do these steps:
 - <a> Take pictures of the piece of the O-ring [15].
 - Record dimension of the O-ring [18] section and estimated radius.
 - <c> Do this task: Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check, TASK 79-00-00-220-801-G00.

NOTE: If the piece of O-ring [15] is not removed during the inspection of the scavenge screen plug, there is a possibility to have a piece of O-ring [15] left in the lubrication unit lube and scavenge pump scavenge cavity. If this piece of O-ring [15] is not removed before scavenge screen plug installation, it will be trapped in the screen during the next engine operation. At the next scavenge screen plug inspection, this piece of O-ring [15] will be found and if the O-ring [15] is not cut during the visual inspection, this will cause confusion and potentially lead to unnecessary actions to troubleshoot the problem.

- (d) Visually inspect the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] for debris.
- (e) If you find some magnetic material on the TGB1 sump [7], TGB2 sump [8], or AGB sump [11] scavenge screen plugs, examine the starter magnetic plug for contamination, do this task: Engine Starter Magnetic Plug Inspection, TASK 80-11-09-200-801-G00.
- (f) If the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] are free from debris, do the following steps:



DO NOT GET THE SOLVENT IN YOUR MOUTH, EYES, OR ON YOUR SKIN. DO NOT BREATHE IN THE FUMES FROM THE SOLVENT. PUT ON PROTECTIVE SPLASH GOGGLES AND GLOVES WHEN YOU USE THE SOLVENT. KEEP THE SOLVENT AWAY FROM SPARKS, FLAME, AND HEAT. THE SOLVENT IS POISONOUS AND FLAMMABLE, WHICH CAN CAUSE INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT.

- 1) Clean the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] with solvent, B00682 [CP2011].
- 2) Dry the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] with a 0-30 psig dry filtered regulated air source, STD-1280.

SIA ALL



- 3) Make sure that the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] are free of all particles.
- 4) Install the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9], do this task: Scavenge Screen Plugs Installation, TASK 79-21-04-400-801-G00.
- (g) If there are debris particles on single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], or double stage scavenge screen plug [9], carefully remove them and keep the particles.
 - 1) If it is possible, take pictures of the particles on the concerned scavenge screen sump (either A sump [3], B sump [5], TGB1 sump [7], TGB2 sump [8], C sump [10], or AGB sump [11]).
 - a) Make sure that you identify each of the concerned scavenge screen sump before remove them.
 - 2) Carefully remove and keep the particles as follows:



DO NOT USE A TOO STRONG POWER MAGNET TO REMOVE THE PARTICLES FROM THE SCAVENGE SCREENS PLUGS. IF YOU USE A TOO STRONG POWER MAGNET, IT CAN DECREASE THE MAGNETIC PERFORMANCE OF THE MAGNETIC CHIP DETECTOR. IF YOU DO NOT OBEY, DAMAGE CAN OCCUR.

 Use cotton wiper, G00034, on a thin sheet of paper or/and a magnetic bar retriever.

NOTE: Characteristics of magnetic bar retriever without impact on scavenge screen plug magnetic field:

- BHmax = 5.5 MGOe (max. energy product of magnetic field strength and magnetic flux density)
- Br = 12.8 kG (remanence, residual magnetism left behind after an external magnetic field is removed)
- Hc = 640 Oe (coercivity, measure of ability to withstand an external magnetic field without becoming demagnetized).
- b) Use a magnet to separate the magnetic particles.



DO NOT GET THE SOLVENT IN YOUR MOUTH, EYES, OR ON YOUR SKIN. DO NOT BREATHE IN THE FUMES FROM THE SOLVENT. PUT ON PROTECTIVE SPLASH GOGGLES AND GLOVES WHEN YOU USE THE SOLVENT. KEEP THE SOLVENT AWAY FROM SPARKS, FLAME, AND HEAT. THE SOLVENT IS POISONOUS AND FLAMMABLE, WHICH CAN CAUSE INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT.

<1> Remove the oil from the collected particles with solvent, B00682 [CP2011], or White Spirit, B50295 [CP2010].

SIA ALL



- <2> Keep the material collected from each scavenge screen separately with the following information attached: ESN, TSC/CSN, source of particles (sump), and removal date.
- 3) Clean the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] with solvent, B00682 [CP2011].
- 4) Make sure that single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] are free of all particles
- 5) Dry the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9] with a 0-30 psig dry filtered regulated air source, STD-1280.
- 6) Install the single stage scavenge screen plug [2], single stage scavenge screen plug [4], double stage scavenge screen plug [6], and double stage scavenge screen plug [9], do this task: Scavenge Screen Plugs Installation, TASK 79-21-04-400-801-G00.



DO NOT GET THE SOLVENT IN YOUR MOUTH, EYES, OR ON YOUR SKIN. DO NOT BREATHE IN THE FUMES FROM THE SOLVENT. PUT ON PROTECTIVE SPLASH GOGGLES AND GLOVES WHEN YOU USE THE SOLVENT. KEEP THE SOLVENT AWAY FROM SPARKS, FLAME, AND HEAT. THE SOLVENT IS POISONOUS AND FLAMMABLE, WHICH CAN CAUSE INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT.

7) Do the analysis of the particles, do this task: Engine Oil System (Oil Debris Monitoring System Sensor (ODMS), Scavenge Screen Plugs, Starter Magnetic Plug, and Oil Filter) Detailed Dimensional Check, TASK 79-00-00-220-801-G00.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-04-860-011-G00

- (1) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location		
413	Left Fan Cowl, Engine 1		
423	Left Fan Cowl. Engine 2		

SUBTASK 79-21-04-860-012-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Scavenge Screen Plug Test


SUBTASK 79-21-04-710-002-G00

(1) Do the applicable tests given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

END	\cap E	TΛ	C L	

SIA ALL






Scavenge Screen Plug Inspection Figure 203/79-21-04-990-802-G00 (Sheet 1 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007








ICNLEAP1B792104D5882800005A00201 2897778 S0000691373_V3

Scavenge Screen Plug Inspection Figure 203/79-21-04-990-802-G00 (Sheet 2 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007






ICNLEAP1B792104D5882800006A00101 2897779 S0000691374_V3

Scavenge Screen Plug Inspection Figure 203/79-21-04-990-802-G00 (Sheet 3 of 3)

SIA ALL; PRE LEAP-1B SERVICE BULLETIN SB 79-0007






Scavenge Screen Plug Inspection Figure 204/79-21-04-990-807-G00 (Sheet 1 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007






ICNLEAP1B792104D5882800010A00101

2979251 S0000757355_V1

Scavenge Screen Plug Inspection Figure 204/79-21-04-990-807-G00 (Sheet 2 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007





ICNLEAP1B792104D5882800011A00101

2979255 S0000757359_V1

Scavenge Screen Plug Inspection Figure 204/79-21-04-990-807-G00 (Sheet 3 of 3)

SIA ALL; AIRPLANES WITH POST LEAP-1B SERVICE BULLETIN SB 79-0007

79-21-04


Page 226 Sep 15/2021






[9] DOUBLE STAGE SCAVENGE SCREEN PLUG





CUT PIECE OF O-RING

[15] O-RING



[6] DOUBLE STAGE SCAVENGE SCREEN PLUG

DOUBLE STAGE SCAVENGE PLUGS WITH CUT O-RING (EXAMPLE GRAPHIC)

658430

2898960 S0000691671_V2

Scavenge Screen Plug Inspection Figure 205/79-21-04-990-808-G00

SIA ALL



OIL FILTER CARTRIDGE ELEMENT - REMOVAL/INSTALLATION

1. General

- A. This procedure has these tasks:
 - (1) A removal of the oil filter cartridge element
 - (2) An installation of the oil filter cartridge element.

TASK 79-21-07-000-801-G00

2. Oil Filter Cartridge Element Removal

(Figure 401)

A. General

(1) This task gives the instructions on how to remove the oil filter cartridge element.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
79-21-03-000-801-G00	Lubrication Unit Removal (P/B 401)
79-21-03-400-801-G00	Lubrication Unit Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-199	Container - 2 U.S. Gallon (7.6 I) (oil resistant)	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
3	Preformed packing	79-21-07-01-020	SIA ALL

F. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

H. Prepare for the Removal

SUBTASK 79-21-07-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.

SIA ALL



- (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-07-860-002-G00

- (2) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

I. Oil Filter Cartridge Element Removal

SUBTASK 79-21-07-020-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the oil filter cartridge element [4] as follows:
 - (a) Put a container, STD-199, below the lubrication unit lube and scavenge pump [1].
 - (b) Drain the oil from the lubrication unit lube and scavenge pump [1] as follows:
 - 1) Cut the safety cable [11] from the drain plug [2].
 - 2) Remove the drain plug [2] from the lubrication unit lube and scavenge pump [1] as follows:
 - Remove the drain plug [2] from the lubrication unit lube and scavenge pump [1].
 - b) Remove and discard the preformed packing [3] from the groove of the drain plug [2].
 - c) Let the oil drain into the container, STD-199.

79-21-07

SIA ALL

D633AM101-SIA



- (c) Install the drain plug [2] on the lubrication unit lube and scavenge pump [1] as follows:
 - 1) Make sure that the mating faces are clean and clear of unwanted materials.
 - 2) Lubricate the threads of the drain plug [2] and the new preformed packing [3] with engine oil, D00599 [CP2442].
 - 3) Install the new preformed packing [3] onto the groove of the drain plug [2].
 - 4) Install the drain plug [2] in a correct position on the lubrication unit lube and scavenge pump [1].
 - 5) Tighten the drain plug [2] to 67.2 in-lb (7.6 N·m) 74.3 in-lb (8.4 N·m).
 - NOTE: Safety cable will be installed after the installation of the oil filter cartridge cover.
- (d) Cut the safety cable [6] from the filter drain plug [5].
- (e) Loosen the filter drain plug [5] from the oil filter cartridge cover [8].
- (f) Remove the two bolts [9], two bolts [13], and two nuts [14] that attach the oil filter cartridge cover [8] to the lubrication unit lube and scavenge pump [1].
- (g) Remove the oil filter cartridge cover [8] and oil filter cartridge element [4] from the lubrication unit lube and scavenge pump [1].
- (h) Remove the oil filter cartridge element [4] from the oil filter cartridge cover [8] as follows:
 - 1) Remove the filter drain plug [5] from the oil filter cartridge cover [8].
 - 2) Remove and discard the preformed packing [7] from the groove of the filter drain plug [5].
 - 3) Remove and discard the oil filter cartridge element [4] from the oil filter cartridge cover [8].
- (i) Remove and discard the preformed packing [10] from the groove of the oil filter cartridge cover [8].
- (j) Inspect the two inserts on the housing at the oil filter cartridge cover [8] location for indications such as insert pulled out, insert movement, impacted thread insert.
 - 1) If any, replace the lubrication unit lube and scavenge pump [1]:
 - Lubrication Unit Removal, TASK 79-21-03-000-801-G00
 - Lubrication Unit Installation, TASK 79-21-03-400-801-G00.
- (k) Inspect the oil filter cartridge cover [8] flange in contact with the lubrication unit lube and scavenge pump [1].
 - 1) If there is any marks on the oil filter cartridge cover [8] at the location of the two inserts on the housing, replace the lubrication unit lube and scavenge pump [1] (Figure 401):
 - Lubrication Unit Removal, TASK 79-21-03-000-801-G00
 - Lubrication Unit Installation, TASK 79-21-03-400-801-G00.
- (I) Install the protective cover on the lubrication unit lube and scavenge pump [1].


 ENID	OE	TASK	
	OI.	IASK	

SIA ALL

79-21-07

D633AM101-SIA





Oil Filter Cartridge Element Installation Figure 401/79-21-07-990-801-G00 (Sheet 1 of 2)


EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details





Oil Filter Cartridge Element Installation Figure 401/79-21-07-990-801-G00 (Sheet 2 of 2)

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-07

Page 405 May 15/2023



TASK 79-21-07-400-801-G00

3. Oil Filter Cartridge Element Installation

(Figure 401)

A. General

(1) This task provides the instructions on how to install the oil filter cartridge element.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236
G50065 [CP8006]	Cable, Safety, Stainless Steel, 0.032 inch (0.8 mm) Diameter	M50 TF 9 CL-A
G50375	Kit - Safety Cable, 321 CRES - 0.032 Inch (0.81 mm) Diameter, (Contains both Cable and Ferrule)	BACC13AT3K, AMS 5689

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
4	Oil filter cartridge element	79-21-07-01-100	SIAALL
7	Preformed packing	79-21-07-01-040	SIA ALL
10	Preformed packing	79-21-07-01-090	SIA ALL
12	Preformed packing	79-21-07-01-110	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

H. Oil Filter Cartridge Element Installation

SUBTASK 79-21-07-420-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Install the oil filter cartridge element [4] as follows:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective cover from the lubrication unit lube and scavenge pump [1].
 - (c) Lubricate the threads of the filter drain plug [5], bolts [9], bolts [13], and nuts [14] with graphite mineral vaseline, D00601 [CP2101].
 - (d) Lubricate the new preformed packing [7] and new preformed packing [10] with pure mineral vaseline, D00672 [CP5070].
 - (e) Install the preformed packing [10] into the groove of the oil filter cartridge cover [8].
 - (f) Install the new preformed packing [12] into the groove of the new oil filter cartridge element [4].
 - (g) Install the oil filter cartridge element [4] on the oil filter cartridge cover [8] as follows:
 - 1) Install the preformed packing [7] into the groove of the filter drain plug [5].
 - 2) Put the oil filter cartridge element [4] in position on the oil filter cartridge cover [8].
 - 3) Install the filter drain plug [5] on the oil filter cartridge cover [8].
 - 4) Tighten the filter drain plug [5] to 67.2 in-lb (7.6 N·m) 74.3 in-lb (8.4 N·m).
 - (h) Install the oil filter cartridge cover [8] and oil filter cartridge element [4] on the lubrication unit lube and scavenge pump [1].
 - (i) Install the bolts [9], bolts [13], and nuts [14] that attach the oil filter cartridge cover [8] to the lubrication unit lube and scavenge pump [1].



YOU MUST APPLY THE TORQUE SPECIFIED FOR BOLTS AND NUTS. IF YOU DO NOT OBEY, AN OIL LEAK CAN OCCUR. THE LEAK CAN CAUSE AN IN-FLIGHT SHUT DOWN (IFSD).

- (j) Tighten the bolts [9] and nuts [14] to 67.2 in-lb (7.6 N·m) 74.3 in-lb (8.4 N·m).
- (k) Install a 0.032 in. (0.813 mm) safety cable [11] from safety cable kit, G50375, or cable, G50065 [CP8006], on the drain plug [2].
 - NOTE: The safety cable is anchored on the oil filter cartridge cover.
- (I) Install a 0.032 in. (0.813 mm) safety cable [6] from safety cable kit, G50375, or cable, G50065 [CP8006], on the filter drain plug [5].
- (m) Clean the work area and clear the tools you used to do the task.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-07-860-003-G00

- (1) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

SIA ALL

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

SUBTASK 79-21-07-860-004-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Oil Filter Cartridge Element Installation Test

SUBTASK 79-21-07-710-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

——— END OF TASK ———

SIA ALL 79-21-07



OIL FILTER CARTRIDGE ELEMENT- INSPECTION/CHECK

1. General

- A. This procedure has this task:
 - (1) Oil Filter Cartridge Element Inspection.

TASK 79-21-07-200-801-G00

2. Oil Filter Cartridge Element Inspection

A. General

(1) This task gives the instructions to do the inspection of the oil filter cartridge element.

B. References

Reference	Title
79-21-04-211-801-G00	Scavenge Screen Plug Inspection (P/B 201)
79-21-07-000-801-G00	Oil Filter Cartridge Element Removal (P/B 401)
79-21-07-400-801-G00	Oil Filter Cartridge Element Installation (P/B 401)

C. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

D. Oil Filter Cartridge Element Inspection

SUBTASK 79-21-07-210-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Do the inspection of oil filter cartridge element:
 - (a) Do this task: Oil Filter Cartridge Element Removal, TASK 79-21-07-000-801-G00.

SIA ALL



- (b) Examine the lubrication unit inner wall of the oil filter housing for contaminants or debris.
 - 1) If you find any contaminants or debris, do a visual inspection of the scavenge screen plug for debris (TASK 79-21-04-211-801-G00).
- (c) Examine the removed oil filter element as follows:
 - Take the filter element in both hands and put two pleats apart to show the contaminants at the bottom of these pleats. Do this at several locations around the cartridge.
 - 2) If you find any contaminants or debris, do a visual inspection of the scavenge screen plug for debris (TASK 79-21-04-211-801-G00).
- (d) If an oil filter impending or Actual By-Pass Faults is triggered on the engine, place oil filter on hold.
 - 1) Do not discard the oil filter.
 - NOTE: It could be requested for investigation by CFM.
- (e) Install a new oil filter cartridge element, do this task: Oil Filter Cartridge Element Installation, TASK 79-21-07-400-801-G00.

----- END OF TASK -----

SIA ALL 79-21-07



OIL DEBRIS MONITORING SYSTEM SENSOR - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil debris monitoring system sensor removal
 - (2) Oil debris monitoring system sensor installation.

TASK 79-21-12-000-801-G00

2. Oil Debris Monitoring System Sensor Removal

(Figure 401)

A. General

(1) This task gives the instructions to remove the Oil Debris Monitoring System (ODMS) sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl. Engine 2

F. Prepare for the Removal

SUBTASK 79-21-12-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-12-010-001-G00

(2) On the applicable engine, open the right fan cowl panel (TASK 71-11-04-010-801-G00).

SIA ALL



(a) Open these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

G. Oil Debris Monitoring System Sensor Removal

SUBTASK 79-21-12-010-002-G00



DO NOT TOUCH THE COMPONENTS OF THE OIL SYSTEM IF THE ENGINE IS HOT. THESE COMPONENTS STAY HOTTER THAN OTHER COMPONENTS. HOT COMPONENTS CAN BURN YOU.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the ODMS sensor [1] as follows:
 - (a) Remove the two nuts [9] from the two bolts [6] that attach the ODMS sensor [1] to the air/oil separator [8].

NOTE: The bolts [6] are captive to the ODMS sensor.

(b) Remove the ODMS sensor [1] from the air/oil separator [8].



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.




USE TEFLON-JAWED PLIERS TO LOOSEN ELECTRICAL CONNECTORS. DO NOT USE METAL-JAWED PLIERS. DAMAGE TO THE ELECTRICAL CONNECTORS COULD OCCUR.

- (c) Use a teflon-jawed pliers, STD-664 to disconnect the electrical connector [4] from oil debris monitoring unit [3] (TASK 70-00-01-910-803-G00).
- (d) Remove and discard the preformed packing [7] from the ODMS sensor [1].
- (e) Remove the ODMS sensor [1] and the ODMS sensor harness [2] from the four clips [5].
- (f) Install protective covers on the ODMS sensor [1] and the air/oil separator [8].

----- END OF TASK -----

EFFECTIVITY
SIA ALL





2355361 S00061517106_V2


Oil Debris Monitoring System (ODMS) Sensor Installation Figure 401/79-21-12-990-801-G00 (Sheet 1 of 2)

ECCN 9E991 BOEING PROPRIETARY - See title page for details

SIA ALL

D633AM101-SIA





Oil Debris Monitoring System (ODMS) Sensor Installation Figure 401/79-21-12-990-801-G00 (Sheet 2 of 2)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-12

Page 404 Sep 15/2021



TASK 79-21-12-400-801-G00

3. Oil Debris Monitoring System Sensor Installation

(Figure 401)

A. General

(1) This task gives the instructions to install the Oil Debris Monitoring System (ODMS) sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	ODMS sensor	79-21-12-01-030	SIA ALL
7	Preformed packing	79-21-12-01-020	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

H. Oil Debris Monitoring System Sensor Installation

SUBTASK 79-21-12-410-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Install the ODMS sensor [1] as follows:
 - (a) Remove the protective covers from the ODMS sensor [1] and the air/oil separator [8].

SIA ALL



- b) Make sure that the mating surfaces are clean and clear of unwanted materials.
- (c) Lubricate the threads of the two nuts [9] with engine oil, D00599 [CP2442].
- (d) Lubricate the new preformed packing [7] with mineral vaseline, D00672 [CP5070].
- (e) Install the new preformed packing [7] on the ODMS sensor [1].
- (f) Install the ODMS sensor [1] on the air/oil separator [8] with the two bolts [6] and nuts [9].
- (g) Tighten the nuts [9] to 100.7 in-lb (11.4 N·m) 111.3 in-lb (12.6 N·m).
- (h) Install the ODMS sensor harness [2] on the four clips [5].



MAKE SURE THAT THE ELECTRICAL CONNECTOR AND RECEPTACLE ARE CLEAN WHEN YOU CONNECT THEM. DIRTY CONNECTORS CAN CAUSE DAMAGE TO EQUIPMENT.



DO NOT USE PLIERS THAT HAVE METAL JAWS TO TIGHTEN THE ELECTRICAL CONNECTOR. DAMAGE TO THE ELECTRICAL CONNECTOR CAN OCCUR.

(i) Use a teflon-jawed pliers, STD-664 to connect the electrical connector [4] to the oil debris monitoring unit [3] (TASK 70-00-01-910-803-G00).

SUBTASK 79-21-12-160-001-G00

(2) Clean the work area and clear the tools used to do the task.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-12-410-002-G00

- (1) On the applicable engine, close the right fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl. Engine 2

SUBTASK 79-21-12-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Oil Debris Monitoring System Sensor Installation Test

SUBTASK 79-21-12-710-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

FND	$\Delta E T$		
	.,	4.30	

79-21-12

SIA ALL

· EFFECTIVITY



OIL DEBRIS MONITORING SYSTEM UNIT - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil debris monitoring system unit removal
 - (2) Oil debris monitoring system unit installation.

TASK 79-21-14-000-801-G00

2. Oil Debris Monitoring System Unit Removal

(Figure 401)

A. General

- (1) This task provides the instructions on how to remove the oil debris monitoring system unit.
- (2) The oil debris monitoring system unit is referred to as the ODMS unit.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location	
414	Right Fan Cowl, Engine 1	
424	Right Fan Cowl. Engine 2	

F. Prepare for the Removal

SUBTASK 79-21-14-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-14-860-002-G00

(2) On the applicable engine, open the right fan cowl panel (TASK 71-11-04-010-801-G00).

SIA ALL



(a) Open these access panels:

<u>number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

G. Oil Debris Monitoring System Unit Removal

SUBTASK 79-21-14-020-001-G00

(1) Remove the ODMS unit [1] as follows:



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.




USE TEFLON-JAWED PLIERS TO LOOSEN ELECTRICAL CONNECTORS. DO NOT USE METAL-JAWED PLIERS. DAMAGE TO THE ELECTRICAL CONNECTORS COULD OCCUR.


- (a) Use the teflon-jawed pliers, STD-664 to disconnect the electrical connector [2] and the electrical connector HJ6B [3] from the ODMS unit [1] as follows (TASK 70-00-01-910-803-G00):
 - 1) Disconnect the oil debris monitoring system sensor electrical connector [2] from the ODMS unit [1].
 - 2) Disconnect the electrical connector HJ6B [3] from the ODMS unit [1].
 - 3) Install the protective covers on the electrical connector [2], the electrical connector HJ6B [3], and the electrical receptacles on the ODMS unit [1].
- (b) Remove the four bolts [4] from the ODMS unit [1].
- (c) Remove the ODMS unit [1] from the mounting bracket [5]

----- END OF TASK -----

SIA ALL








2355364 S00061517117_V1

Oil Debris Monitoring System Unit Installation Figure 401/79-21-14-990-801-G00 (Sheet 1 of 2)

SIA ALL





2439098 S0000565060_V1

Oil Debris Monitoring System Unit Installation Figure 401/79-21-14-990-801-G00 (Sheet 2 of 2)

SIA ALL
D633AM101-SIA



TASK 79-21-14-400-801-G00

3. Oil Debris Monitoring System Unit Installation

(Figure 401)

A. General

- (1) This task provides the instructions on how to install the oil debris monitoring system unit.
- (2) The oil debris monitoring system unit is referred to as the ODMS unit.
- (3) You must do the tests that are listed in the power plant test reference table after you install the ODMS unit.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	ODMS unit	79-21-14-01-020	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

H. Oil Debris Monitoring System Unit Installation

SUBTASK 79-21-14-420-001-G00

- (1) Install the ODMS unit [1] as follows:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Lubricate the threads of the four bolts [4] with the engine oil, D00599 [CP2442].
 - (c) Install the ODMS unit [1] in a correct position on the mounting bracket [5].
 - (d) Install the four bolts [4] that attach the ODMS unit [1] on the mounting bracket [5].
 - (e) Tighten the bolts [4] to 67.45 in-lb (7.6 N·m) 74.55 in-lb (8.4 N·m).

SIA ALL





MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.



USE PLIERS THAT HAVE TEFLON JAWS TO TIGHTEN THE ELECTRICAL CONNECTORS. DO NOT USE PLIERS THAT HAVE METAL JAWS. METAL JAWS CAN CAUSE DAMAGE TO THE ELECTRICAL CONNECTORS.

- (f) Use the teflon-jawed pliers, STD-664 to connect the electrical connector [2] and the electrical connector HJ6B [3] to the ODMS unit [1] as follows (TASK 70-00-01-910-803-G00):
 - 1) Remove the protective covers from the electrical connector [2], the electrical connector HJ6B [3], and the electrical receptacles on the ODMS unit [1].
 - Connect the oil debris monitoring system sensor electrical connector [2] to the ODMS unit [1].
 - 3) Connect the electrical connector HJ6B [3] to the ODMS unit [1].
 - 4) Tighten the electrical connector [2] and the electrical connector HJ6B [3].
- (g) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-14-860-005-G00

- (1) On the applicable engine, close the right fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

SUBTASK 79-21-14-860-004-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Oil Debris Monitoring System Unit Installation Test

SUBTASK 79-21-14-710-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

	END	OF	TASK	
--	------------	----	-------------	--

SIA ALL 79-21-14



OIL EDUCTOR VALVE - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil eductor valve removal
 - (2) Oil eductor valve installation.

TASK 79-21-17-000-801-G00

2. Oil Eductor Valve Removal

(Figure 401 and Figure 402)

A. General

- (1) This task gives the instructions on how to remove the oil eductor valve.
- (2) The oil eductor valve is installed at the 7:00 o'clock position on the turbine center frame.
- (3) You must open the left thrust reverser to get access to the oil educator valve.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description	
SPL-14947	Protector - SACOC	
	Part #: 956A8681G02 Supplier: 58828	

D. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

F. Prepare for the Removal

SUBTASK 79-21-17-010-001-G00

(1) Do these tasks in sequence to safely open the left thrust reverser on the applicable engine:

SIA ALL





DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left fan cowl panel (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left thrust reverser (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

SUBTASK 79-21-17-480-001-G00

(2) Install the protector, SPL-14947 on the engine oil coolers.

G. Oil Eductor Valve Removal



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL 79-21-17



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.



MAKE SURE THAT YOU INSTALL THE SACOC PROTECTOR TO PREVENT DAMAGE TO THE OIL COOLER.

SUBTASK 79-21-17-020-001-G00

(1) Disconnect the eductor air tube [3] B-nut from the oil eductor valve [5].

SUBTASK 79-21-17-020-002-G00

(2) Disconnect the eductor air tube [1] B-nut from the oil eductor valve [5].

SUBTASK 79-21-17-020-003-G00

(3) Remove the three bolts [4] that attach the oil eductor valve [5] to the eductor valve support bracket [2].

SUBTASK 79-21-17-020-004-G00

(4) Remove the oil eductor valve [5] from the engine.


SUBTASK 79-21-17-020-005-G00

(5) Install the protective covers on the eductor air tube [3], the eductor air tube [1], and the oil eductor valve [5].

——— END OF TASK ———

SIA ALL 79-21-17





Oil Eductor Valve Installation Figure 401/79-21-17-990-801-G00

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-17

Page 404 Sep 15/2021





2834961 S0000659770_V1

SACOC Protector Installation Figure 402/79-21-17-990-802-G00

SIA ALL

79-21-17

ECCN 9E991 BOEING PROPRIETARY - See title page for details



TASK 79-21-17-400-801-G00

3. Oil Eductor Valve Installation

(Figure 401 and Figure 402)

A. General

- (1) This task provides the instructions on how to install the oil eductor valve.
- (2) You must do the tests that are listed in the power plant test reference table after you install the oil eductor valve.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description	
SPL-14947	Protector - SACOC	
	Part #: 956A8681G02	Supplier: 58828

D. Consumable Materials

Reference	Description	Specification
D00599 [CP2442]	Oil - Engine	

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity	
5	Oil eductor valve	79-21-17-01-020	SIA ALL	

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Left Fan Cowl, Engine 1
AAE LAGETLAND DAMAGE ENTRE A
415 Left Thrust Reverser, Engine 1
423 Left Fan Cowl, Engine 2
425 Left Thrust Reverser, Engine 2

H. Oil Eductor Valve Installation

SUBTASK 79-21-17-420-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.

SIA ALL



(WARNING PRECEDES)



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(1) Remove the protective covers from the eductor air tube [3], the eductor air tube [1], and the oil eductor valve [5].

SUBTASK 79-21-17-420-002-G00

(2) Put the oil eductor valve [5] in position on the eductor valve support bracket [2].

SUBTASK 79-21-17-410-001-G00

(3) Put a light coat of the oil, D00599 [CP2442] on the threads of the three bolts [4].

SUBTASK 79-21-17-420-003-G00

- (4) Install the three bolts [4] that attach the oil eductor valve [5] to the eductor valve support bracket [2].
 - (a) Tighten the three bolts [4] to 106 in-lb (12 N·m) 124 in-lb (14 N·m).

SUBTASK 79-21-17-420-004-G00

- (5) Connect the eductor air tube [1] B-nut to the oil eductor valve [5].
 - (a) Tighten the eductor air tube [1] B-nut to 460 in-lb (52 N·m) 540 in-lb (61 N·m).

SUBTASK 79-21-17-420-005-G00

- (6) Connect the eductor air tube [3] B-nut to the oil eductor valve [5].
 - (a) Tighten the eductor air tube [3] B-nut to 450 in-lb (51 N·m) 550 in-lb (62 N·m).

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-17-080-001-G00

(1) Remove the protector, SPL-14947 from the engine.

SUBTASK 79-21-17-410-002-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

(2) Do these tasks in sequence to safely close the left thrust reverser:

SIA ALL



- (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

- (b) Close the applicable left Fan Cowl Panel (TASK 71-11-04-410-801-G00).
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

- (c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.
- J. Oil Eductor Valve Installation Test

SUBTASK 79-21-17-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

----- END OF TASK -----

SIA ALL 79-21-17



AIR OIL SEPARATOR - REMOVAL/INSTALLATION

1. General

- A. This procedure has these tasks:
 - (1) A removal of the air oil separator
 - (2) An installation of the air oil separator.

TASK 79-21-21-000-801-G00

2. Air Oil Separator Removal

(Figure 401)

A. General

(1) This task provides the instructions on how to remove the air oil separator.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
79-21-12-000-801-G00	Oil Debris Monitoring System Sensor Removal (P/B 401)

C. Tools/Equipment

Reference	Description
STD-858	Tag - DO NOT OPERATE
STD-1055	Container - Oil Resistant, 5 Gallon (19 Liter)

D. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

E. Prepare for the Removal

SUBTASK 79-21-21-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-21-21-010-001-G00

- (2) On the applicable engine, open the right fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

SIA ALL



F. Air Oil Separator Removal

SUBTASK 79-21-21-010-002-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



I

DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the air oil separator [1] as follows:
 - (a) Put an oil resistant container (5 gal)(19 Liter), STD-1055, below all the tube openings and air oil separator [1].
 - (b) Remove the oil debris monitoring system sensor [3] (TASK 79-21-12-000-801-G00).
 - (c) Disconnect the oil tube [4] from the air oil separator [1] as follows:
 - Remove the bolt [5] from the clamp [6] that attaches the oil tube [4] to the bracket [7].
 - 2) Remove the bolt [8] from the clamp [9] that attaches the oil tube [4] to the bracket [10].
 - 3) Remove the four bolts [11] from the oil tube [4].
 - a) Do not move the flange [16] of the check valve air oil separator [1].
 - 4) Disconnect the oil tube [4] from the air oil separator [1].
 - 5) Remove and discard the gasket seal [12] from the oil tube [4].
 - 6) Install the protective caps on the openings.
 - (d) Disconnect the oil tube [13] from the air oil separator [1]:
 - 1) Remove the four bolts [14] from the oil tube [13].
 - 2) Disconnect the oil tube [13] from the air oil separator [1].
 - 3) Remove and discard the gasket seal [15] from the oil tube [13].
 - 4) Install the protective caps on the openings.
 - (e) Remove the six bolts [17] from the air oil separator [1].

SIA ALL

LEAP-1B ENGINES




737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

- (f) Remove the air oil separator [1] from the oil tank [2].
- (g) Remove and discard the preformed packing [18] from the air oil separator [1].
- (h) Install the protective caps on the openings.

----- END OF TASK -----

SIA ALL





Air Oil Separator Installation Figure 401/79-21-21-990-801-G00 (Sheet 1 of 5)


SIA ALL


D633AM101-SIA

79-21-21

Page 404 May 15/2023







Air Oil Separator Installation Figure 401/79-21-21-990-801-G00 (Sheet 2 of 5)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-21

Page 405 May 15/2023





A0003-A-001-01 2403559 S0000555941_V3

Air Oil Separator Installation Figure 401/79-21-21-990-801-G00 (Sheet 3 of 5)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-21-21

Page 406 May 15/2023





A0004-A-001-01 2403561 S0000555942_V2


Air Oil Separator Installation Figure 401/79-21-21-990-801-G00 (Sheet 4 of 5)

SIA ALL PRE SB 737-CFM-LEAP-1B-79-0012

79-21-21

Page 407 May 15/2023





A0004-A-001-01 3023009 S0000795313_V1

Air Oil Separator Installation Figure 401/79-21-21-990-801-G00 (Sheet 5 of 5)

SIA ALL POST SB 737-CFM-LEAP-1B-79-0012

79-21-21

Page 408 May 15/2023



TASK 79-21-21-400-801-G00

3. Air Oil Separator Installation

(Figure 401)

A. General

(1) This task gives the instructions on how to install the air oil separator.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
79-21-12-400-801-G00	Oil Debris Monitoring System Sensor Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	Air oil separator	79-21-21-01-120	SIA ALL
12	Gasket seal	79-21-21-01-080	SIAALL
15	Gasket seal	79-21-21-01-100	SIAALL
18	Preformed packing	79-21-21-01-130	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

H. Air Oil Separator Installation

SUBTASK 79-21-21-410-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

SIA ALL



(CAUTION PRECEDES)

ı

П

I



MAKE SURE THAT YOU INSTALL THE CORRECT BOLT LENGTH WHEN YOU INSTALL THE POST SB 737-CFM-LEAP-1B-79-0012 AIR OIL SEPARATOR. IF YOU DO NOT OBEY, DAMAGE TO EQUIPMENT CAN OCCUR.

- Install the air oil separator [1]:
 - (a) Remove the protective covers from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Lubricate the threads of the six bolts [17] with graphite mineral vaseline, D00601 [CP2101].
 - (d) Lubricate the new preformed packing [18] with the mineral vaseline, D00672 [CP5070].
 - (e) Install the preformed packing [18] on the groove of the air oil separator [1].
 - (f) Install the air oil separator [1] on the oil tank [2].
 - (g) Install the six bolts [17] on the air oil separator [1].
 - (h) Connect the oil tube [13] to the air oil separator [1]:
 - 1) Remove the protective covers from the openings.
 - 2) Make sure that the mating faces are clean and clear of unwanted materials.
 - 3) Lubricate the threads of the four bolts [14] with graphite mineral vaseline, D00601 [CP2101].
 - 4) Install the new gasket seal [15] and oil tube [13] on the air oil separator [1].
 - 5) Install the four bolts [14] that attach the oil tube [13] to the air oil separator [1].
 - (i) Connect the oil tube [4] to the air oil separator [1]:
 - 1) Do not move the flange [16] of the check valve air oil separator [1].
 - 2) Remove the protective covers from the openings.
 - 3) Make sure that the mating faces are clean and clear of unwanted materials.
 - 4) Lubricate the threads of the four bolts [11] with graphite mineral vaseline, D00601 [CP2101].
 - 5) Install the new gasket seal [12] and oil tube [4] in a correct position on the air oil separator [1].
 - 6) Install the four bolts [11] that attach the oil tube [4] to the air oil separator [1].
 - 7) Install the bolt [8] on the clamp [9] that attaches the oil tube [4] on the bracket [10].
 - 8) Install the bolt [5] on the clamp [6] that attaches the oil tube [4] on the bracket [7].
 - (j) Tighten the bolts [17] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - (k) Tighten the bolts [14] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - (I) Tighten the bolts [11] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).
 - (m) Tighten the bolt [8] to 42.0 in-lb (4.75 N·m) 46.5 in-lb (5.25 N·m).
 - (n) Tighten the bolt [5] to 42.0 in-lb (4.75 N·m) 46.5 in-lb (5.25 N·m).
 - (o) Install the oil debris monitoring system sensor [3] (TASK 79-21-12-400-801-G00).
 - (p) Clean the work area and clear the tools used to do the task.

SIA ALL



I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-21-860-002-G00

- (1) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SUBTASK 79-21-21-410-002-G00

- (2) On the applicable engine, close the right fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

J. Air Oil Separator Installation Test

SUBTASK 79-21-21-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

----- END OF TASK -----

SIA ALL 79-21-21



ANTI LEAK VALVE - REMOVAL/INSTALLATION

1. General

- A. This procedure has these tasks:
 - (1) A removal of the anti leak valve
 - (2) An installation of the anti leak valve.

TASK 79-21-22-000-801-G00

2. Anti Leak Valve Removal

(Figure 401)

A. General

(1) This task gives the instructions to remove the anti leak valve.

B. References

Reference	Title
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
79-21-03-000-801-G00	Lubrication Unit Removal (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

F. Prepare for the Removal

SUBTASK 79-21-22-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SIA ALL



SUBTASK 79-21-22-010-001-G00

(2) Do these tasks in sequence to safely open the left thrust reverser on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left fan cowl panel (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left thrust reverser (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

G. Anti Leak Valve Removal

SUBTASK 79-21-22-020-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE IS STOPPED. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

(1) Do this task: Lubrication Unit Removal, TASK 79-21-03-000-801-G00.


SUBTASK 79-21-22-020-002-G00

- (2) Remove the anti leak valve [1] as follows:
 - (a) Insert a screwdriver or a dental pick into the removal notch of the retaining ring [2].
 - (b) Use the screwdriver or the dental pick to pull out the first end of the retaining ring [2].
 - (c) Manually twist the retaining ring [2] around until it is released from the groove of the lubrication unit [3].
 - (d) Discard the retaining ring [2].
 - (e) Remove the anti leak valve [1] equipped with its O-ring from the lubrication unit [3].
 - (f) Discard the anti leak valve [1] equipped with its O-ring.
 - (g) Install the protective covers on the openings.

——— END OF TASK ———

SIA ALL





Anti Leak Valve Installation Figure 401/79-21-22-990-801-G00

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



TASK 79-21-22-400-801-G00

3. Anti Leak Valve Installation

(Figure 401)

A. General

(1) This task gives the instructions to install the anti leak valve.

B. References

Reference	Title
12-13-11-600-801	Engine Servicing (Oil Replenishing) (P/B 301)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
72-63-01-610-802-G00	Accessory Gearbox Assembly Oil Replenishing (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)
79-21-03-400-801-G00	Lubrication Unit Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity	
1	Anti leak valve	79-21-03-01-370	SIA ALL	
2	Retaining ring	79-21-03-01-365	SIA ALL	

F. Location Zones

Zone	Area	
411	Engine 1 - Engine	
421	Engine 2 - Engine	

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
415	Left Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2

H. Anti Leak Valve Installation

SUBTASK 79-21-22-410-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL



(WARNING PRECEDES)



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO PAINT AND RUBBER.

- (1) Install the anti leak valve [1] as follows:
 - (a) Make sure that the mating faces are clean and clear of unwanted materials.
 - (b) Remove the protective covers on the openings.



MAKE SURE THAT THE O-RING IS INSTALLED ON THE NEW ANTI LEAK VALVE. IF YOU DO NOT OBEY, DAMAGE TO THE ANTI LEAK VALVE CAN OCCUR.

- (c) Lubricate the O-ring of a new anti leak valve [1] with vaseline, D00672 [CP5070].
- (d) Install the anti leak valve [1] equipped with its O-ring to the lubrication unit [3].
- (e) Install the new retaining ring [2] on the groove of the lubrication unit [3].

SUBTASK 79-21-22-400-001-G00

(2) Do this task: Lubrication Unit Installation, TASK 79-21-03-400-801-G00.

SUBTASK 79-21-22-610-001-G00

(3) Do this task: Accessory Gearbox Assembly Oil Replenishing, TASK 72-63-01-610-802-G00.

SUBTASK 79-21-22-600-001-G00

(4) Do this task: Engine Servicing (Oil Replenishing), TASK 12-13-11-600-801.

SUBTASK 79-21-22-420-001-G00

(5) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-21-22-410-002-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the left thrust reverser:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2

- (b) Close the applicable left Fan Cowl Panel (TASK 71-11-04-410-801-G00).
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

EFFECTIVITY -

79-21-22

Page 406 May 15/2022

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

SUBTASK 79-21-22-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

J. Lubrication Unit Installation Test

SUBTASK 79-21-22-730-002-G00

(1) Do the applicable tests given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

——— END OF TASK ———

SIA ALL



OIL INDICATING SYSTEM - INSPECTION/CHECK

1. General

- A. This procedure contains this task:
 - (1) Oil indicating system inspection.

TASK 79-30-00-210-801-G00

2. Oil Indicating System Inspection

(Figure 601)

A. General

- (1) This task gives the instructions on how to examine the oil indicating system.
- (2) The oil indicating system inspection examines these components:
 - (a) Oil level sensor
 - (b) Oil pressure and temperature sensor
 - (c) Oil Filter Differential Pressure (OFDP) sensor.

B. References

Reference	Title
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)
78-31-00-010-801-G00	Open the Thrust Reverser (Selection) (P/B 201)
78-31-00-010-802-G00	Close the Thrust Reverser (Selection) (P/B 201)
78-31-00-040-801-G00	Thrust Reverser Deactivation For Ground Maintenance (P/B 201)
78-31-00-440-801-G00	Thrust Reverser Activation After Ground Maintenance (P/B 201)
79-31-01-000-801-G00	Oil Level Sensor Removal (P/B 401)
79-31-01-400-801-G00	Oil Level Sensor Installation (P/B 401)
79-32-01-000-801-G00	Oil Pressure and Temperature Sensor Removal (P/B 401)
79-32-01-400-801-G00	Oil Pressure and Temperature Sensor Installation (P/B 401)
79-35-01-000-801-G00	Oil Filter Differential Pressure Sensor Removal (P/B 401)
79-35-01-400-801-G00	Oil Filter Differential Pressure Sensor Installation (P/B 401)

C. Tools/Equipment

Reference	Description	
STD-562	Lens - Magnifying, 10x	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
414	Right Fan Cowl, Engine 1	

EFFECTIVITY ·

79-30-00

SIA ALL



(Continued)

Number	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

F. Prepare for the Inspection

SUBTASK 79-30-00-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-30-00-010-001-G00

(2) Do these tasks in sequence to safely open the left and right thrust reversers on the applicable engine:



DO THE DEACTIVATION PROCEDURE FOR THE THRUST REVERSER TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

- (a) Do this task: Thrust Reverser Deactivation For Ground Maintenance, TASK 78-31-00-040-801-G00.
- (b) Open the applicable left or right fan cowl panels (TASK 71-11-04-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO OPEN THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (c) Open the applicable left or right thrust reversers (TASK 78-31-00-010-801-G00).
 - 1) Open these access panels:

<u>Number</u>	<u>Name/Location</u>
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1

SIA ALL



(Continued)

<u>Number</u>	<u>Name/Location</u>
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

SUBTASK 79-30-00-480-001-G00

(3) Use good lighting and a 10x magnifying lens, STD-562 to help you see damage to the oil indicating system.

NOTE: Reject all parts that have wear or damage more than the applicable limits.

NOTE: Reject the parts that show wear or damage that is more than normal. Repair the minor damage to the applicable parts.

G. Oil Indicating System Inspection

SUBTASK 79-30-00-212-001-G00

- (1) Do the general checks of the oil level sensor [1], oil pressure and temperature sensor [5] and oil filter differential pressure sensor [8] as follows:
 - (a) Do a visual check to the parts for signs of wear, galled material, loose metal, cracks, nicks burrs, dents and other damage.
 - (b) Do a visual check to the treated parts for damage that shows bare metal.
 - (c) Do a visual check to the internal housing bores and machined surfaces for scores, wear, or damage.
 - (d) Do a check of the internal openings to be sure that they are clean and do not have blockages.
 - (e) Do a check of the threads for rough edges and defects.

NOTE: Make sure that the threads are satisfactory.

SUBTASK 79-30-00-010-002-G00

(2) Do this task: Oil Level Sensor Removal, TASK 79-31-01-000-801-G00.

SUBTASK 79-30-00-212-002-G00

- (3) Do the inspection of the oil level sensor [1] zones A, B1, B2, C1, C2, D1, D2 and E for these conditions:
 - (a) Scratches, nicks and dents
 - 1) Not permitted.
 - 2) Replace the oil level sensor [1].

SUBTASK 79-30-00-410-001-G00

(4) Do this task: Oil Level Sensor Installation, TASK 79-31-01-400-801-G00.

SUBTASK 79-30-00-212-003-G00

- (5) Do the inspection of the oil pressure and temperature sensor [5] for these conditions:
 - (a) Cracks, nicks, dents, scratches and deformations.
 - Not permitted.
 - Replace the oil pressure and temperature sensor [5] (TASK 79-32-01-000-801-G00 and TASK 79-32-01-400-801-G00).
 - (b) Visible voids and cracks at where the connector [6] and connector [7] are welded to the oil pressure and temperature sensor [5].
 - 1) Not permitted.



- Replace the oil pressure and temperature sensor [5] (TASK 79-32-01-000-801-G00 and TASK 79-32-01-400-801-G00).
- (c) Dents, cracks and loose or bent pins on the connector [6] and the connector [7].
 - 1) Not permitted.
 - Replace the oil pressure and temperature sensor [5] (TASK 79-32-01-000-801-G00 and TASK 79-32-01-400-801-G00).

SUBTASK 79-30-00-212-004-G00

- (6) Do the inspection of the oil filter differential pressure sensor [8] for these conditions:
 - (a) Cracks, nicks, dents, scratches and deformations.
 - 1) Not permitted if the oil filter differential pressure sensor [8] shows evidence of defects.
 - 2) Replace the oil filter differential pressure sensor [8] (TASK 79-35-01-000-801-G00 and TASK 79-35-01-400-801-G00).
 - (b) Voids and cracks where the connector [9] is welded to the oil filter differential pressure sensor [8].
 - 1) Not permitted.
 - 2) Replace the oil filter differential pressure sensor [8] (TASK 79-35-01-000-801-G00 and TASK 79-35-01-400-801-G00).
 - (c) Dents, cracks and loose or bent pins on connector [9].
 - 1) Not permitted.
 - Replace the oil filter differential pressure sensor [8] (TASK 79-35-01-000-801-G00 and TASK 79-35-01-400-801-G00).

H. Put the Airplane Back to Its Usual Condition

SUBTASK 79-30-00-410-002-G00



OBEY THE INSTRUCTIONS IN THE PROCEDURE TO CLOSE THE THRUST REVERSERS. IF YOU DO NOT OBEY THE INSTRUCTIONS, INJURIES TO PERSONS AND DAMAGE TO EQUIPMENT CAN OCCUR.

- (1) Do these tasks in sequence to safely close the applicable left or right thrust reversers:
 - (a) Do this task: Close the Thrust Reverser (Selection), TASK 78-31-00-010-802-G00.
 - Close these access panels:

<u>Number</u>	Name/Location
415	Left Thrust Reverser, Engine 1
416	Right Thrust Reverser, Engine 1
425	Left Thrust Reverser, Engine 2
426	Right Thrust Reverser, Engine 2

- (b) Do this task: Close the Fan Cowl Panels (Selection), TASK 71-11-04-410-801-G00.
 - 1) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
414	Right Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2
424	Right Fan Cowl, Engine 2

SIA ALL



(c) Do this task: Thrust Reverser Activation After Ground Maintenance, TASK 78-31-00-440-801-G00.

SUBTASK 79-30-00-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

I. Oil Indicating System Tests


SUBTASK 79-30-00-700-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

_____ END OF TASK _____

SIA ALL 79-30-00






2484318 S0000584153_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 1 of 7)

SIA ALL

D633AM101-SIA





2485636 S0000584593_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 2 of 7)


SIA ALL

D633AM101-SIA

79-30-00

Page 607 Sep 15/2021





NOTE:

ALL DIMENSIONS ARE IN INCHES (mm).

2485641 S0000584594_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 3 of 7)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-30-00

Page 608 Sep 15/2021





2485643 S0000584595_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 4 of 7)


SIA ALL

D633AM101-SIA

79-30-00

Page 609 Sep 15/2021





2485662 S0000584596_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 5 of 7)


SIA ALL


D633AM101-SIA

79-30-00

Page 610 Sep 15/2021







Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 6 of 7)


EFFECTIVITY


SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details







2485667 S0000584598_V1

Oil Indicating System Inspection Figure 601/79-30-00-990-801-G00 (Sheet 7 of 7)

EFFECTIVITY

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



OIL LEVEL SENSOR - REMOVAL/INSTALLATION

1. General

- A. This procedure contains two tasks:
 - (1) Oil level sensor removal
 - (2) Oil level sensor installation.

TASK 79-31-01-000-801-G00

2. Oil Level Sensor Removal

(Figure 401)

A. General

(1) This task gives the instructions on how to remove the oil level sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

NOTE: When more than one tool part number is listed under the same "Reference" number, the tools shown are alternates to each other within the same airplane series. Tool part numbers that are replaced or non-procurable are preceded by "Opt:", which stands for Optional.

Reference	Description
SPL-14904	Tool Set - Jackscrew
	Part #: 956A1609G01 Supplier: 58828
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE
STD-1055	Container - Oil Resistant, 5 Gallon (19 Liter)

D. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity	
1	Oil level sensor	79-31-01-01-020	SIA ALL	

E. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

F. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

G. Prepare for the Removal

SUBTASK 79-31-01-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.

SIA ALL



- 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
- (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-31-01-010-001-G00

- (2) On the applicable engine, open the right fan cowl panel (TASK 71-11-04-010-801-G00).
 - (a) Open these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

H. Oil Level Sensor Removal

SUBTASK 79-31-01-030-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Remove the oil level sensor [1] as follows:
 - (a) Put the oil resistant container (5 gal)(19 Liter), STD-1055 below the oil tank [2].



MAKE SURE ELECTRICAL CONNECTORS ARE CLEAN WHEN YOU DISCONNECT THEM. CONTAMINATION OF ELECTRICAL CONNECTORS CAN CAUSE DAMAGE TO EQUIPMENT.

SIA ALL 79-31-01



(CAUTION PRECEDES)



USE TEFLON-JAWED PLIERS TO LOOSEN ELECTRICAL CONNECTORS. DO NOT USE METAL-JAWED PLIERS. DAMAGE TO THE ELECTRICAL CONNECTORS COULD OCCUR.

- (b) Use the teflon-jawed pliers, STD-664 to disconnect the electrical connector [3] from the oil level sensor [1]:
 - 1) Disconnect the electrical connector [3] from the oil level sensor [1] (TASK 70-00-01-910-803-G00).
 - 2) Put the protective covers on the electrical connector [3] and the electrical receptacles on the oil level sensor [1].
- (c) Remove the three bolts [4] that attach the oil level sensor [1] on the oil tank [2].
- (d) Install the Tool Set, SPL-14904 jackscrews through the extraction bolt holes of the oil level sensor [1].

NOTE: You can use the bolts [4] as an alternative to the Tool Set, SPL-14904 jackscrews.




BE CAREFUL WHEN YOU REMOVE THE OIL LEVEL SENSOR BECAUSE OF ITS LENGTH. DAMAGE TO THE OIL LEVEL SENSOR CAN OCCUR.

- (e) Remove the oil level sensor [1] from the oil tank [2].
- (f) Remove and discard the preformed packing [5] and the preformed packing [6] from the grooves of the oil level sensor [1].
- (g) Remove the two Tool Set, SPL-14904 jackscrews from the extraction bolt holes of the oil level sensor [1].
- (h) Install the protective cover on the open port on the oil tank [2].

	END	OF TAS	SK
--	------------	--------	----

SIA ALL





Oil Level Sensor Installation Figure 401/79-31-01-990-801-G00 (Sheet 1 of 2)

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-31-01

Page 404 Sep 15/2021





Oil Level Sensor Installation Figure 401/79-31-01-990-801-G00 (Sheet 2 of 2)

SIA ALL

D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-31-01

Page 405 Sep 15/2021



TASK 79-31-01-400-801-G00

3. Oil Level Sensor Installation

(Figure 401)

A. General

(1) This task provides the instructions on how to install the oil level sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)	
STD-858	Tag - DO NOT OPERATE	

D. Consumable Materials

Reference	Description	Specification
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	Oil level sensor	79-31-01-01-020	SIAALL
5	Preformed packing	79-31-01-01-040	SIAALL
6	Preformed packing	79-31-01-01-030	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

H. Oil Level Sensor Installation

SUBTASK 79-31-01-420-001-G00



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(1) Install the oil level sensor [1] as follows:

SIA ALL



- (a) Remove the protective cover from the open port on the oil tank [2].
- (b) Make sure that the mating faces are clean and clear of unwanted materials.
- (c) Lubricate the new preformed packing [5] and the new preformed packing [6] with pure mineral vaseline, D00672 [CP5070].
- (d) Install the new preformed packing [5], and the new preformed packing [6] in the grooves of the oil level sensor [1].
- (e) Lubricate the threads of the three bolts [4] with graphite mineral vaseline, D00601 [CP2101].
- (f) Install the oil level sensor [1] on the oil tank [2].
 - NOTE: If the oil level sensor is new, make sure to remove all protective covers before installation.
- (g) Install the three bolts [4] that attach the oil level sensor [1] to the oil tank [2].
 - 1) Tighten the three bolts [4] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.



USE PLIERS THAT HAVE TEFLON JAWS TO TIGHTEN THE ELECTRICAL CONNECTORS. DO NOT USE PLIERS THAT HAVE METAL JAWS. METAL JAWS CAN CAUSE DAMAGE TO THE ELECTRICAL CONNECTORS.

- (h) Use the teflon-jawed pliers, STD-664 to connect the electrical connector [3] to the oil level sensor [1]:
 - 1) Remove the protective covers from the electrical connector [3] and the electrical receptacles on the oil level sensor [1].
 - 2) Connect the electrical connector [3] to the oil level sensor [1] (TASK 70-00-01-910-803-G00).
- (i) Clean the work area and clear the tools used to do the task.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-31-01-410-001-G00

- On the applicable engine, close the right fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
414	Right Fan Cowl, Engine 1
424	Right Fan Cowl, Engine 2

SUBTASK 79-31-01-860-002-G00

- (2) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SIA ALL

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL

J. Oil Level Sensor Installation Test

SUBTASK 79-31-01-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

----- END OF TASK -----

SIA ALL



OIL PRESSURE AND TEMPERATURE SENSOR - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil pressure and temperature sensor removal
 - (2) Oil pressure and temperature sensor installation.

TASK 79-32-01-000-801-G00

2. Oil Pressure and Temperature Sensor Removal

(Figure 401)

A. General

(1) This task provides the instructions on how to remove the oil pressure and temperature sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-203	Container - Oil Resistant, 1 U.SGal (3.8 I)
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	

F. Prepare for the Removal

SUBTASK 79-32-01-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-32-01-010-001-G00

(2) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).

SIA ALL

79-32-01



(a) Open these access panels:

<u>number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

G. Oil Pressure and Temperature Sensor Removal

SUBTASK 79-32-01-030-001-G00



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.



USE TEFLON-JAWED PLIERS TO LOOSEN ELECTRICAL CONNECTORS. DO NOT USE METAL-JAWED PLIERS. DAMAGE TO THE ELECTRICAL CONNECTORS COULD OCCUR.

- (1) Use the teflon-jawed pliers, STD-664 to disconnect the electrical connector HJ6A [3] and the electrical connector HJ6B [4] from the oil pressure and temperature sensor [1] as follows (TASK 70-00-01-910-803-G00):
 - (a) Disconnect the electrical connector HJ6A [3] and the electrical connector HJ6B [4] from the oil pressure and temperature sensor [1].
 - (b) Put the protective covers on the electrical connector HJ6A [3], the electrical connector HJ6B [4], and the electrical receptacles of the oil pressure and temperature sensor [1].

SUBTASK 79-32-01-020-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.

SIA ALL

79-32-01



(WARNING PRECEDES)




DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (2) Remove the oil pressure and temperature sensor [1] from the accessory gearbox [2] as follows:
 - (a) Put a 1 U.S.-gal (3.81 I) oil resistant container, STD-203 below the oil pressure and temperature sensor [1].
 - (b) Remove the two bolts [5] that attach the oil pressure and temperature sensor [1] to the accessory gearbox [2].
 - (c) Remove the oil pressure and temperature sensor [1] from the accessory gearbox [2].
 - (d) Remove and discard the preformed packing [6] and the preformed packing [7] from the oil pressure and temperature sensor [1].
 - (e) Install the protective covers on the open on the openings.

 END	OF TA	ZK –	





Oil Pressure and Temperature Sensor Installation Figure 401/79-32-01-990-801-G00 (Sheet 1 of 2)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-32-01

Page 404 Sep 15/2021





Oil Pressure and Temperature Sensor Installation Figure 401/79-32-01-990-801-G00 (Sheet 2 of 2)

- EFFECTIVITY **SIA ALL** D633AM101-SIA 79-32-01



TASK 79-32-01-400-801-G00

3. Oil Pressure and Temperature Sensor Installation

(Figure 401)

A. General

- (1) This task provides the instructions on how to install the oil pressure and temperature sensor.
- (2) You must do the tests that are listed in the power plant test reference table after you install the oil pressure and temperature sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	Oil pressure and temperature sensor	79-32-01-01-020	SIA ALL
6	Preformed packing	79-32-01-01-040	SIA ALL
7	Preformed packing	79-32-01-01-030	SIA ALL

F. Location Zones

I

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	

H. Oil Pressure and Temperature Sensor Installation

SUBTASK 79-32-01-420-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



(WARNING PRECEDES)



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Install the oil pressure and temperature sensor [1] as follows:
 - (a) Remove the protective covers from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Lubricate the new preformed packing [6] and the new preformed packing [7] with vaseline, D00672 [CP5070].
 - (d) Lubricate the threads of the two bolts [5] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new preformed packing [6] and the new preformed packing [7] onto the grooves of the oil pressure and temperature sensor [1].
 - (f) Install the oil pressure and temperature sensor [1] with the new preformed packing [6] and new preformed packing [7] on the accessory gearbox [2].
 - (g) Install the two bolts [5] that attach the oil pressure and temperature sensor [1] to the accessory gearbox [2].
 - 1) Tighten the bolts [5] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-32-01-430-001-G00



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.



(CAUTION PRECEDES)



DO NOT USE PLIERS THAT HAVE METAL JAWS TO TIGHTEN THE ELECTRICAL CONNECTOR. DAMAGE TO THE ELECTRICAL CONNECTOR CAN OCCUR.

- (2) Use the teflon-jawed pliers, STD-664 to connect the electrical connector HJ6A [3] and the electrical connector HJ6B [4] to the oil pressure and temperature sensor [1] as follows (TASK 70-00-01-910-803-G00).
 - (a) Remove the protective covers from the electrical connector HJ6A [3], the electrical connector HJ6B [4], and the electrical receptacles of the oil pressure and temperature sensor [1].
 - (b) Connect the electrical connector HJ6A [3] and the electrical connector HJ6B [4] to the oil pressure and temperature sensor [1].
 - (c) Tighten the electrical connector HJ6A [3] and the electrical connector HJ6B [4].

SUBTASK 79-32-01-860-002-G00

(3) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-32-01-860-003-G00

- (1) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SUBTASK 79-32-01-410-001-G00

- (2) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

J. Oil Pressure and Temperature Sensor Installation Test

SUBTASK 79-32-01-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

 END	OF	TASK	
	\sim 1	IASIN	



OIL FILTER DIFFERENTIAL PRESSURE SENSOR - REMOVAL/INSTALLATION

1. General

- A. This procedure has two tasks:
 - (1) Oil filter differential pressure sensor removal
 - (2) Oil filter differential pressure sensor installation.

TASK 79-35-01-000-801-G00

2. Oil Filter Differential Pressure Sensor Removal

(Figure 401)

A. General

- (1) This task provides the instructions on how to remove the oil filter differential pressure sensor.
- (2) The oil filter differential pressure sensor is referred to as the oil filter DP sensor.

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-11-04-010-801-G00	Open the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description	
STD-203	Container - Oil Resistant, 1 U.SGal (3.8 I)	
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)	
STD-858	Tag - DO NOT OPERATE	

D. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

E. Access Panels

Number	Name/Location	
413	Left Fan Cowl, Engine 1	
423	Left Fan Cowl, Engine 2	

F. Prepare for the Removal

SUBTASK 79-35-01-860-001-G00

- (1) Do these steps to make sure that the ENGINE START switch and the START LEVER switch are not operated:
 - (a) Make sure that the applicable ENGINE START switch, on the P5 overhead panel, is in the AUTO or OFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable ENGINE START switch.
 - (b) Make sure that the applicable START LEVER switch, on the P10 control stand, is in the CUTOFF position.
 - 1) Put a DO NOT OPERATE tag, STD-858, on the applicable START LEVER switch.

SUBTASK 79-35-01-010-001-G00

(2) On the applicable engine, open the left fan cowl panel (TASK 71-11-04-010-801-G00).

SIA ALL

79-35-01



(a) Open these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

G. Oil Filter Differential Pressure Sensor Removal

SUBTASK 79-35-01-030-001-G00



MAKE SURE THAT THE ELECTRICAL CONNECTORS AND RECEPTACLES ARE CLEAN AND CLEAR OF UNWANTED MATERIALS BEFORE YOU DISCONNECT, OR CONNECT THEM. CONTAMINATION OF THE ELECTRICAL CONNECTORS AND RECEPTACLES CAN CAUSE DAMAGE TO EQUIPMENT.



USE TEFLON-JAWED PLIERS TO LOOSEN ELECTRICAL CONNECTORS. DO NOT USE METAL-JAWED PLIERS. DAMAGE TO THE ELECTRICAL CONNECTORS COULD OCCUR.

- (1) Use the teflon-jawed pliers, STD-664 to disconnect the electrical connector [3] from the oil filter DP sensor [1] (TASK 70-00-01-910-803-G00):
 - (a) Disconnect the electrical connector [3] from the oil filter DP sensor [1].
 - (b) Put the protective covers on the electrical connector [3] and the electrical receptacle of the oil filter DP sensor [1].

SUBTASK 79-35-01-020-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

(2) Remove the oil filter DP sensor [1] as follows:

SIA ALL

79-35-01

Page 402 May 15/2023

LEAP-1B ENGINES



737-7/8/8200/9/10 AIRCRAFT MAINTENANCE MANUAL


- (a) Put a 1 U.S.-gal (3.81 I) oil resistant container, STD-203 below the oil filter DP sensor [1].
- (b) Remove the two bolts [4] that attach the oil filter DP sensor [1] to the lubrication unit [2].
- (c) Remove the oil filter DP sensor [1] from the lubrication unit [2].
- (d) Remove and discard the preformed packing [5] and the preformed packing [6] from the oil filter DP sensor [1].
- (e) Install the protective covers on the openings.

ENID	OF TA	CV	
 CIND	UE IF	13N -	

SIA ALL

79-35-01





Oil Filter Differential Pressure Sensor Installation Figure 401/79-35-01-990-801-G00 (Sheet 1 of 2)

EFFECTIVITY

SIA ALL


D633AM101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

79-35-01

Page 404 Sep 15/2021





A0002-A-002-01

Oil Filter Differential Pressure Sensor Installation Figure 401/79-35-01-990-801-G00 (Sheet 2 of 2)

- EFFECTIVITY SIA ALL D633AM101-SIA 79-35-01

Page 405 Sep 15/2021



TASK 79-35-01-400-801-G00

3. Oil Filter Differential Pressure Sensor Installation

(Figure 401)

A. General

- (1) This task provides the instructions on how to install the oil filter differential pressure sensor.
- (2) The oil filter differential pressure sensor is referred to as the oil filter DP sensor [1].
- (3) You must do the tests that are listed in the power plant test reference table after you install the oil filter DP sensor [1].

B. References

Reference	Title
70-00-01-910-803-G00	Electrical Connector Disconnection and Connection (P/B 201)
71-00-00-800-804-G00	Power Plant Test Reference Table (P/B 501)
71-11-04-410-801-G00	Close the Fan Cowl Panels (Selection) (P/B 201)

C. Tools/Equipment

Reference	Description
STD-664	Pliers - Teflon-jawed (or Equivalent Soft-Jawed)
STD-858	Tag - DO NOT OPERATE

D. Consumable Materials

Reference	Description	Specification
D00601 [CP2101]	Vaseline - Graphite Mineral	
D00672 [CP5070]	Vaseline - Pure Mineral	V V-P-236

E. Expendables/Parts

AMM Item	Description	AIPC Reference	AIPC Effectivity
1	Oil filter DP sensor	79-35-01-01-020	SIA ALL
5	Preformed packing	79-35-01-01-040	SIA ALL
6	Preformed packing	79-35-01-01-030	SIA ALL

F. Location Zones

Zone	Area
411	Engine 1 - Engine
421	Engine 2 - Engine

G. Access Panels

Number	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

H. Oil Filter Differential Pressure Sensor Installation

SUBTASK 79-35-01-420-001-G00



BE CAREFUL WHEN YOU DO WORK ON THE ENGINE PARTS AFTER THE ENGINE IS STOPPED. THE ENGINE PARTS CAN STAY HOT FOR ALMOST ONE HOUR. DO NOT TOUCH HOT PARTS WITHOUT APPLICABLE GLOVES. HOT PARTS CAN CAUSE INJURIES TO PERSONNEL.

SIA ALL

79-35-01



(WARNING PRECEDES)



DO NOT OPEN THE OIL SYSTEM UNTIL THE PRESSURE GOES TO ZERO. THE PRESSURE GOES TO ZERO APPROXIMATELY 5 MINUTES AFTER AN ENGINE STOPS. A PRESSURIZED OIL SYSTEM CAN RELEASE A SPRAY OF HOT OIL THAT CAN BURN YOU.



DO NOT LET HOT OIL GET ON YOU. PUT ON CLOTHES, GOGGLES, AND OTHER EQUIPMENT FOR PROTECTION, OR LET THE ENGINE BECOME COOL. HOT OIL CAN BURN YOU.



DO NOT LET THE OIL STAY ON YOUR SKIN. YOU CAN ABSORB POISONOUS MATERIALS FROM THE OIL THROUGH YOUR SKIN.



DO NOT LET OIL GET ON THE ENGINE OR OTHER COMPONENTS. IMMEDIATELY CLEAN THE OIL WHEN IT FALLS ON THEM. OIL CAN CAUSE DAMAGE TO EQUIPMENT.

- (1) Install the oil filter DP sensor [1] as follows:
 - (a) Remove the protective covers from the openings.
 - (b) Make sure that the mating faces are clean and clear of unwanted materials.
 - (c) Lubricate the new preformed packing [5] and the new preformed packing [6] with vaseline, D00672 [CP5070].
 - (d) Lubricate the threads of the two bolts [4] with graphite mineral vaseline, D00601 [CP2101].
 - (e) Install the new preformed packing [5] and the new preformed packing [6] in the grooves of the oil filter DP sensor [1].
 - (f) Install the oil filter DP sensor [1] on the lubrication unit [2].
 - (g) Install the two bolts [4] that attach the oil filter DP sensor [1] to the lubrication unit [2].
 - (h) Torque the two bolts [4] to 109.31 in-lb (12.35 N·m) 120.81 in-lb (13.65 N·m).

SUBTASK 79-35-01-420-002-G00



MAKE SURE THAT THE ELECTRICAL CONNECTOR AND RECEPTACLE ARE CLEAN WHEN YOU CONNECT THEM. DIRTY CONNECTORS CAN CAUSE DAMAGE TO EQUIPMENT.



DO NOT USE PLIERS THAT HAVE METAL JAWS TO TIGHTEN THE ELECTRICAL CONNECTOR. DAMAGE TO THE ELECTRICAL CONNECTOR CAN OCCUR.

- (2) Use the teflon-jawed pliers, STD-664 to connect the electrical connector [3] to the oil filter DP sensor [1] (TASK 70-00-01-910-803-G00):
 - (a) Remove the protective covers from the electrical connector [3] and the electrical receptacle of the oil filter DP sensor [1].

D633AM101-SIA

(b) Connect the electrical connector [3] to the oil filter DP sensor [1].

SIA ALL

79-35-01

Page 407 May 15/2023



(c) Tighten the electrical connector [3].

SUBTASK 79-35-01-860-002-G00

(3) Clean the work area and clear the tools and other items.

I. Put the Airplane Back to Its Usual Condition

SUBTASK 79-35-01-860-003-G00

- (1) Do these steps to remove the DO NOT OPERATE tags, STD-858, from the applicable ENGINE START switch and START LEVER switch:
 - (a) On the P5 overhead panel, remove the DO NOT OPERATE tag, STD-858, from the applicable ENGINE START switch.
 - (b) On the P10 control stand, remove the DO NOT OPERATE tag, STD-858, from the applicable START LEVER switch.

SUBTASK 79-35-01-410-001-G00

- (2) On the applicable engine, close the left fan cowl panel (TASK 71-11-04-410-801-G00).
 - (a) Close these access panels:

<u>Number</u>	Name/Location
413	Left Fan Cowl, Engine 1
423	Left Fan Cowl, Engine 2

J. Oil Filter Differential Pressure Sensor Installation Test

SUBTASK 79-35-01-730-001-G00

(1) Do the test(s) that are given in the Power Plant Test Reference Table (TASK 71-00-00-800-804-G00).

----- END OF TASK -----