

CHAPTER

54

Nacelles and Pylons



CHAPTER 54
NACELLES AND PYLONS

Subject/Page	Date	COC	Subject/Page	Date	COC
54-EFFECTIVE PAGES					
1	Oct 15/2023				
2	BLANK				
54-CONTENTS					
1	Oct 15/2021				
2	BLANK				
54-00-00					
1	Oct 15/2021				
2	Oct 15/2021				
3	Oct 15/2021				
4	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

54-EFFECTIVE PAGES



CHAPTER 54
NACELLES AND PYLONS

<u>CH-SC-SU</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>EFFECT</u>
54-00-00	NACELLES-PYLONS - GENERAL DESCRIPTION	2	SIA ALL

54-CONTENTS



THIS PAGE IS INTENTIONALLY LEFT BLANK

54-00-00

D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

**NACELLES-PYLONS - GENERAL DESCRIPTION****General**

The nacelle is the fairings and the components that surround the engine. The nacelle gives an aerodynamically smooth surface to the strut and engine. The nacelle also contains these items:

- Inlet cowl
- Fan cowl
- Fan duct cowl and thrust reverser
- Primary exhaust nozzle
- Exhaust plug.

The pylon is the strut that attaches the engine to the wing. The strut also contains these items:

- Fuel lines
- Electrical lines
- Hydraulic lines
- Pneumatic ducts
- Fairings
- Fire detection/extinguish lines.


Nacelle stations and waterlines give locations on the nacelle-ylon. The scale for nacelle stations and waterlines is inches.

The station line is a horizontal dimension. It starts at station line zero.

The water line is a height dimension. You measure the water line from a horizontal reference plane below the nacelle-ylon.

EFFECTIVITY	
SIA ALL	

NACELLES-PYLONS - GENERAL DESCRIPTION



M87797 S0004631929_V2

NACELLES-PYLONS - GENERAL DESCRIPTION

54-00-00

SIA ALL	EFFECTIVITY
	D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

