

CHAPTER

55

Stabilizers

CHAPTER 55
STABILIZERS

Subject/Page	Date	COC	Subject/Page	Date	COC
55-EFFECTIVE PAGES					
1	Oct 15/2023				
2	BLANK				
55-CONTENTS					
1	Oct 15/2021				
2	BLANK				
55-00-00					
1	Oct 15/2021				
2	Oct 15/2021				
3	Oct 15/2021				
4	Oct 15/2021				
5	Oct 15/2021				
6	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

55-EFFECTIVE PAGES



CHAPTER 55
STABILIZERS

<u>CH-SC-SU</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>EFFECT</u>
55-00-00	STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION	2	SIA ALL
55-00-00	STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION	4	SIA ALL

55-CONTENTS

D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details



THIS PAGE IS INTENTIONALLY LEFT BLANK

55-00-00

D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

**STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION****General**

Most of material in the horizontal stabilizer is aluminum. The elevator is graphite composite.

Horizontal Stabilizer Reference Dimensions

The horizontal stabilizer has three reference dimensions. These reference dimensions give horizontal stabilizer locations in inches. Measure each location from buttock line 0. These are the horizontal stabilizer reference dimensions:

- Stabilizer station
- Stabilizer leading edge station
- Elevator station.

Measure stabilizer stations perpendicular to the horizontal stabilizer rear spar.

Measure stabilizer leading edge stations perpendicular to the horizontal stabilizer leading edge.

Measure elevator stations perpendicular to the elevator hinge centerline.


55-00-00

SIA ALL EFFECTIVITY

D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION



M87798 S0004631934_V2

STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION

55-00-00

SIA ALL	EFFECTIVITY
	D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

**STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION****General**

Most of material in the vertical stabilizer is aluminum. The rudder is graphite composite.

Vertical Stabilizer Reference Dimensions

The vertical stabilizer has four reference dimensions. These reference dimensions give vertical stabilizer locations in inches. These are the vertical stabilizer reference dimensions:

- Vertical stabilizer station
- Vertical stabilizer leading edge station
- Rudder station
- Vertical stabilizer waterline.

Measure the vertical stabilizer station perpendicular to the vertical stabilizer rear spar. Vertical stabilizer station 0 starts at the body crown line.

Measure the vertical stabilizer leading edge station perpendicular to the vertical stabilizer leading edge. Vertical stabilizer leading edge station 0 starts at the body crown line.

Measure the rudder station perpendicular to the rudder hinge centerline. Rudder station 0 starts at the body crown line.


Measure the vertical stabilizer waterline parallel to the body waterline.

55-00-00**SIA ALL EFFECTIVITY**

D633A101-SIA

ECCN 9E991 BOEING PROPRIETARY - See title page for details

STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION



M87799 S0004631936_V1

STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION

55-00-00

SIA ALL	EFFECTIVITY
	D633A101-SIA

